

## Beautiful 19263

# Beautiful Slush Crush 60 oz 4-Speed Frozen Drink Maker Instruction Manual

Model: 19263

## 1. INTRODUCTION

Thank you for choosing the Beautiful Slush Crush Frozen Drink Maker. This appliance is designed to create a variety of frozen beverages, including smoothies, slushies, and snow cones, with ease and efficiency. Featuring a 60 oz Tritan BPA-free jar and a powerful 800-watt motor, it ensures consistent results for up to 10 frozen drinks in 60 seconds. The PrecisionSense blade technology and 4 preset functions simplify operation, providing optimal drink consistency at the touch of a button.

Please read this manual thoroughly before first use to ensure safe and proper operation of your appliance. Keep these instructions for future reference.

## 2. IMPORTANT SAFETY INFORMATION

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the appliance.
- Do not touch moving parts.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then

remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Blades are sharp. Handle with care.
- Ensure the lid is securely locked in place before operating the appliance.

### **3. PACKAGE CONTENTS**

---

Your Beautiful Slush Crush Frozen Drink Maker package includes the following components:

- Motor Base
- 60 oz Tritan BPA-free Jar with Spout
- Lid with Measuring Cup Insert
- Blade Assembly (pre-installed in jar)



*Image: Exploded view showing the motor base, jar with blade assembly and spout, and lid with measuring cup insert.*

## 4. SETUP AND ASSEMBLY

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or disposal.

2. **Clean Before First Use:** Wash the jar, lid, and blade assembly in warm, soapy water. Rinse thoroughly and dry. The jar and lid are dishwasher safe (top rack recommended). Do not immerse the motor base in water.
3. **Assemble the Jar:** Ensure the blade assembly is securely seated at the bottom of the jar.
4. **Place Jar on Motor Base:** Position the assembled jar onto the motor base. Align the jar with the base and twist clockwise until it locks securely into place. You should feel it click.
5. **Secure the Lid:** Place the lid onto the jar and twist clockwise to lock it. Ensure the measuring cup insert is placed into the lid opening.
6. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet. The appliance is now ready for use.



*Image: The Beautiful Slush Crush Frozen Drink Maker fully assembled and ready for use.*

## 5. OPERATING INSTRUCTIONS

---

The Beautiful Slush Crush Frozen Drink Maker features 4 preset functions and a Pulse option for versatile blending. Always ensure the jar is securely locked onto the base and the lid is properly sealed before operation.

### 5.1 Adding Ingredients

1. Ensure the appliance is unplugged before adding ingredients.
2. Remove the lid. Add your desired ingredients to the 60 oz Tritan jar. For best results with frozen drinks, add liquids first, then soft ingredients, and finally ice or frozen fruit. Do not exceed the MAX fill line.
3. Replace and securely lock the lid.



*Image: A hand pouring liquid ingredients into the blender jar, which already contains ice cubes.*

## **5.2 Using Preset Functions**

The control panel features dedicated buttons for specific blending tasks:



Image: Close-up of the control panel showing buttons for Frozen Drink, Smoothie, Snow Cone, Pulse, and Dispense, along with the power button.

- **Frozen Drink:** Press this button for optimal blending of frozen cocktails, margaritas, and other icy beverages. The PrecisionSense blade technology will adjust for consistent results.
- **Snow Cone:** This setting is designed to crush ice into a fine, fluffy consistency suitable for snow cones.
- **Smoothie:** Use this function for blending fruits, vegetables, and liquids into smooth, creamy smoothies.
- **Pulse:** Press and hold the "Pulse" button for short bursts of blending. Release to stop. This is useful for chopping ingredients or controlling texture.
- **Dispense:** After blending, press the "Dispense" button to activate the no-drip spout for easy pouring directly into glasses.

To start a preset function, simply press the corresponding button. The appliance will run through its programmed cycle and stop automatically. To stop blending at any time, press the power button.

### 5.3 Dispensing Your Drink

Once your drink is blended to your desired consistency, place a glass under the spout and press the "Dispense" button. The spout is designed for no-mess pouring.



*Image: A red frozen drink being dispensed from the blender's spout into a margarita glass.*

## 6. CARE AND MAINTENANCE

Proper cleaning and maintenance will ensure the longevity and optimal performance of your Beautiful Slush Crush Frozen Drink Maker.

1. **Always Unplug:** Before cleaning, always ensure the appliance is unplugged from the power outlet.
2. **Jar and Lid:** The 60 oz Tritan jar and lid are dishwasher safe. For manual cleaning, wash in warm, soapy water using a non-abrasive sponge. Rinse thoroughly and dry completely. Handle the blade assembly with extreme care as blades are sharp.
3. **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
4. **Storage:** Store the assembled appliance in a clean, dry place.

## 7. TROUBLESHOOTING

If you encounter issues with your Slush Crush Frozen Drink Maker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in. Jar not properly seated/locked. Power outage.	Ensure power cord is securely plugged into a working outlet. Twist jar clockwise until it clicks into place. Check household circuit breaker.
Ingredients are not blending smoothly.	Too much ice/frozen ingredients. Not enough liquid. Ingredients are too large.	Reduce the amount of ice/frozen ingredients. Add more liquid. Cut ingredients into smaller pieces before blending. Use the Pulse function for stubborn ingredients.
Loud noise or vibration during operation.	Jar not properly seated. Overloaded. Foreign object in jar.	Ensure jar is securely locked onto the motor base. Reduce ingredients. Unplug, remove jar, and check for any obstructions.
Spout is clogged or not dispensing.	Thick mixture. Ingredient lodged in spout.	Add more liquid to thin the mixture. Unplug, remove jar, and carefully clear the spout opening.

## 8. PRODUCT SPECIFICATIONS

- **Model Number:** 19263
- **Brand:** Beautiful
- **Color:** Lavender
- **Capacity:** 60 oz (approx. 1.77 Liters)
- **Power:** 800 Watts
- **Voltage:** 120 Volts
- **Number of Speeds:** 4 (Preset Functions)
- **Product Dimensions (D x W x H):** 15.35" x 8.58" x 8.58"
- **Item Weight:** 4.9 Pounds
- **Material:** Plastic (BPA Free Tritan Jar)
- **Blade Material:** Stainless Steel
- **Special Features:** Dishwasher Safe Parts (Jar & Lid), PrecisionSense Blade Technology, No-Drip Pulse and Dispense Spout

## 9. WARRANTY AND SUPPORT

This Beautiful Slush Crush Frozen Drink Maker comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product packaging or contact customer support.

For technical support, replacement parts, or any questions regarding your appliance, please visit the official Beautiful Kitchenware website or contact their customer service department. Contact information can typically be found in the

product packaging or on the manufacturer's website.



© 2024 Beautiful Kitchenware. All rights reserved.