

## Rolosar Q76

# Rolosar Q76 Wireless Earbuds User Manual

Model: Q76

## 1. INTRODUCTION

---

Thank you for choosing the Rolosar Q76 Wireless Earbuds. This manual provides detailed instructions for the proper use, setup, and maintenance of your earbuds. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

## 2. PACKAGE CONTENTS

---

The Rolosar Q76 Wireless Earbuds package typically includes:

- Rolosar Q76 Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- Multiple Sizes of Ear Tips (S/M/L)
- User Manual

## 3. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your Rolosar Q76 Wireless Earbuds.



Image of Rolosar Q76 Wireless Earbuds in their open charging case, displaying the earbuds and the digital battery indicator.

## Key Features:

- **Bluetooth 5.4:** For stable and efficient wireless connection.
- **ENC Noise Canceling Mic:** Ensures clear call quality.
- **IP7 Waterproof:** Resistant to sweat, rain, and splashes.
- **Flexible Earhooks:** Provides a secure and comfortable fit for sports.
- **Dual LED Display:** Shows battery status of earbuds and charging case.
- **Smart Touch Control:** Intuitive control over music and calls.

## 4. SETUP

### 4.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB Type-C charging cable to the charging port on the case and to a power source.

3. The LED display on the case will indicate the charging status.

#### Charging Times:

- Earbuds: Approximately 1.5 hours for a full charge.
- Charging Case: Approximately 2 hours for a full charge.

A fully charged earbud provides about 10 hours of playtime. The charging case provides multiple additional charges, extending total playtime to approximately 50 hours.



Graphic depicting the battery life and charging times for the Rolosar Q76 earbuds and their charging case, showing 10 hours playtime per charge and 50 hours total with the case.

## 4.2. Bluetooth Pairing

The earbuds feature Bluetooth 5.4 for a fast and stable connection.

1. **Power On:** Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode.
2. **Activate Bluetooth:** On your device (smartphone, tablet, laptop), enable Bluetooth.
3. **Select Device:** In your device's Bluetooth settings, search for available devices and select "Q76" to connect.

4. **Confirmation:** Once connected, you will hear an audio prompt, and the earbuds will be ready for use.

The earbuds will automatically reconnect to the last paired device when removed from the charging case, provided Bluetooth is enabled on the device.

# 2025 Bluetooth 5.4

## ONE STEP AUTO PAIRING

Step1: Open the lid (Earbuds auto power on)

Step2: After open the Phone Bluetooth, Click the <Q76> to Pairing



Illustration demonstrating the one-step auto-pairing process for the Rolosar Q76 earbuds, showing a phone's Bluetooth settings connecting to 'Q76'.

## 5. OPERATING INSTRUCTIONS

### 5.1. Wearing the Earbuds

The Rolosar Q76 earbuds are designed with flexible earhooks for a secure and comfortable fit, especially during physical activity.

1. **Choose Ear Tips:** Select the ear tips (S/M/L) that best fit your ear canal for optimal sound and comfort.
2. **Position Earhook:** Gently place the earbud into your ear and loop the flexible earhook over the top of your ear.
3. **Adjust:** Rotate and adjust the earbud and earhook until it feels secure and comfortable.

# Hi-Fi Stereo & Deep Bass

HD Mic, Clear Call, Noise Reduction



Diagram illustrating the three steps for properly wearing the Rolosar Q76 earbuds: selecting ear tips, positioning the earhook, and adjusting for comfort.

## 5.2. Smart Touch Controls

The earbuds feature high-sensitivity touch controls located on the upper part of each earbud's surface.

Action	Function
Single Tap (L/R)	Play/Pause Music, Answer/End Call
Double Tap (L)	Previous Song
Double Tap (R)	Next Song
Triple Tap (L)	Volume Down (-)
Triple Tap (R)	Volume Up (+)
Long Press (L/R)	Activate Voice Assistant, Reject Call
Tap 5 times simultaneously (L & R)	Unpair Earbuds

# SMART TOUCH CONTROL

High-sensitivity smart touch brings easy operation



Visual guide to the smart touch controls on the Rolosar Q76 earbuds, detailing functions like power on/off, play/pause, volume adjustment, call management, and voice assistant activation.

## 5.3. Audio Quality

The Rolosar Q76 earbuds are equipped with 14.2mm double-layer diaphragm drivers, delivering Hi-Fi stereo sound with strong bass, clear mids, and bright treble. The built-in ENC (Environmental Noise Canceling) microphone ensures your voice is transmitted clearly during calls by reducing ambient distractions.

## Designed for sports Earhooks Design

Comfortable, firm, not easy to fall off



- ① Choose the right size ear caps.
- ② Place the earhook over your ear.
- ③ Rotate and adjust to a comfortable angle.

Exploded view diagram of the earbud's internal components, highlighting the 14.2mm double-layer diaphragm drivers responsible for Hi-Fi stereo sound and deep bass.

## 6. MAINTENANCE

### 6.1. Waterproofing

The Rolosar Q76 earbuds feature an IP7 waterproof rating, making them resistant to sweat, rain, and minor water splashes. This makes them suitable for workouts and outdoor activities. However, they are not designed for submersion in water (e.g., swimming).

# 50H LONG PLAYTIME



Image illustrating the IP7 waterproof capabilities of the Rolosar Q76 earbuds, showing them resistant to rain, sweat, and minor splashes.

## 6.2. Cleaning and Storage

- Regularly clean the ear tips and charging contacts with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive materials.
- Store the earbuds in their charging case when not in use to protect them from dust and damage.
- Keep the device away from extreme temperatures and direct sunlight.

## 7. TROUBLESHOOTING

If you encounter any issues with your Rolosar Q76 earbuds, please refer to the following common solutions:

- **No Sound/Connection Issues:**
  - Ensure earbuds are charged.
  - Verify Bluetooth is enabled on your device and

