

Augnner B005

Augnner Sound Machine Alarm Clock User Manual

Model: B005

INTRODUCTION

Thank you for choosing the Augnner Sound Machine Alarm Clock. This device combines a white noise sound machine, alarm clock, night light, and Bluetooth speaker into one compact unit, designed to enhance your sleep environment and daily routine. This manual provides detailed instructions for setup, operation, and maintenance.



The Augnner Sound Machine Alarm Clock, a compact device designed for sleep and daily use.

PRODUCT FEATURES

The Augnner Sound Machine Alarm Clock offers a versatile set of features:

- **32 Non-Looping Soothing Sounds:** Includes white noise, brown noise, pink noise, and natural sounds like rain, streams, birdsong, waves, and more, designed to create an optimal sleep environment.
- **Dimmable Alarm Clock:** Features a clock display with adjustable brightness (off, 10%, 50%, 100%). Set alarms with 32 gentle natural wake-up sounds that gradually increase in volume. Includes a 9-minute snooze function.
- **Multi-functional Night Light:** Offers 8 unique light modes, RGB breathing, and 3000 adjustable color temperatures. Infinite dimming and color changes are controllable via the app. Can be used as a bedside lamp or wake-up light.
- **Bluetooth Speaker:** Connects via Bluetooth 5.3 for fast and stable audio streaming.
- **Smart App Control:** Control all functions including sound, volume, light color, brightness, and auto-off timer via a dedicated mobile application (available for iOS and Android).
- **Portable Design:** Compact size (3.15 x 3.15 x 1.85 inches) makes it suitable for home, office, or travel.
- **Long-lasting Battery & Memory Function:** Equipped with an 800 mAh built-in battery, providing 8+ hours of

continuous use after 1-2 hours of Type-C charging. Remembers previous settings for volume, brightness, tracks, alarm, and timers.



The device functions as a sound machine, alarm clock, Bluetooth speaker, and night light.

PACKAGE CONTENTS


Please check the box for the following items:

- Augnner Sound Machine Alarm Clock (Model: B005)
- USB Type-C Charging Cable
- User Manual

PRODUCT CONTROLS AND OVERVIEW

Familiarize yourself with the buttons and ports on your Augnner Sound Machine Alarm Clock:

Multi-function noise machine



Auto-Off Timer:
No time limit




800 mAh Battery:
8H ultra-long standby



Child Lock:
Prevent misoperation,
suitable for breastfeeding moms

Top view of the Augnner Sound Machine with labeled controls.



A detailed diagram illustrating the function of each button on the device.

Button Functions Overview

Button/Icon	Function	Action
+	Volume Up / Previous Sound	Short press: Increase volume. Long press: Go to previous track.
-	Volume Down / Next Sound	Short press: Decrease volume. Long press: Go to next track.
▶	Play/Pause / Bluetooth Pairing	Short press: Play/Pause sound. Long press (2+ seconds): Enter Bluetooth mode.
(Bell Icon)	Alarm Clock Button	Short press: Turn alarm on/off. Long press (2 seconds): Enter alarm settings. Short press again: Cycle through settings (hour, minute, ringtone, volume, workday). Adjust values with +/- keys.
(Clock Icon)	Time Setting	Long press to enter time setting mode. Adjust values with +/- keys.
(Light Bulb Icon)	Light Control / Snooze	Short press: Cycle through light modes/brightness. When alarm sounds, short press for 9-minute snooze.
(Timer Icon)	Timer Button	Short press: Start timer. Short press again: Cycle through auto-off durations (30/60/90/120/240 minutes/OFF).
(Power Icon)	Power Switch / Display Dimmer	Short press: Adjust clock display brightness (Off-10%-50%-100%). Long press: Power On/Off.

SETUP

1. Charging the Device

Before first use, fully charge the device. Connect the provided USB Type-C cable to the charging port on the back of the device and plug the other end into a USB power adapter (not included) or a computer USB port.

- A full charge takes approximately 1-2 hours.
- The device can operate for 8+ hours on a full charge.
- The app displays the exact battery status.

2. Power On/Off


To power on the device, long press the (Power Icon) button. To power off, long press the same button again.

3. App Download and Connection

For smart control and extended features, download the companion app. Search for "White Whisper" in your app store or scan the QR codes below:

Safely Download Free APP

Search for White Whisper in the App Store or
Scan the QR code to download



Scan the QR codes to download the "White Whisper" app from various app stores.

- **iOS App Store:** [Download for iOS](#)
- **Google Play Store:** [Download for Android \(Google Play\)](#)
- **Alternative Android App Store:** [Download for Android \(Alternative\)](#)

Once the app is installed:

1. Ensure Bluetooth is enabled on your smartphone.
2. Open the "White Whisper" app.
3. The app will automatically search for and connect to your Augnner Sound Machine. If prompted, confirm the connection.

OPERATING INSTRUCTIONS

1. Sound Playback

- **Playing Sounds:** The device will typically start playing a default sound upon power-on.
- **Changing Sounds:** Long press the + button for the previous sound or the- button for the next sound. There are 32 soothing sounds available.
- **Adjusting Volume:** Short press the + button to increase volume or the- button to decrease volume.
- **Pause/Play:** Short press the ▶ || button to pause or resume playback.

32 Soothing Sounds--More choices for better sleep



Brown noise




Pink noise



White noise




Soft music



Ocean waves



Thunderstorm



Wind



Whistle



Fetal sounds



Bird



Fire flames



Train



12 sleep white noise sounds



8 environmental sounds



8 natural sounds



4 object sounds

A visual representation of the 32 soothing sounds available, including various types of noise and natural sounds.

2. Night Light Control

- **Changing Light Modes/Brightness:** Short press the (Light Bulb Icon) button to cycle through 8 unique light modes and adjust brightness.
- **App Control:** For infinite dimming, RGB breathing, and 3000 adjustable color temperatures, use the "White Whisper" app.

8 Colors Night Light

Infinite dimming and **3000** color temperatures change can be achieved through APP



The mobile app interface for controlling the night light's colors and brightness.

3. Alarm Clock Settings

- **Setting Alarm:** Long press the (Bell Icon) button for 2 seconds to enter alarm settings.
- **Adjusting Settings:** Short press the button again to cycle through settings: hour, minute, ringtone (choose from 32 sounds), alarm volume, and workday settings. Use the + and - buttons to adjust values.
- **Turning Alarm On/Off:** Short press the (Bell Icon) button to toggle the alarm on or off.
- **Snooze Function:** When the alarm sounds, short press the (Light Bulb Icon) button for a 9-minute snooze.

Smart alarm clock

 0%-100% screen brightness

 16 levels of volume

 32 wake-up sounds

 Set alarm according Monday to Sunday

 Up to 7 alarms can be set simultaneously



The device's smart alarm clock features, including app control for setting multiple alarms and choosing wake-up sounds.

4. Auto-off Timer

- Setting Timer:** Short press the (Timer Icon) button to activate the auto-off timer.
- Cycling Durations:** Short press the button again to cycle through preset durations: 30, 60, 90, 120, 240 minutes, or OFF.
- App Control:** The app allows you to set the auto-off timer for any custom duration.

5. Clock Display

- Adjusting Brightness:** Short press the (Power Icon) button to cycle through clock display brightness levels: Off, 10%, 50%, 100%.
- Time Format:** The device supports both 12-hour and 24-hour time formats. This can typically be adjusted via the app or during initial time setting.



Visual representation of the clock display at different brightness levels: Off, 10%, 50%, and 100%.




Examples of the clock display in both 12-hour (AM/PM) and 24-hour formats.

6. Bluetooth Speaker Function

- **Entering Bluetooth Mode:** Long press the **► ||** button for more than 2 seconds. The device will indicate it's ready for pairing (e.g., a sound prompt or flashing light).
- **Pairing:** On your smartphone or other Bluetooth-enabled device, search for "Augnner B005" (or similar name) in the Bluetooth settings and select it to pair.
- **Playback:** Once paired, you can play audio from your connected device through the Augnner Sound Machine.

7. Memory Function

The device is equipped with a memory function that remembers your last settings for volume, brightness, tracks, alarm, and timers, even after being powered off. This ensures your preferred settings are retained for convenience.



An icon representing the memory function, indicating the device remembers your last settings.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.

- **Storage:** Store the device in a cool, dry place when not in use for extended periods.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in constant use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low battery or no charge.	Connect the device to a power source using the USB Type-C cable and allow it to charge for at least 30 minutes before attempting to power on again.
No sound or low volume.	Volume is too low; device is paused; incorrect sound selected.	Increase volume using the + button. Short press ▶ to ensure it's not paused. Cycle through sounds using + / - long press.
Bluetooth connection issues.	Device not in pairing mode; Bluetooth off on phone; interference.	Long press ▶ to enter Bluetooth pairing mode. Ensure Bluetooth is enabled on your phone. Move closer to the device and away from other wireless devices.
Alarm does not sound.	Alarm is off; volume is too low; incorrect time set.	Short press to ensure alarm is enabled. Check alarm volume. Verify alarm time is correctly set.
Clock display is off or too dim.	Brightness set to off or lowest level.	Short press the (Power Icon) button to cycle through brightness levels.
App cannot connect to device.	Bluetooth not enabled; app not updated; device not powered on.	Ensure device is powered on and Bluetooth is enabled on your phone. Restart the app. Try restarting the device.

SPECIFICATIONS

Feature	Detail
Model Number	B005
Brand	Augnner
Dimensions	3.15 x 3.15 x 1.85 inches (approx.)
Color	Yellowwhite
Material	Plastic
Power Source	Battery Powered (800 mAh built-in battery)
Charging Port	USB Type-C
Bluetooth Version	5.3
Sound Library	32 Non-Looping Soothing Sounds

Feature	Detail
Night Light	8 Light Modes + RGB Breathing, 3000 Adjustable Color Temperatures

Easy to Carry A Must-Have for Travel



The compact dimensions of the Augnner Sound Machine, highlighting its portability.

SAFETY INFORMATION

Please read and adhere to the following safety guidelines:

- Do not use the device near water or in excessively humid environments.
- To prevent hearing damage, avoid using the device at high volumes for prolonged periods.
- This product is not a toy. Keep it out of reach of children when not in use to prevent accidental damage or injury.
- Do not attempt to disassemble, repair, or modify the device yourself. Refer all servicing to qualified personnel.
- Use only the provided or a certified USB Type-C cable for charging.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

WARRANTY AND SUPPORT

Augnner products are manufactured with high-quality standards. For any questions, technical support, or warranty claims, please contact Augnner customer service through the retailer where the product was purchased or visit the official Augnner website for contact information.

Please retain your proof of purchase for warranty purposes.

© 2025 Augnner. All rights reserved.