realme Realme 14x

realme 14x 5G Smartphone User Manual

Model: Realme 14x | Brand: realme

Introduction

Welcome to the user manual for your new realme 14x 5G Smartphone. This guide provides comprehensive instructions on setting up, operating, maintaining, and troubleshooting your device. Please read this manual carefully to ensure optimal performance and longevity of your smartphone.
The realme 14x is a powerful 5G smartphone featuring a 2.2 GHz Octa-core processor, 8GB of RAM, and 256GB of internal storage, expandable via microSDXC. It runs on Android 15 with Realme UI 6.0 and is equipped with a 5000mAh non-removable battery.

What's in the Box

Upon unboxing your realme 14x, please verify that all the following items are included:

- realme 14x 5G Smartphone
- USB Cable
- SIM Ejector Tool (may be included, not explicitly listed but common)
- Quick Start Guide (may be included)
- Safety Information (may be included)



Image: The realme 14x 5G Smartphone in Carbon Black, shown with its included USB cable.

Device Overview

Familiarize yourself with the physical components and buttons of your realme 14x smartphone.


realme
14x
5G




Image: Front view of the realme 14x, showcasing the display and front camera.





Image: Back view of the realme 14x, highlighting the camera module and realme branding.





Image: Side view of the realme 14x, showing the power button and volume rocker.



Image: Top and bottom view of the realme 14x, displaying the USB-C port, speaker grille, and microphone.

Setup

Inserting SIM Cards and microSD Card

Your realme 14x supports dual SIM cards and a microSDXC card for expandable storage. Note that the microSDXC card uses a shared SIM slot.

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM cards into the designated slots (SIM1, SIM2) and the microSD card into its slot, ensuring the gold contacts face downwards.
4. Carefully push the tray back into the device until it is flush with the side.

Initial Power On and Setup Wizard

1. Press and hold the Power button (located on the side) until the realme logo appears.
2. Follow the on-screen instructions to complete the initial setup, including selecting your language, connecting to Wi-Fi, signing in to your Google account, and setting up security features.

Charging the Device

Before first use, it is recommended to fully charge your realme 14x. Use the provided USB cable to connect your device to a compatible power adapter (not included) or a computer's USB port.

- Connect the USB Type-C end of the cable to the charging port at the bottom of your phone.
- Connect the other end of the USB cable to a power adapter and plug it into a wall outlet, or to a computer's USB port.
- The charging indicator will appear on the screen.

Operating Your realme 14x

Basic Navigation

Your realme 14x features an intuitive touchscreen interface. Use the following gestures for navigation:

- **Tap:** Select an item or open an application.
- **Swipe:** Scroll through screens, menus, or web pages.
- **Pinch:** Zoom in or out on photos and web pages.
- **Long Press:** Access contextual menus or move icons.

Making Calls and Sending Messages

To make a call, open the *Phone* app, enter the number, and tap the call icon. To send a message, open the *Messages* app, start a new conversation, enter the recipient and your message, then tap send.

Connecting to Networks

- **Wi-Fi:** Go to *Settings > Network & internet > Wi-Fi*, turn Wi-Fi on, and select your desired network.
- **Bluetooth:** Go to *Settings > Connected devices > Bluetooth*, turn Bluetooth on, and pair with available devices.
- **Mobile Data:** Ensure your SIM card is active. Go to *Settings > Network & internet > Mobile network* and enable Mobile data.

Camera Usage

Open the *Camera* app from your home screen or app drawer. You can switch between photo and video modes, adjust settings, and use various features like portrait mode or night mode. Tap the shutter button to capture photos or start/stop video recording.

App Management

Download new applications from the Google Play Store. To uninstall an app, long-press its icon on the home screen or in the app drawer, then drag it to the "Uninstall" option, or go to *Settings > Apps > See all apps*, select the app, and tap "Uninstall".

Maintenance and Care

Proper care will extend the life of your realme 14x and ensure its optimal performance.

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive materials or harsh chemicals.
- **Water Resistance:** This device is not rated for water resistance. Avoid exposure to liquids.
- **Temperature:** Operate the device within recommended temperature ranges (typically 0°C to 35°C). Avoid extreme heat or cold.
- **Battery Care:** Avoid fully discharging the battery frequently. For long-term storage, charge the battery to about 50%.
- **Software Updates:** Keep your device's software updated to the latest version for security and performance improvements. Go to *Settings > About phone > Software update*

Troubleshooting

This section addresses common issues you might encounter with your realme 14x.

Problem	Possible Solution
Device won't turn on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds to force restart.
Apps crashing or freezing	Clear the app's cache (Settings > Apps > [App Name] > Storage & cache > Clear cache). Restart the device. Update the app.
Poor network signal	Check SIM card insertion. Toggle Airplane mode on/off. Restart the device. Verify network compatibility with your carrier.
Battery drains quickly	Reduce screen brightness. Close background apps. Disable unnecessary features like GPS or Bluetooth when not in use.
Cannot connect to Wi-Fi	Ensure Wi-Fi is enabled. Restart your router. Forget the network and reconnect.

Technical Specifications

Below are the key technical specifications for the realme 14x 5G Smartphone:

Feature	Specification
Model Name	Realme 14x

Feature	Specification
Operating System	Android 15, Realme UI 6.0
Processor	Mediatek Dimensity 6300 (6 nm), Octa-core (2x2.4 GHz Cortex-A76 & 6x2.0 GHz Cortex-A55)
Display	6.67 inches IPS LCD, 720 x 1604 pixels
RAM	8GB
Internal Storage	256GB (expandable via microSDXC, uses shared SIM slot)
Battery	5000mAh non-removable
Connectivity	5G, 4G LTE, Wi-Fi, Bluetooth
SIM Type	Dual-SIM (Nano-SIM)
Color	Carbon Black
Dimensions (Weight)	Approximately 0.5 Kilograms (1.1 pounds)

Warranty and Support

Warranty Information

Your realme 14x 5G Smartphone comes with a limited manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.
This warranty typically covers defects in materials and workmanship under normal use. It does not cover damage caused by accidents, misuse, unauthorized repairs, or normal wear and tear.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact realme customer support. Visit the official realme website for the most up-to-date contact information, including phone numbers, email support, and service center locations in your region.
You can also visit the realme Store on Amazon for additional product information and support resources.

© 2025 realme. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question