Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YITAHOME MAYIHdNyLS

YITAHOME 59-inch TV Stand with Electric Fireplace and Power Strips Instruction Manual

Model: MAYIHdNyLS | Brand: YITAHOME

Introduction

Thank you for choosing the YITAHOME 59-inch TV Stand with Electric Fireplace and Power Strips. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

General Safety:

- Always follow the assembly instructions provided with the product.
- Ensure all connections are secure before use.
- Do not overload the TV stand or shelves. Refer to specifications for weight limits.
- Keep small parts away from children during assembly.
- Place the TV stand on a level, stable surface to prevent tipping.

Electric Fireplace Safety:

- Do not block the air vents of the electric fireplace.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the fireplace.
- Always unplug the fireplace before cleaning or maintenance.
- Do not operate the fireplace with a damaged cord or plug.
- Supervise children and pets when the fireplace is in operation.

Power Strip Safety:

- Do not exceed the electrical rating of the power strip.
- Avoid running cords under rugs or in high-traffic areas.
- Ensure the power strip is properly grounded.

Package Contents

Your YITAHOME TV stand is shipped in two separate boxes, which may arrive on different days. Please ensure you have received all packages before beginning assembly.




Image: Illustration showing the product being delivered in two separate boxes, followed by an "in delivery" truck, and finally a person receiving the boxes. This indicates that the product ships in multiple packages.

Please refer to the included assembly manual for a detailed list of all parts and hardware.

Setup and Assembly Instructions

The YITAHOME TV stand is designed for straightforward assembly. We recommend assembling the unit with another person for ease and safety.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match each part to the corresponding number or letter in the included assembly manual.
3. **Follow Step-by-Step Guide:** Refer to the detailed, illustrated instructions provided in the separate assembly manual. Ensure each step is completed correctly before proceeding.
4. **Secure Connections:** Tighten all screws and fasteners firmly, but do not overtighten to avoid damaging the material.
5. **Install Fireplace:** The 23-inch electric fireplace unit is designed to fit into the central compartment. Follow the specific instructions for installing and connecting the fireplace. The fireplace can be removed and replaced with adjustable dividers for additional storage during warmer months.
6. **Positioning:** Once assembled, carefully move the TV stand to its desired location. Ensure it is on a stable, level surface.

For visual guidance, please refer to the assembly diagrams in your separate instruction booklet.

Operating Instructions

Electric Fireplace Operation

The electric fireplace provides adjustable flame effects and heating. It can be controlled via the touch panel on the unit or the included remote control.



Image: Close-up of the electric fireplace control panel and remote control, showing buttons for power, temperature, flame luminance, and timer settings.

- **Power On/Off:** Press the power button on the unit or remote to turn the fireplace on or off.
- **Temperature Control:** Use the temperature buttons to adjust the heat output. The fireplace features a temperature range of 62°F to 82°F.
- **Flame Luminance:** Adjust the brightness of the flame effect using the luminance button. There are 3 levels of brightness.
- **Timer Function:** Set the operational timer for 0.5 to 6 hours.

For optimal heating, ensure the fireplace vents are not obstructed.

Integrated Power Strips

The TV stand includes integrated power strips for convenient charging and powering of your devices.



Image: Close-up of the integrated power strip on the TV stand, showing two AC outlets, one USB-A port, and one USB-C port, with a phone charging.

- The power strip features 2 AC outlets (120V/12A), 1 USB-A port, and 1 Type-C port.
- Connect your electronic devices to the appropriate ports for power or charging.
- Ensure the total power draw of connected devices does not exceed the power strip's rating.

Maintenance

Regular maintenance will help prolong the life and appearance of your TV stand.

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could

damage the finish.

- **Cleaning the Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Use a soft, dry cloth to wipe the exterior. Do not spray liquids directly onto the unit.
- **Dusting:** Regularly dust all surfaces, including inside cabinets and drawers, to prevent buildup.
- **Hardware Check:** Periodically check all assembly hardware (screws, bolts) and tighten if necessary to maintain stability.

Troubleshooting

If you encounter issues with your YITAHOME TV stand or electric fireplace, refer to the following common solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	Not plugged in; power switch off; circuit breaker tripped.	Ensure the fireplace is securely plugged into a working outlet. Check the main power switch on the unit. Reset the circuit breaker if necessary.
No heat from fireplace.	Heat function not activated; thermostat set too low; air vents blocked.	Activate the heat function using the control panel or remote. Increase the thermostat setting. Ensure air vents are clear of obstructions.
Flame effect not working.	Flame effect function not activated.	Press the flame luminance button to activate the flame effect.
Power strip not providing power.	Not plugged in; circuit breaker tripped; device not compatible.	Ensure the TV stand's main power cord is plugged into a working outlet. Check the circuit breaker. Verify device compatibility and functionality.
Stand feels wobbly after assembly.	Loose hardware; uneven floor.	Re-check and tighten all assembly hardware. Move the stand to a level surface or use shims to stabilize.

If problems persist, please contact YITAHOME customer support.

Specifications

Detailed specifications for the YITAHOME 59-inch TV Stand with Electric Fireplace.




Image: Technical drawing showing the overall dimensions of the TV stand (59" W x 25.6" H x 15.5" D), the electric fireplace (24.2" W x 17.5" H x 5.1" D), and internal drawer dimensions.

- **Model:** MAYIHdNyLS
- **Brand:** YITAHOME
- **Color:** Black
- **Material:** Engineered Wood
- **Overall Dimensions (W x H x D):** 59 inches x 25.6 inches x 15.5 inches (150cm x 65cm x 39.5cm)
- **Weight:** Approximately 96.3 pounds (43.7 kg)
- **TV Size Compatibility:** Up to 65 inches
- **Electric Fireplace:**
  - Size: 23 inches
  - Heating Area: Up to 160 sq ft
  - Temperature Range: 62°F - 82°F
  - Flame Brightness: 3 levels
  - Timer: 0.5 - 6 hours
  - Power: 1400W PTC Ceramic Heater

- **Integrated Power Strip:**
  - AC Outlets: 2 (120V/12A)
  - USB Ports: 1 USB-A, 1 Type-C (5V/2A total)
  - Power Cord Length: 6.5 feet (200cm)
- **Storage:** 2 drawers, 2 open storage compartments, 2 barn door cabinets with adjustable shelves.

Warranty and Support

YITAHOME products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or visit the official YITAHOME website.
If you require assistance with assembly, parts, or have any questions regarding your product, please contact YITAHOME customer support:

- **Website:** Visit the YITAHOME Store on Amazon (for general inquiries and product information)
- Refer to your purchase invoice or packaging for direct customer service contact details.

© 2023 YITAHOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZD139K3

More documents and user manuals: **https://manuals.plus/**