

Aroepurt CPT19

Instruction Manual for Aroepurt Phone Case Cover

Brand: Aroepurt | Model: CPT19

1. INTRODUCTION

Thank you for choosing the Aroepurt Phone Case Cover with Tempered Glass Screen Protector. This manual provides detailed instructions for the proper installation, use, and maintenance of your new phone accessory. Designed for the Foxx FOXXD A67L, this product offers robust protection and enhanced functionality for your device.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Phone Case (CPT19)
- 1 x Tempered Glass Screen Protector

3. PRODUCT FEATURES

The Aroepurt Phone Case Cover is engineered with several features to enhance your phone's usability and protection:

3.1. Magnetic Closure

The case features a built-in magnetic closure that securely keeps the front flap closed, protecting your screen and contents from accidental opening. This ensures your valuables remain safely enclosed.



The magnetic closure keeps the case securely shut.

3.2. Kickstand Function

The case is designed to fold into a convenient kickstand, allowing you to prop up your phone for hands-free viewing. This is ideal for watching videos, reading, or video calls.



The case easily converts into a kickstand for comfortable viewing.

3.3. Card Storage

Equipped with dedicated card slots, the case allows you to carry essential cards such as IDs or credit cards, combining your wallet and phone protection into one compact unit.



Convenient card slots for carrying essential cards.


3.4. Comprehensive Protection

Crafted from high-quality PU leather and featuring a silicone ring, this case provides robust protection against drops, scratches, and daily wear. The fine stitch edge sealing adds to its durability and aesthetic appeal.

3.5. Tempered Glass Screen Protector

The included tempered glass screen protector offers superior defense for your phone's display:

- **9H High Hardness:** Provides excellent resistance against scratches from sharp objects.
- **Perfect Adhesion:** Ensures a smooth, bubble-free application and strong bond to the screen.
- **Shatterproof:** Designed to resist shattering into dangerous shards upon impact.
- **Case Friendly:** Engineered to fit perfectly with the phone case without lifting or peeling.
- **99.9% Super Transparency:** Maintains the original clarity and brightness of your phone's display.
- **Anti-fingerprint:** Features an oleophobic coating to reduce smudges and fingerprints.



Key features of the tempered glass screen protector.

3.6. Scratch Proof Screen

The tempered glass screen protector is highly resistant to scratches, effectively protecting your screen from sharp objects and abrasions.



Scratch Proof

Scratch proof screen effectively avoids sharp objects scratching or abrasion



The screen protector offers strong scratch resistance.

4. SETUP AND INSTALLATION

4.1. Installing the Phone Case

1. Ensure your phone is clean and free of dust or debris.
2. Align your phone with the silicone inner shell of the case.
3. Gently press your phone into the case, starting from one corner and working your way around until it is fully seated. Ensure all buttons and ports align correctly with the case cutouts.

4.2. Installing the Tempered Glass Screen Protector

For best results, install the screen protector in a clean, dust-free environment.

1. **Clean the Screen:** Use the provided alcohol wipe to thoroughly clean your phone's screen. Follow with the microfiber cloth to dry and remove any lint or smudges. Ensure the screen is perfectly clean and dry.

2. **Remove Dust:** Use the dust-absorber sticker to pick up any remaining dust particles from the screen.
3. **Peel Off Protective Film:** Carefully peel off the protective film from the adhesive side of the tempered glass (usually marked with a tab). Avoid touching the adhesive surface.
4. **Align the Protector:** Carefully align the screen protector with your phone's screen, paying attention to the cutouts for the speaker, camera, and home button (if applicable).
5. **Apply:** Once aligned, gently lower the screen protector onto the screen. It will naturally adhere.
6. **Remove Bubbles:** If there are any small bubbles, gently push them towards the edges of the screen using the microfiber cloth or a soft card. Minor bubbles may disappear on their own within 24-48 hours.

5. OPERATING INSTRUCTIONS

5.1. Using the Magnetic Closure

To close the case, simply fold the front flap over the screen. The magnetic closure will automatically engage, keeping the case securely shut. To open, gently pull the flap away from the phone.

5.2. Utilizing the Kickstand

To use the kickstand feature, fold the back of the case along the designated crease until it forms a stable triangle. Place your phone horizontally in the groove to achieve a comfortable viewing angle.

5.3. Accessing Card Slots

Insert your cards into the designated slots on the inner flap of the case. Ensure cards are fully inserted to prevent them from falling out when the case is open.

6. MAINTENANCE

Proper care will extend the life and appearance of your phone case and screen protector:

- **Cleaning the Case:** Wipe the PU leather surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive water, as these can damage the material.
- **Cleaning the Screen Protector:** Use a microfiber cloth to gently wipe the screen protector to remove fingerprints and smudges. For stubborn marks, a small amount of screen cleaner can be applied to the cloth (not directly to the screen).
- **Avoid Extreme Conditions:** Do not expose the case or screen protector to extreme temperatures, direct sunlight for prolonged periods, or sharp objects that could cause damage.

7. TROUBLESHOOTING

7.1. Case Does Not Fit

Ensure that you have purchased the correct model case for your Foxx FOXXD A67L phone. This case is specifically

designed for that model. Double-check your phone's model number.

7.2. Bubbles Under Screen Protector

Small bubbles are common immediately after installation. Most will disappear within 24-48 hours. For larger bubbles, gently lift the nearest edge of the protector and re-apply, pushing the bubble out with a microfiber cloth. Ensure no dust particles are trapped underneath.

7.3. Magnetic Closure Not Holding

Check if there are too many cards or bulky items in the card slots that might prevent the magnetic flap from closing properly. Remove excess items if necessary.

8. SPECIFICATIONS

Attribute	Detail
Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	2.46 ounces
Form Factor	Hybrid Case
Color	CPT19
Special Features	Card insertion, Thickened anti-drop + Card Function, Stash the change
What's in the Box	1*Phone Case, 1*Tempered Glass Screen Protector

9. WARRANTY AND SUPPORT

This product is covered by the standard return and refund policies of the retailer from which it was purchased. For any questions, concerns, or support needs regarding your Aroepurt Phone Case Cover or Tempered Glass Screen Protector, please contact the seller directly through the platform where you made your purchase. Please have your order details ready for faster assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DZDFQT34>

More documents and user manuals: **<https://manuals.plus/>**