

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Conair](#) /

› [Conair Compact Garment Steamer for Clothes, Small Size Tackles Big Wrinkles with Fast Heat Up User Manual](#)

## Conair GS81

# Conair Compact Garment Steamer User Manual

Model: GS81

Brand: Conair

## 1. INTRODUCTION

---

Thank you for choosing the Conair Compact Garment Steamer. This manual provides important information for the safe and efficient operation of your new appliance. Please read all instructions carefully before use and retain for future reference.

The Conair Compact Garment Steamer is designed to quickly and effectively remove wrinkles from various fabrics, making it ideal for both daily use and travel. Its compact size and fast heat-up time offer convenience and efficiency in garment care.



Image 1.1: The Conair Compact Garment Steamer shown with its included bristle brush and delicates bonnet attachments.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

**WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances.**

- Read all instructions before using the steamer.
- Use the appliance only for its intended household use.
- To protect against electric shock, do not immerse the steamer in water or other liquids.
- Always turn off and unplug the steamer from the electrical outlet before filling or emptying water, and when not in use.
- Do not operate the steamer with a damaged cord or plug, or if the appliance has been dropped or damaged.
- Keep the cord away from heated surfaces. Do not pull or carry by cord.
- Do not direct steam at people, animals, or directly at electrical outlets. Steam is hot and can cause burns.

- Use only distilled or demineralized water in the steamer to prevent mineral buildup.
- Our products comply with North American safety standards, verified by independent labs such as ETL.

### 3. PACKAGE CONTENTS

---

Verify that all items are present in the package:

- Conair Compact Garment Steamer Unit
- Delicates Bonnet Attachment
- Bristle Brush Attachment



Image 3.1: The steamer unit with its two included attachments: a bristle brush for heavier fabrics and a delicates bonnet for gentle fabrics.

### 4. SETUP

---

1. **Fill the Water Tank:** Ensure the steamer is unplugged. Remove the water tank from the base of the steamer. Open

the fill cap and fill the tank with distilled or demineralized water. Do not overfill. Close the cap securely and reinsert the tank into the steamer until it clicks into place. The large removable water tank allows for fewer refills during use.

2. **Attach Accessories (Optional):** If desired, attach either the delicates bonnet or the bristle brush to the steamer head. Align the attachment with the steamer head and press firmly until it is securely in place.
3. **Plug In:** Plug the steamer into a standard electrical outlet. The indicator light will illuminate, signaling that the steamer is heating up.
4. **Heat-Up Time:** The steamer heats up quickly, typically in just 30 seconds, and will be ready to produce steam.



## EXTENDED RUNTIME

UP TO 10 MINUTES OF STEAM



## MORE STEAM FEWER REFILLS

LARGE REMOVABLE WATER TANK




Image 4.1: The steamer highlighting its large removable water tank, designed for extended runtime and fewer refills.

## 5. OPERATING INSTRUCTIONS

1. **Prepare Garment:** Hang the garment on a hanger. For best results, hold the fabric taut with one hand while steaming with the other.
2. **Begin Steaming:** Once the steamer is heated (indicator light may change or stop blinking), press the steam trigger

to release steam. Move the steamer head slowly over the fabric, allowing the steam to penetrate and relax the fibers. The steamer provides up to 10 minutes of continuous steam.

### 3. Using Attachments:

- **Bristle Brush:** Use this attachment for heavier fabrics like coats or upholstery to help open the weave for deeper steam penetration and to remove lint.
- **Delicates Bonnet:** This attachment provides a protective layer for delicate fabrics, preventing water spots and ensuring gentle steaming.

4. **Maneuvering:** The long swivel cord allows for easy maneuvering around garments and furniture, providing flexibility and reach.

5. **Fabric Compatibility:** The steamer is safe for all fabric types, including cotton, wool, silk, and synthetics. Always test on an inconspicuous area first if unsure.

6. **Finish Steaming:** When finished, release the steam trigger and unplug the steamer from the outlet. Allow the unit to cool completely before storing.



**FASTER, EASIER  
AND LIGHTER  
THAN AN IRON**

SMALL SIZE TACKLES  
BIG WRINKLES



**EASY  
MANEUVERING**

WITH LONG SWIVEL CORD



Image 5.1: Demonstrates the ease of use and maneuverability of the steamer on a pair of pants, highlighting its lighter design compared to

an iron.




Image 5.2: A visual comparison showing a wrinkled shirt before and after being treated with the steamer, illustrating fast and effective wrinkle removal.



Image 5.3: The steamer head positioned over different fabric textures, indicating its suitability for cotton, wool, and other materials.

## 6. MAINTENANCE AND CARE

---

1. **Empty Water Tank:** After each use, ensure the steamer is unplugged and cool. Remove the water tank and empty any remaining water. This prevents mineral buildup and prolongs the life of the appliance.
2. **Cleaning:** Wipe the exterior of the steamer with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
3. **Storage:** Store the steamer in a cool, dry place. Ensure the cord is not tightly wrapped around the unit to prevent damage. The compact design makes it easy to store or pack for travel.



Image 6.1: The compact steamer shown with its dimensions (4.375" x 9") and packed in a suitcase, illustrating its travel-friendly design.

## 7. TROUBLESHOOTING

If you encounter issues with your Conair Compact Garment Steamer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No steam produced	Steamer not plugged in; water tank empty; not heated sufficiently.	Ensure steamer is securely plugged in. Fill water tank. Allow 30 seconds for heat-up.
Water leaking from steamer head	Overfilled water tank; steamer not fully heated; mineral buildup.	Do not overfill the tank. Wait for the steamer to fully heat. Use distilled water to prevent buildup.
Steamer not removing wrinkles effectively	Fabric not held taut; steaming too quickly; incorrect attachment used.	Hold fabric taut. Move steamer head slowly. Use bristle brush for heavier fabrics.

## 8. SPECIFICATIONS

---

Feature	Detail
Brand	Conair
Model Number	GS81
Color	Black
Product Dimensions	4.5"L x 4"W x 10.3"H
Item Weight	1.3 Pounds
Style	Compact
Wattage	1200 watts
Heat Time	30 seconds
Product Benefits	Fabric Refreshening, Remove Wrinkle
Included Components	Bristle Brush, Delicates Bonnet
UPC	074108508720

## 9. WARRANTY AND SUPPORT

---

Conair is committed to delivering quality and innovation. Our products are designed and tested to meet high standards for quality and durability. For product support or inquiries, please refer to the official Conair website or contact customer service.

# Quality & Performance

Get Wrinkle-Free Fast with a Brand You Can Trust!

**The #1 Selling Garment Care Brand\***



## SAFETY

Our products comply with North American safety standards, verified by independent labs such as ETL.



## PERFORMANCE

We performance test our products to ensure that they meet our customers' high standards for quality and durability.



## TRUST

The Conair brand has delivered quality and innovation to U.S. consumers since 1959 - it's no wonder we're a brand you can trust!

**CONAIR**

\*Source: Circana, Retail Tracking Service, U.S. dollar sales, 52 weeks ending February 1, 2025.

Image 9.1: An infographic detailing Conair's commitment to safety, performance, and trust, highlighting 65 years of delivering quality and innovation.