



Manuals.plus /

› **Ninja** /

› Ninja Blast Portable Blender CL155AGY User Manual

Ninja CL155AGY

Ninja Blast Portable Blender CL155AGY User Manual

Model: CL155AGY | Brand: Ninja

1. INTRODUCTION

The Ninja Blast Portable Blender CL155AGY is a cordless, personal blending solution designed for convenience and portability. It features an 18-ounce vessel, a powerful BlastBlade Assembly for processing frozen ingredients, and a USB-C rechargeable base. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your blender.



Image 1.1: The Ninja Blast Portable Blender with an additional blending vessel, showcasing its compact design.

2. IMPORTANT SAFEGUARDS

Please read all instructions before using your Ninja Blast Portable Blender to ensure safe operation and to reduce the risk of injury or damage.

- Always keep the blender and its components out of reach of children.
- Do not blend hot liquids. Hot liquids can create pressure, leading to a risk of burns or injury.
- Ensure the vessel is securely attached to the motor base before blending.
- Do not immerse the motor base in water or other liquids. Clean with a damp cloth only.
- Use only the provided USB-C cable for charging.
- Avoid contact with moving parts.
- Do not operate the blender if any part is damaged. Contact customer service for assistance.
- All food-contact parts are BPA-free.

3. WHAT'S INCLUDED

Your Ninja Blast Portable Blender package includes the following components:

- 7.4V USB-C rechargeable motor base
- Blade Cover (1)

- 18 oz. Blending Vessels (2)
- Vessel Cap (1)
- Easy-Open Sip Lids with carrying handle (2)
- USB-C Cable (1)
- Quick Start Guide (1)

4. ASSEMBLY AND SETUP

4.1 Initial Charging

Before first use, fully charge the motor base. Connect the provided USB-C cable to the charging port on the motor base and plug the other end into a compatible USB power adapter (not included). The indicator lights will show charging progress and a full charge.



Image 4.1: Connecting the USB-C charging cable to the blender's motor base.

4.2 Assembling the Blender

1. Place the blade cover onto the blade assembly.
2. Add your desired ingredients into the 18 oz. blending vessel.
3. Screw the motor base onto the blending vessel until securely tightened.

4. Attach the easy-open sip lid to the top of the vessel.

5. OPERATING INSTRUCTIONS

5.1 Loading Ingredients

For optimal blending results, load ingredients in the following order:

1. Liquids (e.g., water, milk, juice)
2. Soft ingredients (e.g., yogurt, protein powder, leafy greens)
3. Hard ingredients (e.g., fresh fruits, vegetables)
4. Frozen ingredients (e.g., frozen fruits, ice cubes)



18-oz. vessel

Extra room for all your favorite ingredients.

Image 5.1: The 18-ounce vessel filled with a variety of ingredients, ready for blending.

5.2 Blending

The Ninja Blast features separate power and blend buttons to prevent unintentional blending.

1. Ensure the motor base is securely attached to the vessel.
2. Press the **Power** button to turn on the blender. The indicator lights will illuminate.
3. Press the **Start/Stop** button to begin blending. The blender will run for a preset cycle.

4. For optimal results with frozen ingredients, you may gently shake the blender during the blending cycle to ensure all contents come into contact with the blade.
5. Press the **Start/Stop** button again to stop blending at any time.
6. Once blending is complete, press the **Power** button to turn off the blender.



Easy to use

With separate power and blend buttons, there's no unintended blending.

Image 5.2: A hand pressing the 'Start/Stop' button to initiate blending.

5.3 Portability Features

The Ninja Blast is designed for on-the-go use:

- **Cup Holder Friendly:** Its design allows it to fit conveniently in most car cup holders.
- **Leak-Proof Lid:** The easy-open sip lid is designed to prevent spills, making it suitable for transport in bags.
- **Hinged Carry Handle:** A comfortable handle is integrated into the lid for easy carrying.



Cup holder friendly

Conveniently fits in car cup holders making travel and portability a breeze.

Image 5.3: The blender fits securely in a car cup holder, highlighting its travel-friendly design.



Leak-proof lid

From your office bag to your gym bag, our leak-proof lid prevents spills in storage or on the go.

Image 5.4: The leak-proof lid allows for secure transport in a backpack.



Hyper portable

Bring your drink on the go with a comfortable, hinged carry strap.

Image 5.5: The blender's hinged carry handle makes it easy to transport.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your Ninja Blast Portable Blender.

6.1 Cleaning

- **Dishwasher Safe Parts:** The blending vessel and sip lid are BPA-free and top-rack dishwasher safe.
- **Self-Cleaning Cycle:** For quick cleaning, fill the vessel with water and a drop of dish soap. Secure the motor base and lid, then run a 30-second blend cycle. Rinse thoroughly.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse in water.

6.2 Storage

Store the blender in a clean, dry place. Ensure all components are dry before storing.

7. TROUBLESHOOTING

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not start.	Battery is low or depleted. Vessel not properly assembled.	Charge the motor base. Ensure the vessel is securely twisted onto the motor base.
Ingredients are not blending smoothly or are stuck.	Too many ingredients. Insufficient liquid. Ingredients loaded incorrectly.	Reduce ingredient quantity. Add more liquid. Follow the recommended loading order (liquids first). Gently shake the blender during operation to dislodge ingredients.
Blender stops unexpectedly.	Overload protection activated. Battery depleted.	Remove some ingredients and restart. Charge the motor base.

8. SPECIFICATIONS

- **Model Number:** CL155AGY
- **Brand:** Ninja
- **Vessel Capacity:** 18 oz. (532 ml)
- **Product Dimensions:** 7.09"D x 3.54"W x 10.71"H
- **Item Weight:** 3.39 pounds
- **Power Source:** Integrated rechargeable battery (7.4V)
- **Controls:** Push Button (Separate Power & Blend)
- **Special Features:** Compact, Cordless, Portable, Leakproof Lid, USB-C Charging, BPA Free
- **Material:** BPA Free plastic vessel, Stainless Steel BlastBlade Assembly

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the warranty card included with your product or visit the official Ninja website. Contact information for customer service can typically be found on the manufacturer's website or in the Quick Start Guide.