

[Manuals.plus](#) /

› [ALLIMITY](#) /

› ALLIMITY RM-C3363 Replacement Voice Remote Control User Manual for JVC LED Smart TV LT-32KB208

ALLIMITY RM-C3363

ALLIMITY RM-C3363 Replacement Voice Remote Control User Manual

For JVC LED Smart TV Models: LT-32KB208

1. INTRODUCTION

This manual provides instructions for the ALLIMITY RM-C3363 Replacement Voice Remote Control. This remote is designed to be compatible with specific JVC LED Smart TV models, including LT-32KB208. Please read this manual carefully to ensure proper setup and operation of your new remote control.

2. PRODUCT OVERVIEW

The ALLIMITY RM-C3363 is a replacement voice-enabled remote control. It features dedicated buttons for popular streaming services and a voice search function for convenient control of your compatible JVC Smart TV.



Image 2.1: Front view of the ALLIMITY RM-C3363 Replacement Voice Remote Control, showing all buttons including power, input, Netflix, YouTube, navigation, volume, channel, and number pad. A microphone icon is visible, indicating voice control capability.

Key Features:

- Voice Search Functionality
- Dedicated Quick Access Buttons (e.g., Netflix, YouTube)
- Standard TV Control Functions (Power, Volume, Channel, Navigation)
- Durable Plastic Construction

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside

the compartment.

4. Replace the battery cover by sliding it back into place until it clicks securely.





Image 3.1: Back view of the remote control with the battery compartment open, illustrating the correct orientation for AAA battery insertion.

3.2 Pairing with Your TV

This voice remote control requires pairing with your JVC LED Smart TV before its voice functions can be utilized. Refer to your JVC Smart TV's user manual for specific instructions on how to pair a new Bluetooth or voice-enabled remote control. Generally, the process involves:

1. Ensure your TV is powered on.
2. Navigate to the TV's settings menu (often found under 'Settings' or 'System').
3. Look for options related to 'Remotes & Accessories', 'Bluetooth', or 'Add Device'.
4. Follow the on-screen prompts to put your TV into pairing mode.
5. On the RM-C3363 remote, there may be a specific button combination to initiate pairing (e.g., holding down 'OK' and 'Back' simultaneously, or a dedicated pairing button if present). Consult your TV's manual for the exact remote pairing procedure.
6. Once paired, a confirmation message should appear on your TV screen.

Note: If your TV does not support Bluetooth pairing for remotes, the voice function may not be available, but basic infrared (IR) functions should still operate.

4. OPERATING INSTRUCTIONS

To ensure optimal performance, aim the remote control directly at the infrared (IR) sensor on your JVC Smart TV. Avoid any obstacles between the remote and the TV sensor.

4.1 Basic Functions

- **Power Button (U):** Turns the TV on or off.
- **Input Button:** Cycles through available input sources (HDMI, AV, etc.).
- **Netflix / YouTube Buttons:** Direct access to Netflix and YouTube applications.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and select items.
- **Volume Up/Down (VOL +/-):** Adjusts the TV's volume.
- **Channel Up/Down (CH +/-):** Changes TV channels.
- **Number Pad (0-9):** Directly enters channel numbers.
- **Back Button (↶):** Returns to the previous screen or menu.
- **Home Button (△):** Accesses the TV's home screen or smart hub.
- **Menu Button (≡):** Opens the TV's main menu.
- **Mute Button (⏸):** Mutes or unmutes the TV audio.

4.2 Voice Search Function

After successful pairing, press the Voice Search button (microphone icon) on the remote. Speak clearly into the

remote control's microphone. Your TV will process the voice command for searching content, launching apps, or controlling certain TV functions, depending on your TV's capabilities.

5. MAINTENANCE

5.1 Cleaning the Remote

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or immerse the remote in liquid.

5.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA 1.5V batteries. Do not mix old and new batteries, or different types of batteries.

6. TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Ensure there are no obstacles between the remote and the TV's IR sensor.
 - Point the remote directly at the TV's IR sensor.
- **Voice control not working:**
 - Ensure the remote is successfully paired with your TV (refer to Section 3.2).
 - Check your TV's settings to ensure voice control is enabled.
 - Speak clearly and at a normal volume into the remote's microphone.
 - Verify that your TV model supports voice control with this type of remote.
- **Specific buttons not working:**
 - Some advanced functions or app-specific buttons may require your TV to be updated or have specific settings enabled.
 - Ensure the remote is compatible with your exact TV model.

7. SPECIFICATIONS

Model Number	RM-C3363 (Also known as AMT-RM-C3363-NY-SGP-BT)
Brand	ALLIMITY
Compatible TV Models	JVC LED Smart TV LT-32KB208
Product Material	Plastic
Special Feature	Voice Search
Color	Black

Product Dimensions	5 x 1 x 0.5 inches (approx.)
Item Weight	1 ounce (approx.)
Power Source	2 x AAA 1.5V Batteries (not included)

8. CUSTOMER SUPPORT

If you encounter any issues with your ALLIMITY RM-C3363 Replacement Voice Remote Control or have questions regarding its compatibility or functionality, please contact the seller directly for assistance. Providing your TV's exact model number will help expedite support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0DZFJNPZD>

More documents and user manuals: <https://manuals.plus/>