

SVAKOM Iker Neo

SVAKOM Iker Neo Prostate Vibrator Instruction Manual

Model: Iker Neo (54065100000)

1. PRODUCT OVERVIEW

The SVAKOM Iker Neo is a rechargeable silicone vibrator designed for prostate and perineal massage. It features powerful vibration and pulsation, a flexible neck for optimal positioning, and colored lights to indicate vibration modes. The device is app-compatible, allowing for customized control and interactive experiences.

Key Features:

- Vibrating shaft with independent pulsation for prostate stimulation.
- Independent external stimulator for vibrating perineal massage.
- SVAKOM App compatibility for customization and long-distance play.
- Syncs with interactive adult videos or cam sites.
- Waterproof design for easy cleaning and versatile use.
- USB-recharging with battery indicator lights.
- Memory function and travel lock for convenience.



Figure 1: SVAKOM Iker Neo Prostate Vibrator, Navy Blue/Gold. This image shows the overall design and color of the product.

2. SETUP AND CHARGING

Initial Charge:

Before first use, fully charge the device. The Iker Neo uses a magnetic USB charging cable. Connect the magnetic end to the charging points on the device and the USB end to a compatible power source (e.g., computer, USB wall adapter).

- **Charging Time:** Approximately 1.5 hours.
- **Battery Life:** Approximately 1.5 hours of continuous use.




Figure 2: Rear packaging of the SVAKOM Iker Neo, detailing product specifications including battery type, charging time, and battery life.



Figure 3: The SVAKOM Iker Neo connected to its magnetic USB charging cable, illustrating the charging process.

3. OPERATING INSTRUCTIONS

Power On/Off:

Press and hold the power button (usually indicated by a universal power symbol) for 2-3 seconds to turn the device on or off. The device will typically give a short vibration or light indication when powered on.

Modes and Intensity:

The Iker Neo features multiple vibration and pulsation modes. Short press the mode button (often indicated by a wave or vibration symbol) to cycle through the available patterns and intensities. The device has 5 vibration modes and 5 pulsation modes, offering a total of 10 intensity levels.

App Control:

Enhance your experience by connecting the Iker Neo to the SVAKOM App. The app allows for custom pattern creation, long-distance control, and synchronization with interactive adult videos or cam sites.

- Download the SVAKOM App from your device's app store.
- Ensure Bluetooth is enabled on your smartphone.
- Open the SVAKOM App and follow the on-screen instructions to pair your Iker Neo.
- For more interactive experiences, consider downloading the FeelConnect App.





Figure 4: Front packaging of the Svakom Iker Neo, emphasizing its app compatibility feature.



Figure 5: Open box view of the Svakom Iker Neo, showing instructions for app download and various usage methods.

Download the Svakom App: svakom.com/manuals

Download the FeelConnect App (Google Play): [Google Play Store](https://play.google.com/store/apps/details?id=com.svakom.feelconnect)

Download the FeelConnect App (Apple App Store): [Apple App Store](https://apps.apple.com/us/app/feelconnect/id1444444444)

Remote Control:

The Iker Neo may come with a remote control for convenient operation. Use the remote to power on/off and cycle through modes without directly interacting with the device buttons.

Video 1: This video demonstrates the features and operation of a similar prostate massager, including its various modes and how to use the controls. It highlights the product's flexibility and ease of use.

4. MAINTENANCE

Cleaning:

The Iker Neo is fully waterproof, making it easy to clean. After each use, wash the product with warm water

and mild soap. Rinse thoroughly and allow it to air dry completely before storing.

Important: Always use a water-based lubricant with silicone products. Oil-based or silicone-based lubricants can degrade the silicone material over time.

Storage:

Store the product in a clean, dry, and cool place, away from direct sunlight and extreme temperatures. Keep out of reach of children or pets.

5. TROUBLESHOOTING

Device Not Turning On:

- Ensure the device is fully charged.
- Press and hold the power button for 2-3 seconds. A quick press may not activate it.

App Connectivity Issues:

- Ensure Bluetooth is enabled on your smartphone.
- Make sure the device is powered on and within range of your smartphone.
- Try restarting both the device and the app.

Reduced Performance:

- Recharge the device fully.
- Ensure the device is clean and free from debris.

6. SPECIFICATIONS

| Attribute | Detail |
|------------------------|------------------------------|
| Product Name | Iker Neo |
| Brand | SVAKOM |
| Model Number | 54065100000 |
| Material | Liquid Silicone, ABS Plastic |
| Size | 101 x 104 x 35mm |
| Insertable Size | 100 x 30mm |
| Weight | 135g |
| Battery Capacity | 550mAh |
| Battery Type | Polymer Lithium Battery |
| Rated Charging Voltage | 5.0V |
| Charging Time | 1.5 hours |

| | |
|------------------|------------------------------|
| Battery Life | 1.5 hours |
| Modes | 5 (Vibration), 5 (Pulsation) |
| Intensity Levels | 5 (Vibration), 5 (Pulsation) |
| Waterproof Level | Waterproof |
| Sound Level | <60dB |

7. WARRANTY AND SUPPORT

Legal Disclaimer:

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

Additional Information:

For more product information, refer to the user manual included inside the packaging or visit www.svakom.com.