

[Manuals.plus](#) /

› [COMHOMA](#) /

› COMHOMA Recliner Chair User Manual

COMHOMA H1148-GRAY-N

COMHOMA Recliner Chair Instruction Manual

Model: H1148-GRAY-N

1. PRODUCT OVERVIEW

The COMHOMA Recliner Chair is a versatile and comfortable seating solution designed for relaxation. It features a 360° swivel function, a rocking mechanism, and a manual reclining system with multiple adjustable angles. Constructed with a sturdy metal frame and upholstered in skin-friendly fabric with high-density sponge filling, this chair offers both durability and comfort. Convenient dual cup holders and a side storage pocket are integrated for enhanced usability.



Image: Front view of the COMHOMA Recliner Chair in grey, showcasing its plush design and integrated features.

2. SAFETY INFORMATION

- Ensure all components are securely assembled before use.
- Do not allow children to play on or around the recliner unsupervised.
- Avoid placing heavy objects on the footrest when extended, as this may cause damage or instability.
- Keep hands and feet clear of the reclining mechanism during operation to prevent injury.
- Do not stand on the chair or use it as a step stool.
- Maximum weight capacity for this recliner is 330 lbs (150 kg). Do not exceed this limit.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please

contact customer support.

- Recliner Backrest
- Recliner Seat Base with Armrests
- Swivel Base Mechanism
- Cup Holder Inserts (2)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly of the COMHOMA Recliner Chair is designed to be straightforward and does not require complex tools. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, soft surface to prevent scratches.
2. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding slots on the seat base. Slide the backrest down firmly until it clicks securely into place. Ensure both sides are fully engaged.
3. **Insert Cup Holders:** Place the plastic cup holder inserts into the designated circular openings on the armrests.
4. **Final Check:** Once assembled, gently rock and swivel the chair to ensure all connections are stable and the mechanisms move freely.

360° SWIVEL

Provide better relaxation experience



360° swivel



Solid metal frame



Good choice for your family

Image: The 360° swivel capability of the recliner, illustrating its rotational movement.

5. OPERATING INSTRUCTIONS

5.1. Reclining Function

To recline the chair, locate the pull tab on the side of the chair (typically on the right side). Pull the tab firmly to release the footrest and allow the backrest to recline. The chair offers three adjustable angles:

- **90°:** Upright position, ideal for reading or working.
- **120°:** Relaxed position, suitable for watching TV.
- **160°:** Fully reclined position, perfect for napping or deep relaxation.

To return to the upright position, gently push the footrest down with your legs until it locks into place. The backrest will simultaneously return to its upright position.



TWO CUP HOLDERS



COMFORTABLE SEAT



PADDED BACKREST

Image: Visual representation of the three adjustable reclining angles (90°, 120°, 160°) for various activities.

5.2. Swivel and Rocking Functions

The chair is equipped with a 360° swivel base, allowing for full rotation without moving the entire chair. It also features a gentle rocking motion for added comfort and relaxation.

5.3. Cup Holders and Side Pocket

The recliner includes two integrated cup holders on the armrests for convenient placement of beverages. A side storage pocket is also provided for keeping magazines, remote controls, or other small items within easy reach.



■ 2 CUP HOLDERS



■ 2 SIDE POCKETS



Image: Detailed view of the dual cup holders and the convenient side storage pocket on the recliner.

6. MAINTENANCE AND CARE

- **Regular Cleaning:** Vacuum the fabric regularly using a soft brush attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner following the product's instructions, testing on an inconspicuous area first.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fabric fading.
- **Mechanism Care:** Periodically check the reclining and swivel mechanisms for smooth operation. Avoid forcing the mechanism if it feels stiff.
- **FSC-Certified Wood:** The internal wood components are FSC-Certified, indicating responsible forest management.

RECLINER SWIVEL CHAIR

Adjust to fit your needs by pulling up the handle
Enjoy your entertainment or rest



BOOK READING
90°



TV WATCHING
120°



TAKE A NAPPING
160°

Image: A close-up view of the upholstered fabric, highlighting its texture and quality.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not recline smoothly.	Mechanism obstruction or loose connection.	Check for any objects obstructing the mechanism. Ensure the backrest is fully engaged and secured to the base.
Footrest does not retract fully.	Obstruction or mechanism issue.	Ensure no objects are under the footrest. Apply firm, even pressure with your legs to close the footrest.
Chair feels unstable or wobbly.	Improper assembly or uneven floor.	Verify that all assembly connections are secure. Ensure the chair is placed on a flat, level surface.

8. SPECIFICATIONS

- **Brand:** COMHOMA
- **Model Name:** CHAIR (H1148-GRAY-N)
- **Color:** Grey
- **Product Dimensions (Overall):** 37.48"D x 37.48"W x 39.05"H
- **Seat Size:** 22"W x 22"D
- **Seat Depth:** 21.87 inches
- **Item Weight:** 95.4 pounds
- **Maximum Weight Capacity:** 330 lbs
- **Reclining Position Count:** 3 (90°, 120°, 160°)
- **Special Feature:** Back Support, 360° Swivel, Rocking, Cup Holders, Side Pocket
- **Material:** Upholstered Fabric, Metal Frame, FSC-Certified Wood
- **Assembly Required:** Yes
- **Batteries Required:** No

SIZE



Image: Diagram illustrating the key dimensions of the COMHOMA Recliner Chair.

9. WARRANTY AND SUPPORT

While specific warranty details are not provided in this manual, COMHOMA is committed to customer satisfaction. If you encounter any issues with your recliner or require assistance, please contact COMHOMA customer support. Please retain your proof of purchase for any inquiries. The product is eligible for 30-day easy returns.

For further assistance, please visit the [COMHOMA Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question