Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lawyettle XG7008O-1BK-NEW

Lawyettle 15-inch Dusk to Dawn Outdoor Wall Light Fixture

User Manual - Model XG7008O-1BK-NEW

Introduction

Thank you for choosing the Lawyettle 15-inch Dusk to Dawn Outdoor Wall Light Fixture. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions thoroughly before beginning installation and retain them for future reference.
This outdoor lighting fixture features a modern design with a sturdy black frame and clear glass. It is equipped with an advanced dusk to dawn sensor for automatic operation and is constructed from premium metal for exceptional weather resistance.

Safety Information

- **WARNING:** Always turn off the electrical supply at the main circuit breaker or fuse box before installation or performing any maintenance.
- Consult a qualified electrician if you are unsure about the wiring process.
- Ensure all electrical connections are made in accordance with local codes and ordinances.
- This fixture is designed for outdoor use.
- Do not exceed the maximum wattage of 60W for E26 bulbs.
- Handle glass components with care to prevent breakage.
- Proper grounding is essential for safety.

Package Contents

Verify that all components are present before installation:

- 1 x Lawyettle Outdoor Wall Light Fixture
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

Note: Bulb is not included. This fixture requires one E26 base bulb (LED, CFL, or incandescent, up to 60W).



Image: A selection of E26 base bulbs, such as LED, CFL, and incandescent types, that are compatible with the fixture (bulb not included).

Specifications

Feature	Specification
Brand	Lawyettle
Model Number	XG7008O-1BK-NEW
Dimensions (L x W x H)	6" x 5" x 15"
Material	Metal, Tempered Glass
Color	Black
Power Source	Corded Electric

Voltage	110 volts
Bulb Base	E26
Max Wattage	60 watts
Sensor Type	Dusk to Dawn Photocell
Weather Resistance	Waterproof, Anti-Rust
Installation Type	Semi Flush Mount
Certifications	ETL Listed



Image: This diagram provides the exact measurements of the light fixture, including its 15-inch height, 6-inch length, and 5-inch width, along with mounting plate dimensions.

Setup and Installation

Follow these steps to install your outdoor wall light fixture. It is recommended to have two people for installation.

1. **Prepare for Installation:** Turn off power at the circuit breaker. Ensure the mounting surface is clean, dry, and structurally sound.
2. **Install Mounting Plate:** Secure the mounting plate to the junction box using the provided screws. Ensure the plate is level and firmly attached.
3. **Connect Wires:** Carefully connect the electrical wires. Connect the fixture's black wire to the house's black (live) wire, the fixture's white wire to the house's white (neutral) wire, and the fixture's ground wire to the house's ground wire (or ground screw on the mounting plate). Use wire nuts to secure connections.
4. **Mount the Fixture:** Align the fixture with the mounting plate and secure it using the provided screws. Ensure the fixture is flush against the wall and stable.
5. **Install Bulb:** Insert an E26 base bulb (not included) into the socket. Do not exceed 60W.
6. **Restore Power:** Turn the power back on at the circuit breaker.



Image: This image illustrates the initial step of installation, focusing on securing the mounting bracket to the wall.

Your browser does not support the video tag.

Video: This video provides a visual guide for installing the Lawyettle 15-inch outdoor wall light, covering mounting the backplate, connecting wires, and securing the fixture.

Operating Instructions

This fixture is equipped with an advanced dusk to dawn photocell sensor for automatic operation.

- **Automatic On/Off:** The sensor detects ambient light levels. The light will automatically turn on when the surrounding light drops below a certain threshold (e.g., at dusk) and turn off when sufficient light is detected (e.g., at dawn).
- **Sensor Placement:** Ensure the photocell sensor (typically a small clear dome or circle on the fixture) is not obstructed by eaves, trees, or other objects that could block natural light.
- **Testing:** After installation, cover the sensor to simulate darkness. The light should turn on. Uncover the sensor, and the light should turn off after a short delay.



Image: This image illustrates the automatic operation of the dusk to dawn photocell sensor, showing the light fixture off during the day (LUX>90) and automatically turning on at night (LUX<20).

Maintenance

- **Cleaning:** To clean the fixture, ensure the power is off. Wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass.

- **Bulb Replacement:** Turn off power at the circuit breaker. The fixture features an open bottom design for easy bulb replacement. Simply unscrew the old bulb and screw in a new E26 base bulb (max 60W).
- **Inspection:** Periodically inspect the fixture for any signs of damage, loose wiring, or corrosion. Address any issues promptly.



Image: This image highlights the light fixture's robust construction, indicating its waterproof, snow protection, heat-resistant, and storm-proof capabilities for various weather conditions.

Troubleshooting

Problem	Possible Cause	Solution

Light does not turn on at night.	◦ Power is off. ◦ Bulb is faulty or loose. ◦ Photocell sensor is obstructed or faulty. ◦ Wiring issue.	◦ Check circuit breaker. ◦ Replace bulb or tighten it. ◦ Clear any obstructions from the sensor. ◦ Consult an electrician to check wiring.
Light stays on during the day.	◦ Photocell sensor is obstructed or dirty. ◦ Sensor is receiving insufficient ambient light.	◦ Clean the sensor. ◦ Ensure no objects are blocking light to the sensor. ◦ Relocate the fixture if necessary to an area with more natural light.
Light flickers.	◦ Loose bulb. ◦ Faulty bulb. ◦ Loose wiring connection.	◦ Tighten bulb. ◦ Replace bulb. ◦ Turn off power and check wiring connections.

Warranty and Support

This Lawyettle outdoor wall light fixture comes with a**1-year manufacturer's warranty** from the date of purchase, covering defects in materials and workmanship under normal use.
For warranty claims, technical support, or any questions regarding your product, please refer to the contact information provided at the point of purchase or visit the official Lawyettle brand store for assistance.

© 2023 Lawyettle. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZGDZZX8

More documents and user manuals: **https://manuals.plus/**