

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [kensen](#) /

› [Kensen 6.0 Upgraded 2-in-1 Dual-Head Electric Body Hair Trimmer Instruction Manual \(Model: 06-KTMQ32-01A\)](#)

kensen 06-KTMQ32-01A

Kensen 6.0 Upgraded 2-in-1 Dual-Head Electric Body Hair Trimmer Instruction Manual

Model: 06-KTMQ32-01A

[Safety Information](#)

[Product Overview](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Specifications](#)

[Support &](#)

[Warranty](#)

1. SAFETY INFORMATION

Please read all safety instructions carefully before using the Kensen Body Hair Trimmer. Retain this manual for future reference.

- **General Safety:** Always clean and dry the shaver after use to prevent bacterial growth and skin irritation. Avoid using the shaver while charging.
- **Blade Handling:** Be cautious when using the double-sided blades and the rotating head, especially in sensitive areas, to prevent scratches, cuts, or pulling. Ensure blades are properly attached before use.
- **Waterproof Use:** The trimmer features an IPX6 waterproof design, supporting both wet and dry shaving. It can be used in the shower.
- **Children:** Keep out of reach of children. This device is not a toy.
- **Damage:** Do not use the device if it is damaged. Contact customer support for assistance.

2. PRODUCT OVERVIEW

The Kensen 6.0 Upgraded 2-in-1 Dual-Head Electric Body Hair Trimmer is designed for versatile grooming, offering precision and comfort for various body areas.

Key Features:

- **Innovative Double-Sided Blade Head:** High-quality stainless steel double-edged blades allow for close shaving and versatile use for facial shaping, body hair removal, and sideburns.
- **Ergonomic 30-Degree Blade Head Rotation:** The blade head rotates 30 degrees for better body contouring, ensuring safe trimming in sensitive areas and preventing cuts or pulling.
- **2-in-1 Electric Trimmer with Multiple Heads:** Includes two interchangeable trimmer heads and two 1-10mm adjustable comb attachments for various hair types and body parts (face, arms, shoulders, chest, armpit, groin, pubic, legs).
- **Powerful Motor & Long Battery Life:** Features a 6800RPM motor for efficient, low-vibration performance. A 600mAh battery provides up to 100 minutes of use on a 1.5-hour charge.
- **IPX6 Waterproof Design:** Supports wet and dry shaving for full body care, even in the shower.
- **Travel Lock Function:** Long press for 3 seconds to lock/unlock the device, preventing accidental activation during travel.

Product Components:



Figure 1: Complete set of Kensen Body Hair Trimmer components.

2-IN-1 REPLACEABLE BLADES

Two shaving heads allow you to style your entire body as you see fit



T-shaped shaving head:

Fine shaving, suitable for body and beard



I-shaped shaving head:

Fast shaving, suitable for body hair




Figure 2: The 2-in-1 replaceable blade heads for versatile grooming.

20-IN-1 ADJUSTABLE COMB

DIY THE BEARD OR HAIR YOU WANT!

1-10mm adjustable, 0.5mm increment or decrement for each adjustment.



Figure 3: Adjustable comb for precise hair length control (1-10mm).

ULTRA-LONG BATTERY LIFE

Single charge = 100~120 minutes of usage time



Figure 4: USB-C charging for convenience and ultra-long battery life.

3. SETUP

3.1 Unboxing and Initial Charge

Upon receiving your Kensen Body Hair Trimmer, carefully unbox all components. Before first use, fully charge the device using the provided USB-C cable. A full charge takes approximately 1.5 hours and provides up to 100 minutes of usage.

Your browser does not support the video tag.

Video 1: An overview of the Kensen 2-in-1 Body Hair Trimmer, demonstrating its features and components.

3.2 Attaching/Changing Trimmer Heads

The Kensen trimmer comes with interchangeable heads for different grooming needs. To change a head:

1. Ensure the trimmer is turned off.

2. Gently pull the currently attached head upwards to detach it from the main body.
3. Align the desired head (T-shaped or I-shaped) with the body of the trimmer and push it down until it clicks securely into place.
4. For adjustable length, attach the appropriate comb to the trimmer head. Rotate the dial on the comb to select your desired hair length (1-10mm).



Figure 5: Simple and safe replacement of different shaving heads.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off and Travel Lock

- **To Power On/Off:** Press the power button once. The LED display will show the battery percentage.
- **To Activate Travel Lock:** Press and hold the power button for 3 seconds. The device will lock, preventing accidental activation.
- **To Deactivate Travel Lock:** Press and hold the power button for 3 seconds again. The device will unlock and be ready for use.

TRAVEL WITHOUT WORRY

Long press for 3 seconds to lock/
unlock the device



Figure 6: Travel lock function for worry-free portability.

4.2 General Trimming Guidelines

- For best results, ensure your skin is clean.
- Hold the trimmer flat against the skin and move it slowly against the direction of hair growth.
- Use the T-shaped head for general body and beard trimming, and the I-shaped head for more precise or sensitive areas.
- Utilize the adjustable comb attachments to achieve desired hair lengths.



Figure 7: Versatile use for multiple body regions.

Your browser does not support the video tag.

Video 2: Short demonstration of the Kensen Body Hair Trimmer in action.

4.3 Wet & Dry Use

The IPX6 waterproof rating allows for convenient wet or dry shaving. You can use the trimmer with shaving cream or gel in the shower for a comfortable experience, or dry for quick touch-ups.

WET & DRY BEARD TRIMMER

IPX6 Waterproof 

Easy hair removal in the shower for
everyday relaxing moments



Figure 8: Enjoy easy hair removal in the shower with the IPX6 waterproof design.

5. MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your Kensen Body Hair Trimmer.

1. **Cleaning the Blades:** After each use, turn off the trimmer and detach the blade head. Rinse the blade head under running water to remove hair and debris. Use the provided cleaning brush for stubborn hairs.
2. **Drying:** Shake off excess water and allow the blade head to air dry completely before reattaching or storing.

3. **Lubrication:** Periodically apply a small drop of clipper oil (not included) to the blades to maintain smooth operation.
4. **Storage:** Store the trimmer in a cool, dry place away from direct sunlight.

6. SPECIFICATIONS

Feature	Detail
Model Name	Body Hair Trimmer
Item Model Number	06-KTMQ32-01A
Brand	kensen
Power Source	Battery Powered (600mAh)
Battery Life	Up to 100 minutes
Charging Time	Approx. 1.5 hours
Special Feature	IPX6 Waterproof, Dual-Head Design, Adjustable Comb (1-10mm), Travel Lock
Motor Speed	6800 RPM
Package Dimensions	7.91 x 5.2 x 1.85 inches
Item Weight	9.91 ounces

7. SUPPORT & WARRANTY

Kensen is committed to providing excellent customer service and product support.

- **After-Sale Service:** If you encounter any problems or have suggestions, please contact our customer service team. We aim to resolve your issues within 24 hours.
- **Warranty:** The product comes with a 12-month replacement warranty and lifetime service.
- **Contact:** For support, please refer to the contact information provided in your product packaging or visit the official Kensen website.

