

manuals.plus /

› [mooas](#) /

› [mooas Time Loop Digital Timer Model 102726 User Manual](#)

mooas 102726

mooas Time Loop Digital Timer User Manual

Model: 102726

INTRODUCTION

The mooas Time Loop Digital Timer is a versatile and intuitive device designed to assist with time management for various activities such as studying, cooking, or focused work. It features a clear LCD display, a visual color timer ring, and both count-up and count-down functionalities. This manual provides detailed instructions for setting up, operating, and maintaining your timer.



Image: Front view of the mooas Time Loop Digital Timer, showcasing its digital display and color ring.

PRODUCT FEATURES

- High-clarity LCD display with 3-level brightness adjustment.
- Intuitive color timer ring for visual time representation.
- Supports count-up to 99 hours and count-down up to 60 minutes.
- Fast and easy time setting using dual dials.
- Repeat function for up to 99 cycles.
- Low-power ECO mode for extended battery life.
- 3-level alarm volume settings: Low, High, and Silent.
- Versatile placement options with an integrated stand and magnet.
- Convenient USB Type-C charging.

PACKAGE CONTENTS

- mooas Time Loop Digital Timer (Model 102726)
- USB Type-C Charging Cable
- User Manual

SETUP

1. Charging the Device

Before initial use, fully charge the timer using the provided USB Type-C cable. Connect the cable to the charging port on the back of the device and to a standard USB power adapter (not included).

Convenient Charging

Type C USB Cable




Image: Rear view of the timer showing the USB Type-C charging port with a cable connected.

2. Adjusting Brightness and Volume

On the back of the timer, locate the switches for brightness and alarm volume. Adjust these settings according to your preference and environment.

- **Brightness:** Select from 3 levels (e.g., Low, Medium, High) or ECO mode for power saving.
- **Alarm Volume:** Choose between Low, High, or Silent mode.




Image: The timer displaying a time, illustrating its customizable brightness and alarm volume settings.

OPERATING INSTRUCTIONS

1. Setting the Time

The timer features two dials on top: 'M' for minutes and 'S' for seconds. Rotate these dials to set your desired time.

2. Count-Down Mode

1. Rotate the 'M' and 'S' dials to set the desired countdown duration (up to 60 minutes).

2. Press either the 'M' or 'S' dial once to start the countdown. The visual color ring will begin to diminish.
3. To pause, press either dial again. To resume, press again.
4. When the timer reaches zero, the alarm will sound (if not in silent mode).
5. To stop the alarm, press either dial.



Image: The timer displaying a countdown, highlighting its dual functionality for counting up or down.

3. Count-Up Mode

1. Ensure the timer is set to 00:00.
2. Press either the 'M' or 'S' dial once to start the count-up. The timer will begin counting upwards (up to 99 hours).
3. To pause, press either dial again. To resume, press again.
4. To reset the count-up timer, long-press either dial.

4. Repeat Function

The timer includes a repeat function, allowing you to cycle a set countdown duration up to 99 times.

1. Set your desired countdown time using the 'M' and 'S' dials.
2. Press the 'REPEAT' button (located on the top of the timer) to activate the repeat function. The display will show "REPEAT" and the number of cycles.
3. Press either the 'M' or 'S' dial to start the first countdown cycle.
4. After each cycle completes, the timer will automatically reset and begin the next cycle.
5. To deactivate the repeat function, press the 'REPEAT' button again.



Image: The timer displaying a countdown with the "REPEAT" indicator, demonstrating its repeat function.

PLACEMENT OPTIONS

The mooas Time Loop Digital Timer offers flexible placement options:

- **Integrated Stand:** Pull out the stand on the back of the timer to prop it up on any flat surface, such as a desk or

countertop.

- **Magnetic Attachment:** The timer has a built-in magnet, allowing it to be securely attached to metallic surfaces like refrigerators or whiteboards.

Two Mounting

Stand/Magnet



Image: Two mooas timers, one black and one white, demonstrating both the stand and magnetic mounting options.

MAINTENANCE

- **Cleaning:** Wipe the timer with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Battery Care:** To prolong battery life, avoid fully discharging the timer frequently. Charge it when the low battery indicator appears.
- **Storage:** Store the timer in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Timer not turning on:

Ensure the timer is fully charged. Connect it to a USB power source and allow it to charge for at least 30 minutes before attempting to power it on again.

Alarm not sounding:

Check the alarm volume switch on the back of the device. Ensure it is not set to 'Silent' mode.

Display is dim:

Adjust the brightness switch on the back of the device. If it is in ECO mode, switch to a brighter setting. Ensure the battery is sufficiently charged.

Timer not responding to dial input:

Try resetting the device by long-pressing both dials simultaneously for a few seconds. If the issue persists, ensure the battery is charged.

SPECIFICATIONS







Feature	Detail
Brand	mooas
Model Number	102726
Color	Black
Material	Acrylonitrile Butadiene Styrene
Product Dimensions	86D x 37W x 30H Millimeters
Item Weight	118 g (0.26 Pounds)
Max Count-Up Time	99 Hours
Max Count-Down Time	60 Minutes
Brightness Settings	3 Levels + ECO Mode
Alarm Volume Settings	Low, High, Silent
Charging Port	USB Type-C

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official mooas website. Keep your proof of purchase for warranty claims.



Related Documents - 102726

	<p>Mooas Multi Cube Timer MT-C2 User Manual and Instructions</p> <p>Detailed user manual for the Mooas Multi Cube Timer (MT-C2). Learn how to set the clock, use the timer functions, understand features, and follow safety precautions. Includes product specifications.</p>
	<p>Mooas Multi-hexagon Clock Timer MT-H7X620 User Manual</p> <p>User manual for the Mooas Multi-hexagon Clock Timer (Model MT-H7X620), detailing features, operation, safety warnings, and troubleshooting for this hexagonal digital timer.</p>
	<p>Mooas TC2 Cooking Timer & Alarm Clock User Manual</p> <p>Comprehensive user manual for the Mooas TC2 Cooking Timer & Alarm Clock. Learn about its features, how to use countdown and count-up modes, set alarms, replace batteries, and understand specifications and precautions. Includes troubleshooting and warranty information.</p>
	<p>Mooas Multi-Hexagon Clock Timer 2nd Generation User Manual</p> <p>User manual for the Mooas Multi-Hexagon Clock Timer 2nd Generation, detailing its features, operation, and specifications for various time management needs.</p>
	<p>Mooas Loop Waterproof Clock User Manual</p> <p>User manual for the Mooas Loop Waterproof Clock, detailing features, setup, installation, and precautions for this water-resistant bathroom clock.</p>
	<p>mooas LED Digital Mirror Clock User Manual</p> <p>User manual for the mooas LED Digital Mirror Clock, detailing features, how to use, alarm settings, temperature display, and precautions. Includes product specifications and operational guidance.</p>