

RALGEND 2401MTDBK

RALGEND Farmhouse Shoe Storage Cabinet with 2 Flip Drawers & Coat Rack, LED Light (Model 2401MTDBK) Instruction Manual

Model: 2401MTDBK

1. INTRODUCTION

Thank you for purchasing the RALGEND Farmhouse Shoe Storage Cabinet. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new furniture. Please read this manual thoroughly before beginning assembly and retain it for future reference.

2. IMPORTANT SAFETY INFORMATION

- Always follow the provided instructions for assembly and installation.
- Use the included anti-tip kit to secure the cabinet to the wall to prevent tipping. This is crucial for safety, especially in households with children or pets.
- For your safety, we recommend a two-person installation due to the size and weight of the unit.
- Ensure all connections are secure before use.
- Do not overload the shelves or hooks beyond the specified weight limits.
- Keep small parts and packaging materials away from children.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x Shoe Cabinet Unit
- 1 x Accessory Kit (hardware, screws, etc.)
- 1 x Anti-Tip Kit
- 1 x Instruction Manual (this document)
- LED Light Strip with USB adapter and remote control

4. PRODUCT SPECIFICATIONS

Brand	RALGEND
Model Number	2401MTDBK
Color	Black
Product Dimensions (D x W x H)	9.4"D x 31.5"W x 70.8"H
Item Weight	32.7 pounds
Weight Limit (Top Surface)	62 Pounds
Material	Engineered Wood (Particle Board, MDF)
Special Feature	LED Light (6000+ Colors, Built-in Mic, Music Sync, Timing Function, Remote & App Control)
Mounting Type	Floor Mount (Freestanding with Anti-Tip Kit)
Number of Hooks	5
Number of Flip Drawers	2 (with adjustable/removable dividers)

Product Size



Image: Detailed product dimensions including height, width, and depth, along with internal measurements for the shoe drawers and top shelf.

5. ASSEMBLY INSTRUCTIONS

All components are numbered, and an illustrated guide is included in your package. Please follow the steps carefully. A two-person assembly is recommended.

5.1. Preparation

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify all parts by their corresponding numbers as per the included accessory kit and instruction manual.
3. Gather necessary tools (e.g., screwdriver, hammer if needed).

5.2. Step-by-Step Assembly

1. **Assemble the Base:** Attach the side panels to the bottom panel using the designated hardware. Ensure all connections are snug but do not overtighten.
2. **Install Flip Drawers Mechanism:** Secure the metal runners and hinges for the flip drawers to the side panels according to the diagrams.
3. **Construct Flip Drawers:** Assemble the two flip drawers, inserting the adjustable and removable dividers. These dividers allow customization for various shoe sizes.



Image: The two flip-down shoe drawers, demonstrating the adjustable and removable dividers that allow for customized storage of different shoe types and sizes.

4. **Attach Drawers to Cabinet:** Carefully insert the assembled flip drawers into their respective positions on the cabinet.
5. **Assemble Top Section (Coat Rack):** Attach the back panel and side panels for the upper coat rack section. Install

the 5 hooks onto the back panel.

6. **Integrate LED Light Strip:** Affix the LED light strip to the designated area under the top shelf of the coat rack. Connect the USB adapter.



Image: A detailed view of the LED light strip installed in the coat rack section, highlighting its features such as 6000+ colors, built-in mic, music sync, timing function, and control via remote or app.

7. **Secure Top to Base:** Carefully place and secure the assembled coat rack section onto the shoe cabinet base.
8. **Install Anti-Tip Kit:** Attach the anti-tip kit to the top rear of the cabinet and secure it to a wall stud using appropriate hardware. This step is critical for stability and safety.



Image: The RALGEND Farmhouse Shoe Storage Cabinet fully assembled, showcasing its coat rack with hooks, LED lighting, and two flip-down shoe drawers, positioned in an entryway.

6. OPERATING INSTRUCTIONS

6.1. LED Light Operation

- **Power On/Off:** Plug the USB adapter into a power source. Use the provided remote control or the dedicated mobile app to turn the LED light strip on or off.
- **Color and Mode Selection:** The LED strip offers over 6000 colors and various lighting modes. Use the remote or app to cycle through colors, adjust brightness, and select different dynamic modes.
- **Music Sync Function:** Activate the music sync feature via the remote or app. The built-in microphone will detect ambient sound, and the lights will change rhythmically with the music, creating a lively ambiance.
- **Timing Function:** Set a timer for the LED lights to automatically turn off after a specified duration using the remote or app.

6.2. Flip Drawers Usage

- **Opening/Closing:** Gently pull the handle to flip open the drawer. Push it back to close.
- **Adjusting Dividers:** The internal dividers are removable and adjustable. To customize storage space, slide the dividers to different slots or remove them entirely to accommodate various shoe heights, from sneakers to high heels.
- **Capacity:** Each drawer is designed to hold multiple pairs of shoes, protecting them from dust and pets.

6.3. Coat Rack and Open Compartment

- **Hooks:** Utilize the 5 hooks to hang coats, jackets, hats, scarves, bags, and other accessories.
- **Open Compartment/Desktop:** The spacious desktop and open compartment above the shoe drawers are ideal for placing decorative items, books, keys, or other grab-and-go essentials.

7. MAINTENANCE AND CARE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the cabinet to maintain its appearance.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **LED Light Care:** Keep the LED strip and its connections dry. If the remote or app control malfunctions, check battery levels or app connectivity.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet feels unstable/wobbly.	Loose connections; Anti-tip kit not installed or improperly secured.	Ensure all screws are tightened. Install or properly secure the anti-tip kit to a wall stud.
LED light not turning on.	USB adapter unplugged; Remote battery dead; Faulty connection.	Check if the USB adapter is securely plugged in. Replace remote batteries. Verify LED strip connections.
Flip drawers not closing smoothly.	Obstruction; Misaligned runners; Overloaded.	Check for items blocking the drawer mechanism. Ensure runners are correctly aligned. Reduce the number of shoes if overloaded.
Shoes do not fit in drawers.	Dividers are not adjusted or removed.	Adjust or remove the internal dividers to create more space for larger shoes or boots. Note that very large shoe sizes (e.g., men's size 12+) may not fit.

9. PRODUCT OVERVIEW VIDEO

Watch this video for a visual overview of the RALGEND Farmhouse Shoe Storage Cabinet's features and functionality.

Your browser does not support the video tag.

Video: A brief demonstration of the RALGEND Farmhouse Shoe Storage Cabinet, highlighting its design, flip drawers, coat rack, and LED lighting features.

10. WARRANTY AND CUSTOMER SUPPORT

RALGEND products are designed for quality and durability. For specific warranty details, please refer to the documentation included with your purchase or contact RALGEND customer support directly.

If you encounter any issues or have questions regarding your product, please reach out to our customer service team for assistance. Contact information can typically be found on the RALGEND official website or through your purchase platform.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DZGWH5S1>

More documents and user manuals: <https://manuals.plus/>