

KEMEI KM-2293GAMZ

KEMEI 2293 Professional Hair and Beard Trimmer User Manual

Model: KM-2293GAMZ

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your KEMEI 2293 Professional Hair and Beard Trimmer. Please read all instructions carefully before operating the device and retain this manual for future reference.

The KEMEI 2293 is a versatile, cordless, and rechargeable trimmer designed for precision hair, beard, and body grooming. It features a zero-gapped T-blade for close cuts and an LED display for battery status.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x KEMEI 2293 Electric Hair Trimmer
- 3 x Trimming Guards (1mm, 2mm, 3mm)
- 1 x USB Charging Cable
- 1 x Lubricant Oil Bottle
- 1 x Cleaning Brush
- 1 x Barber Comb



Image 2.1: KEMEI 2293 Trimmer with included accessories: the trimmer, three guide combs, USB charging cable, lubricant oil, cleaning brush, and a barber comb.

3. PRODUCT FEATURES

- **Zero-Gapped T-Blade:** Designed for precise, close cutting and detailing.
- **High-Powered Motor:** Operates at 6000 RPM for efficient and smooth trimming.
- **Low Noise Operation:** Produces less than 60 dB of noise for a quieter grooming experience.
- **LED Display:** Shows current battery level and charging status.
- **Long Battery Life:** Built-in 1200 mAh lithium-ion battery provides over 180 minutes of use on a 3-hour charge.
- **Cordless Design:** Offers flexibility and ease of use without cord restrictions.
- **Durable Construction:** Features a solid metal body for enhanced longevity.




Image 3.1: A close-up view of the KEMEI 2293's precision T-blade, highlighting its sharp cutting edges for detailed grooming.



Image 3.2: The KEMEI 2293 Trimmer connected to a USB charging cable, with its LED display showing the battery percentage and charging status.

4. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please adhere to the following safety guidelines:

- Always unplug the trimmer before cleaning.
- Do not use the trimmer on wet hair or near water.
- Keep blades and the device out of reach of children.
- Always follow recommended cleaning and maintenance procedures to prevent skin irritation or injury.
- Do not attempt to disassemble or repair the trimmer yourself. Contact qualified service personnel for assistance.
- Use only the provided charging cable and accessories.

5. SETUP

1. **Initial Charge:** Before first use, fully charge the trimmer for approximately 3 hours. The LED display will indicate the battery percentage.

2. **Blade Inspection:** Ensure the T-blade is clean and free from debris. Apply a few drops of the provided lubricant oil to the blades before the first use and after each cleaning.
3. **Attach Guard (Optional):** If a specific hair length is desired, select one of the three trimming guards (1mm, 2mm, or 3mm) and securely attach it to the trimmer head.

6. OPERATING INSTRUCTIONS

Follow these steps for effective grooming:

1. **Preparation:** Ensure hair is clean and dry. For best results, comb hair in the direction of growth to remove tangles.
2. **Power On:** Press the power button to turn on the trimmer. The LED display will illuminate.
3. **Trimming:**
 - For hair cutting, beard trimming, or body grooming, hold the trimmer with the blade flat against the skin or at a slight angle, depending on the desired cut.
 - Move the trimmer slowly and steadily against the direction of hair growth for an even cut.
 - When using trimming guards, ensure they are firmly attached.
 - For detailing and outlining, use the zero-gapped T-blade without a guard, carefully guiding it along the desired lines.
4. **Power Off:** Once finished, press the power button to turn off the trimmer.




Image 6.1: The KEMEI 2293 Trimmer demonstrating its versatility for hair trimming, beard trimming, and body grooming.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your trimmer:

1. **Cleaning:** After each use, turn off and unplug the trimmer. Use the provided cleaning brush to remove loose hairs from the blades and the trimmer body.
2. **Oiling Blades:** Apply 1-2 drops of the provided lubricant oil to the blades after every few uses or after cleaning. Turn on the trimmer for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and reduces friction.
3. **Storage:** Store the trimmer in a dry, cool place, away from direct sunlight and moisture. Ensure it is turned off and unplugged.
4. **Battery Care:** To prolong battery life, avoid completely draining the battery before recharging. Recharge the trimmer when the LED display indicates a low battery level.

OFFER SMOOTH & SNUG CUTTING

6000 RPM Motor

**Oil blade often to
make it sharper**

Powder metallurgy blade

Image 7.1: A hand applying lubricant oil to the blades of the KEMEI 2293 Trimmer, a crucial step for maintaining blade performance and longevity.

8. TROUBLESHOOTING

If you encounter issues with your KEMEI 2293 Trimmer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on	Low or no battery charge	Charge the trimmer fully (approx. 3 hours).
Poor cutting performance	Blades are dull or clogged with hair; insufficient lubrication	Clean blades thoroughly with the brush. Apply lubricant oil. If blades are dull, consider professional sharpening or replacement.

Problem	Possible Cause	Solution
Trimmer pulls hair	Blades are not properly aligned or are dull; hair is tangled	Ensure blades are clean and oiled. Comb hair before trimming. If problem persists, check blade alignment or consider replacement.
Excessive noise or vibration	Lack of lubrication; foreign object in blades	Apply lubricant oil to blades. Inspect blades for any foreign objects and remove carefully.

9. SPECIFICATIONS

- **Model Number:** KM-2293GAMZ
- **Brand:** KEMEI
- **Power Source:** Battery Powered
- **Battery Type:** 1200 mAh Lithium-ion (included)
- **Charging Time:** Approximately 3 hours
- **Operating Time:** Over 180 minutes
- **Motor Speed:** 6000 RPM
- **Noise Level:** Less than 60 dB
- **Product Dimensions:** 6.5 x 1.57 x 1.77 inches
- **Item Weight:** 230 Grams (8.11 ounces)
- **Color:** Gold (2293gold)








Image 9.1: The back of the KEMEI 2293 Trimmer, displaying its model number, input voltage, and manufacturing origin.

10. WARRANTY AND SUPPORT

KEMEI products are manufactured with quality and reliability in mind. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the product packaging or contact KEMEI customer support for specific warranty terms and conditions.

For technical assistance, troubleshooting, or warranty claims, please visit the official KEMEI website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Related Documents - KM-2293GAMZ

	<p>Kemei KM-2269 Hair Clipper: Manual and Safety Instructions</p> <p>Official manual and safety instructions for the Kemei KM-2269 hair clipper, providing essential information for safe and effective use.</p>
	<p>Kemei KM-418 Electric Rechargeable Hair Clipper User Manual</p> <p>Detailed user manual for the Kemei KM-418 rechargeable electric hair clipper, covering preparation, usage, maintenance, guarantee, and battery disposal instructions.</p>
	<p>Kemei KM-666 Professional Electric Hair Clipper User Manual</p> <p>User instructions and guide for the Kemei KM-666 Professional Electric Hair Clipper, detailing its features and operation for personal grooming and barber use.</p>
	<p>Kemei KM-2293 Hair Clipper User Manual and Safety Instructions</p> <p>This document provides the user manual and safety instructions for the Kemei KM-2293 Hair Clipper, detailing its features and proper usage for excellent industrial design.</p>
	<p>Kemei KM-1102 Electric Shaver User Manual</p> <p>User manual for the Kemei KM-1102, a rechargeable cordless shaver for men featuring twin blades for efficient shaving and a multifunction trimmer for versatile use.</p>



[Kemei KM-1858 Hair Clipper User Manual and Safety Instructions](#)

User manual and safety instructions for the Kemei KM-1858 professional cordless rechargeable hair clipper, detailing its design and usage.