realme RMX5054

realme 14 Pro+ 5G Smartphone User Manual

Model: RMX5054

1. Introduction

This manual provides essential information for the safe and efficient use of your realme 14 Pro+ 5G Smartphone. Please read this manual thoroughly before using the device to ensure proper operation and to prevent damage.

The realme 14 Pro+ is a high-performance 5G smartphone featuring an Octa-core processor, 8GB RAM, and 256GB internal storage. It operates on Android 15 with Realme UI 6.0 and is equipped with a 6000mAh non-removable battery. This device supports Dual-SIM functionality and a wide range of network frequencies for global compatibility.

2. Setup Guide

2.1 What's in the Box

Upon unboxing your realme 14 Pro+ 5G Smartphone, verify that all components are present:

- realme 14 Pro+ 5G Smartphone (Pearl White)
- USB Cable
- (Note: Power adapter may be included depending on region/package)




Image: realme 14 Pro+ smartphone, showing the device in Pearl White, alongside the USB cable and a 120W power adapter. This image illustrates the primary components typically found in the product packaging.

2.2 Initial Charging

Before first use, it is recommended to fully charge your device. Connect the USB cable to the smartphone's USB Type-C port and the other end to a compatible power adapter. The battery indicator on the screen will show charging progress.

2.3 SIM Card Installation

The realme 14 Pro+ supports Dual-SIM functionality. Locate the SIM card tray on the side of the device. Use the provided SIM ejector tool to open the tray. Insert your Nano-SIM cards into the designated slots, ensuring the gold contacts face downwards. Carefully reinsert the tray into the phone.



Image: Top and bottom edges of the realme 14 Pro+ smartphone. The bottom edge clearly shows the USB Type-C port, speaker grille, and microphone, while the top edge shows another microphone and antenna lines. This view helps in identifying the charging port and SIM tray location.






Image: Side profile of the realme 14 Pro+ smartphone, highlighting the power button and volume rocker. This image assists users in locating the physical buttons for device operation.

2.4 Powering On/Off

To power on, press and hold the Power button (located on the right side) until the realme logo appears. To power off, press and hold the Power button, then select "Power off" from the options on the screen.

3. Operating Instructions

3.1 Basic Navigation

The realme 14 Pro+ features a 6.83-inch OLED display with 1272 x 2800 pixels resolution. Navigate the interface using touch gestures: tap to select, swipe to scroll, pinch to zoom. The Android 15 operating system with Realme UI 6.0 provides an intuitive user experience.



Image: Front and back views of the realme 14 Pro+ smartphone. The front displays the OLED screen and front camera, while the back showcases the Pearl White finish and the prominent circular camera module.

3.2 Network Connectivity

Your device supports 2G, 3G, 4G LTE, and 5G networks. Ensure your SIM card is active and your network provider supports the frequencies listed in the specifications section for optimal connectivity. This phone is designed for GSM networks and is not compatible with CDMA networks.

3.3 Camera Usage

The realme 14 Pro+ is equipped with an advanced triple camera system on the rear and a high-resolution front

camera:

- **Main Camera:** 50 MP, f/1.8, with OIS and multi-directional PDAF for sharp, stable images.
- **Periscope Telephoto Camera:** 50 MP, f/2.7, offering 3x optical zoom with OIS and multi-directional PDAF.
- **Ultrawide Camera:** 8 MP, f/2.2, with a 112° field of view for expansive shots.
- **Front Camera:** 32 MP, f/2.0, with AF for clear selfies and video calls.

Open the Camera application from your home screen or app drawer. Select your desired mode (Photo, Video, Portrait, etc.) and tap the shutter button to capture images or start recording.





Image: Angled rear view of the realme 14 Pro+ smartphone, focusing on the large circular camera module with its multiple lenses and flash. This image emphasizes the phone's photographic capabilities.

4. Maintenance

4.1 Battery Care

The realme 14 Pro+ is equipped with a 6000mAh non-removable battery. To prolong battery life:

- Avoid extreme temperatures.
- Use only the original or certified compatible charging accessories.
- Avoid completely draining the battery frequently.

4.2 Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid using harsh chemicals or abrasive materials, which can damage the finish or screen coating.

4.3 Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. You can usually find this option in the device's Settings menu under "System" or "About phone."

5. Troubleshooting

5.1 Common Issues and Solutions

Issue	Possible Solution

Issue	Possible Solution
Device not powering on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds.
Poor network signal	Check SIM card insertion. Verify network compatibility with your carrier. Move to an area with better coverage.
Apps crashing or freezing	Clear app cache/data. Restart the device. Ensure apps are updated.
Battery draining quickly	Reduce screen brightness. Close background apps. Disable unnecessary features like GPS or Wi-Fi when not in use.

For more complex issues, consider performing a factory reset (*Note: This will erase all data on your device. Back up important data before proceeding.*) or contacting customer support.

6. Specifications

Below are the detailed technical specifications for the realme 14 Pro+ 5G Smartphone:

Feature	Detail
Model Name	Realme 14 Pro+
Item Model Number	RMX5054
Operating System	Android 15, Realme UI 6.0
Processor	Qualcomm SM7635 Snapdragon 7s Gen 3 (4 nm), Octa-core (1x2.5 GHz Cortex-A720 & 3x2.4 GHz Cortex-A720 & 4x1.8 GHz Cortex-A520)
Display	6.83 inches, OLED, 1272 x 2800 pixels
Memory (RAM)	8 GB
Storage (ROM)	256 GB (non-expandable)
Rear Camera	50 MP (wide, OIS), 50 MP (periscope telephoto, 3x optical zoom, OIS), 8 MP (ultrawide)
Front Camera	32 MP (wide, AF)
Battery	6000 mAh, non-removable
Network Compatibility	Dual-SIM (GSM Only), 2G, 3G, 4G LTE, 5G (SA/NSA) - Specific bands listed in product description.
Dimensions	3.94 x 59.06 x 5.91 inches

Feature	Detail
Item Weight	14.1 ounces
Color	Pearl White
Connectivity	USB Type C, Wireless
Languages Supported	English, Spanish, Italian, German, French

7. Warranty and Support

Your realme 14 Pro+ 5G Smartphone is manufactured by Realme. For detailed warranty information, including terms, conditions, and duration, please refer to the warranty card included with your product or visit the official Realme support website.

For technical support, troubleshooting assistance beyond this manual, or service inquiries, please contact Realme customer service through their official channels. Keep your proof of purchase handy when seeking support.

You can find more information and support resources by visiting the official realme store on Amazon: realme Store

© 2025 Realme. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.