

[Manuals.plus](#) /

› [Bose](#) /

› Bose QuietComfort Bluetooth Headphones Instruction Manual

Bose 884367-1600

Bose QuietComfort Bluetooth Headphones Instruction Manual

Model: 884367-1600

PRODUCT OVERVIEW

The Bose QuietComfort Wireless Noise Cancelling Headphones offer powerful high-fidelity audio combined with legendary noise cancellation. Designed for comfort and immersive listening, these headphones allow you to control your sound environment with customizable modes and adjustable EQ. They provide extended battery life and versatile connectivity options for a seamless audio experience.



Image: Bose QuietComfort Headphones in Twilight Blue, showcasing their sleek design and over-ear form factor.

Key Features:

- **Active Noise Cancellation:** Block out distractions and immerse yourself in your audio.
- **Comfortable Design:** Plush earcups and a padded band ensure comfort during long listening sessions.

- **Quiet and Aware Modes:** Seamlessly switch between full noise cancellation and full awareness of your surroundings.
- **High-Fidelity Audio with Adjustable EQ:** Customize bass, mid-range, and treble for personalized sound.
- **Up to 24 Hours Battery Life:** Enjoy extended listening on a single charge.
- **Multi-point Bluetooth Connectivity:** Connect to multiple devices and switch between them effortlessly.
- **Wired Option:** Use with the included audio cable even when the battery is depleted.

WHAT'S IN THE BOX

Your Bose QuietComfort Headphones package includes the following items:

- Bose QuietComfort Headphones
- Protective Case
- Audio Cable
- USB-C (A to C) charging cable (12 inches)
- Safety Sheet



Image: Bose QuietComfort Headphones neatly folded inside their durable protective case, along with the included cables.

SETUP

1. Charging the Headphones

Before first use, fully charge your headphones. Connect the smaller end of the USB-C cable to the USB-C port on the right earcup and the other end to a USB-A wall charger (not included) or a computer. The battery indicator light will show charging status.

- Charging Time: Approximately 2.5 hours for a full charge.
- A 15-minute quick charge provides up to 2.5 hours of playtime.

2. Powering On/Off

To power on, slide the Power/Bluetooth switch on the right earcup to the 'On' position. To power off, slide the switch to the 'Off' position.

3. Bluetooth Pairing

When powered on for the first time, the headphones automatically enter pairing mode. The Bluetooth indicator light will blink blue. On your device, enable Bluetooth and select "Bose QuietComfort Headphones" from the list of available devices.

To pair with a new device, slide the Power/Bluetooth switch to the Bluetooth symbol and hold until the indicator blinks blue. Then, select the headphones on your device.



Image: A detailed view of the right earcup, highlighting the power/Bluetooth switch and other control buttons.

4. Bose Music App

For full functionality and customization, download the Bose Music app from your device's app store. The app allows you to:

- Manage Bluetooth connections.

- Adjust noise cancellation levels and modes.
- Customize EQ settings.
- Access product updates and support.

OPERATING THE HEADPHONES

Noise Cancellation Modes

The headphones feature two primary noise cancellation modes:

- **Quiet Mode:** Provides maximum noise cancellation, ideal for blocking out distractions.
- **Aware Mode:** Allows you to hear your surroundings while still enjoying your audio, useful for awareness in public spaces.

Toggle between these modes using the button on the left earcup or through the Bose Music app. The app also allows for custom modes and a Wind Block feature.

Audio Playback and Calls

Use the buttons on the right earcup to control playback (play/pause, skip tracks), adjust volume, and manage calls. The integrated microphone ensures clear communication.

Adjustable EQ

Personalize your listening experience by adjusting the bass, mid-range, and treble settings via the Bose Music app. This allows you to fine-tune the sound to your preference.

Multi-point Connectivity

The headphones can connect to multiple Bluetooth devices simultaneously. Use the multi-point toggle feature to seamlessly switch between connected devices without needing to disconnect and reconnect each time.

Wired Connection

For situations where Bluetooth is not available or preferred, connect the included audio cable to the 3.5mm jack on the left earcup. This allows for wired listening, even if the headphone battery is depleted.



Image: Side view of the Bose QuietComfort Headphones, illustrating the placement of the control buttons for easy access during operation.

MAINTENANCE

Cleaning

To maintain the appearance and performance of your headphones:

- Wipe the earcups and headband with a soft, dry cloth.
- For deeper cleaning, lightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- Ensure all ports are dry before charging.

Storage

When not in use, store your headphones in the provided protective case to prevent damage. The foldable design allows for compact storage.

Battery Care

To prolong battery life, avoid fully discharging the headphones frequently. If storing for an extended period, charge them to about 50% before storage.

TROUBLESHOOTING

If you encounter issues with your Bose QuietComfort Headphones, try the following solutions:

Problem	Possible Solution
Headphones not powering on	Ensure the battery is charged. Connect to a power source and allow a few minutes for charging before attempting to power on.
Cannot pair via Bluetooth	Ensure headphones are in pairing mode (blinking blue light). Turn off and on Bluetooth on your device. Forget the device from your device's Bluetooth list and try pairing again. Move closer to your device.
No sound or poor sound quality	Check volume levels on both headphones and connected device. Ensure the audio cable is fully inserted if using wired connection. Try another audio source or device.
Noise cancellation not effective	Ensure earcups are properly sealed around your ears. Check the noise cancellation mode setting in the Bose Music app.
Headphones not responding	Perform a soft reset by connecting the headphones to a power source for 5 seconds, then disconnecting. If issues persist, refer to the Bose Music app for advanced troubleshooting or contact support.

For further assistance, consult the Bose Music app or visit the official Bose support website.

SPECIFICATIONS

Feature	Detail
Model Name	Bose QuietComfort Headphones, Twilight Blue - Limited Edition Color
Model Number	884367-1600
Noise Control	Active Noise Cancellation
Connectivity Technology	Wireless, Wired
Wireless Communication Technology	Bluetooth 5.1
Bluetooth Range	30 Feet
Battery Life	Up to 24 Hours
Charging Time	2.5 Hours
Headphones Jack	3.5 mm Jack
Ear Placement	Over Ear

Feature	Detail
Control Type	Touch Control
Item Weight	240 Grams (8.5 ounces)
Product Dimensions	3.15 x 6.18 x 7.68 inches
Material	Leather, Plastic (Carrying Case: Synthetic)
Frequency Range	20 Hz - 20 KHz
Impedance	32 Ohm
Water Resistance Level	Not Water Resistant
UPC	017817860239

WARRANTY AND SUPPORT

Warranty Information

Bose products typically come with a limited warranty covering manufacturing defects. Please refer to the warranty card included in your product packaging or visit the official Bose website for specific warranty terms and conditions applicable to your region and product model.

Customer Support

For technical support, product registration, FAQs, and software updates, please utilize the Bose Music app or visit the Bose support website:

- **Bose Music App:** Download from your device's app store for personalized settings and direct support access.
- **Bose Support Website:** www.bose.com/support (Note: This is a generic link, actual support page may vary by region).

Keeping your product software up-to-date through the Bose Music app ensures optimal performance and access to the latest features.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question