

Haofy RG10B(D)/BGEF

Haofy Universal Air Conditioner Remote Control User Manual

Model: RG10B(D)/BGEF

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Haofy Universal Air Conditioner Remote Control. This remote is designed as a replacement for various air conditioner models, including RG10B(D)/BGEF, RG10A, and RG10B10. It offers a convenient solution for replacing damaged or lost controllers.

Key features include:

- **Ideal Choice:** Simply insert batteries to start using this air conditioner remote controller, making it an ideal choice when your original remote needs replacement, ensuring a seamless transition and restoring your air conditioner's functionality.
- **Convenient Functions:** The user-friendly design includes convenient access to all original functions, making it simple and effortless to control your air conditioner for optimal comfort.
- **Easy Replacement:** Crafted with high strength ABS material, this remote control offers a convenient solution to replace damaged or old controllers for various air conditioner models like RG10B, RG10A, and RG10B10.
- **Restored Functionality:** This air conditioning remote control serves as a replacement for broken or lost remotes, swiftly restoring your air conditioner's functionality without any hassle.
- **High Compatibility:** Compatible with a wide range of air conditioners from renowned brands, ensuring versatility and convenience in controlling your cooling system.

SETUP

Battery Installation

The remote control requires two AAA batteries (not included).

1. Open the battery compartment cover on the back of the remote.
2. Insert two AAA batteries, ensuring correct polarity (+/-).
3. Close the battery compartment cover.



Rear view of the remote control with the battery compartment open, illustrating where to insert AAA batteries.

Initial Setup / Pairing

This universal remote control is designed to be compatible with a wide range of air conditioner brands. Follow these steps to pair it with your unit:

1. Manual Code Input:

- Refer to the provided code list (usually found in the packaging or a separate leaflet) to find the code for your air conditioner brand.
- Press and hold the **"SET"** button for 5 seconds until the code indicator on the remote's screen starts flashing.
- Use the **"TEMP+"** or **"TEMP-"** buttons to input the 3-digit code for your brand.
- Press **"OK"** to confirm. Test the remote's functions. If it doesn't work, try the next code for your brand.

2. Automatic Search:

- Aim the remote at your air conditioner.
- Press and hold the **"SELECT"** button for 5 seconds. The remote will begin searching for the correct code, indicated by a flashing code on the screen and a "BUZZER" sound.
- Once your air conditioner responds (e.g., turns on/off, changes mode), immediately release the **"SELECT"** button.
- Test all functions. If it works, the setup is complete. If not, repeat the automatic search process.







Front view of the Haofy Universal AC Remote Control, showing the display and main function buttons.

OPERATING INSTRUCTIONS

Basic Functions

- **Power (ON/OFF):** Press the **"ON/OFF"** button to turn the air conditioner on or off.
- **Mode Selection:** Press the **"MODE"** button repeatedly to cycle through available modes (e.g., Cool, Heat, Dry, Fan, Auto).
- **Temperature Adjustment:** Use the **"TEMP+"** and **"TEMP-"** buttons to increase or decrease the desired temperature.
- **Fan Speed:** Press the **"FAN SPEED"** button to adjust the fan speed (e.g., Low, Medium, High, Auto).
- **Swing:** Press the **"SWING"** button to activate or deactivate the automatic louver swing function.

Advanced Functions

- **Timer ON/OFF:**
 - To set the timer for the unit to turn on, press **"TIMER ON"**. The display will show a clock symbol. Use **"TEMP+"** or **"TEMP-"** to adjust the desired ON time. Press **"OK"** to confirm.
 - To set the timer for the unit to turn off, press **"TIMER OFF"**. Use **"TEMP+"** or **"TEMP-"** to adjust the desired OFF time. Press **"OK"** to confirm.
 - To cancel a set timer, press **"TIMER ON/OFF"** again.
- **Sleep Mode:** Press the **"SLEEP"** button to activate a quiet, energy-saving mode, often with gradual temperature adjustments.
- **Turbo Mode:** Press the **"TURBO"** button for rapid cooling or heating.
- **LED Display:** Press the **"LED DISPLAY"** button to turn the display light on or off.
- **Clean Function:** Press the **"CLEAN"** button to activate the self-cleaning function (if supported by your AC unit).
- **Reset/Lock:** Press **"RESET LOCK"** to lock the remote settings or reset them.

Your browser does not support the video tag.

This video demonstrates the basic functions and compatibility of the Haofy Universal AC Remote Control with Midea AC units, showing how to power on, change modes, and adjust settings.

MAINTENANCE

Cleaning the Remote

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.

Battery Replacement

Replace batteries when the remote's display becomes dim or unresponsive. Always replace both batteries at the same time with new AAA batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Remote not responding	Dead batteries	Replace batteries with new AAA batteries.
Remote not responding	Incorrect code	Re-perform the initial setup/pairing process.
Remote not responding	Obstruction between remote and AC unit	Ensure a clear line of sight between the remote and the AC unit's receiver.
Limited range	Weak batteries	Replace batteries.
Limited range	Distance too far	Operate the remote within 8 meters of the AC unit.
AC unit not performing desired function	AC unit does not support the function	Some advanced functions may not be supported by all AC models. Refer to your AC unit's manual.

SPECIFICATIONS

- **Brand:** Haofy
- **Model Name:** Haofyxvqstimbah (Compatible with RG10B(D)/BGEF, RG10A, RG10B10 series)
- **Material:** High Strength ABS
- **Power Supply:** 2 x AAA Batteries (Not Included)
- **Controllable Distance:** Less than 8 meters
- **Product Dimensions:** 7.87"D x 1.96"W x 1.18"H
- **Special Feature:** Easy Access to Original Functions
- **Compatibility:** Universal replacement for various AC models and brands.

WARRANTY AND SUPPORT

Warranty Information

This product comes with a standard manufacturer's warranty. Please retain your purchase receipt for warranty claims. For specific warranty details, refer to the documentation provided at the time of purchase or contact Haofy customer support.

Customer Support

For further assistance or inquiries, please contact Haofy customer support through the retailer's platform or the official Haofy website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question