TCL 40V5C

TCL V5C Series Full HD Smart QLED TV User Manual

Model: 40V5C

1. Introduction

This user manual provides comprehensive instructions for the setup, operation, and maintenance of your TCL V5C Series Full HD Smart QLED TV. Please read this manual thoroughly before using your television to ensure proper and safe operation. Keep this manual for future reference.



Figure 1.1: Front view of the TCL 40V5C QLED TV.

2. Package Contents

Before proceeding with the setup, verify that all components are present in the packaging:

- 1N LED TV
- 1N Audio Cable
- 1N Stand
- 1N Power cord
- 1N Remote Control
- 2N Batteries (AAA)




Figure 2.1: Illustration of items included in the product box.

3. Setup

3.1 Assembling the Stand

If you are not wall-mounting the television, attach the included stand to the bottom of the TV. Ensure the stand is securely fastened with the provided screws to prevent instability.

3.2 Connecting Peripherals

Connect your external devices such as set-top boxes, gaming consoles, or sound systems to the appropriate ports on the TV. Refer to the port diagram below for connection points.



Figure 3.1: Rear view of the TCL TV showing various input/output ports.

1. **USB 2.0 Port:** For connecting USB storage devices.
2. **LAN Port:** For wired internet connection.
3. **ANTENNA/CABLE INPUT:** For connecting an antenna or cable TV signal.
4. **SATELLITE INPUT:** For connecting a satellite dish.
5. **DIGITAL AUDIO OUT (OPTICAL):** For connecting to external audio systems.
6. **HDMI 1 Port:** For connecting HDMI-enabled devices.
7. **HDMI 2 (ARC) Port:** For connecting HDMI-enabled devices, supports Audio Return Channel.
8. **AV IN Adapter:** For connecting older devices using an AV cable.
9. **HEADPHONE Port:** For connecting headphones.

3.3 Power Connection

Connect the power cord to the TV and then to a suitable power outlet. The TV is designed to operate on 240 Volts AC power.

4. Operating Instructions

4.1 Initial Setup and Google TV

Upon first power-on, the TV will guide you through the initial setup process, including language selection, network connection (Wi-Fi 4 supported), and Google account sign-in. The Google TV operating system provides a personalized experience, aggregating content from various streaming services.




Figure 4.1: The Google TV interface displaying available applications.

4.2 Remote Control Usage

The smart remote control features dedicated hotkeys for quick access to popular streaming services and a built-in microphone for Google Assistant voice commands. Ensure the included AAA batteries are inserted correctly.



Figure 4.2: The smart remote control for the TCL V5C TV.

4.3 Display and Audio Features

The TCL V5C TV features a Full HD QLED panel with HDR 10 support, offering vibrant colors and enhanced contrast. The 24 Watts Dolby Audio output provides an immersive sound experience. Multiple viewing modes are available to optimize picture and sound for different content types (e.g., Game Mode, Sports Mode, Movie Mode).



Figure 4.3: QLED technology provides vivid and accurate colors.




Figure 4.4: Dolby Audio enhances the sound experience.



Figure 4.5: HDR 10 provides enhanced detail and contrast.

5. Maintenance

5.1 Cleaning the Screen

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals or abrasive materials.

5.2 General Cleaning

Wipe the TV's frame and stand with a dry, soft cloth. Ensure all vents are free from dust accumulation to maintain proper airflow and prevent overheating.

6. Troubleshooting

This section addresses common issues you might encounter. If the problem persists, please contact customer support.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No Power	Power cord disconnected; Power outlet issue.	Ensure power cord is securely connected. Check if the power outlet is working by plugging in another device.
No Signal	Incorrect input source selected; Loose cable connection.	Press the "Source" button on the remote to select the correct input. Check all cable connections (HDMI, Antenna, etc.).
Remote Control Not Responding	Dead batteries; Obstruction between remote and TV.	Replace batteries with new AAA batteries. Ensure no objects are blocking the remote's signal path to the TV's IR receiver.
Picture Quality Issues (e.g., blurry, distorted)	Low-quality source; Incorrect display settings.	Ensure the input source is high-definition. Adjust picture settings (brightness, contrast, sharpness) in the TV menu.
Audio Issues (e.g., no sound, distorted sound)	Volume too low/muted; External audio system issues.	Increase volume and check if TV is muted. If using external audio, ensure it's powered on and correctly connected.

7. Specifications

Feature	Detail
Brand	TCL
Model	40V5C
Screen Size	40 Inches (101 cms)
Resolution	Full HD (1920 x 1080)
Display Technology	QLED, HDR 10
Refresh Rate	60 Hertz
Operating System	Google TV
Processor	64-bit Quad Core Processor
RAM	1 GB
Internal Storage	8 GB
Audio Output	24 Watts, Dolby Audio
Connectivity	2 HDMI Ports, 1 USB Port, 1 LAN, Wi-Fi 4, Bluetooth
Viewing Angle	178 Degrees
Power Consumption (On-mode)	80 Watts
Annual Energy Consumption	95 kWh
Product Dimensions (with stand)	89.2 x 18.4 x 55.8 cm
Item Weight	4.58 kg




Figure 7.1: Physical dimensions and weight of the TCL 40V5C TV.




Figure 7.2: Energy efficiency label for the TCL 40V5C TV.

8. Warranty and Support

The TCL V5C Series TV comes with a**1-year warranty** provided by the manufacturer from the date of purchase. To avail warranty services, please retain your purchase invoice.

For technical support or service requests, please contact TCL India customer service. User manuals and additional product details can often be found on the official TCL website.

Manufacturer: TTE ELECTRONICS INDIA PRIVATE LIMITED

Country of Origin: India

© 2025 TCL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question