

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [vidaXL](#) /

› [vidaXL TV Cabinet Instruction Manual - Model 862576](#)

vidaXL 862576

vidaXL TV Cabinet Instruction Manual

Model: 862576

INTRODUCTION

Thank you for purchasing the vidaXL TV Cabinet, Model 862576. This manual provides detailed instructions for the safe assembly, installation, operation, and maintenance of your new wall-mounted storage unit. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- Always assemble the product on a clean, flat, and soft surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- This cabinet is designed for wall mounting. Improper installation can lead to injury or damage. Seek professional assistance if you are unsure about wall mounting procedures.
- Use appropriate wall-mounting hardware for your specific wall type (e.g., drywall, concrete, wood studs). Wall-mounting hardware is **not included** with this product.
- Do not overload the cabinet. Refer to the 'Specifications' section for weight limits.
- Keep small parts and packaging materials away from children during assembly.

PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- Cabinet panels (top, bottom, sides, back, door)
- Hinges and associated screws
- Assembly fasteners (dowels, cam locks, screws)
- Wall mounting brackets (pre-attached or to be attached to the cabinet)
- Instruction manual

Note: Wall plugs and screws for mounting the cabinet to your wall are **not supplied** and must be purchased separately based on your wall material.

SETUP AND ASSEMBLY

Assembly is required for this product. Follow these steps carefully:

- 1. Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface. Refer to the parts list in your included assembly diagram to identify each piece.
- 2. Assemble the Cabinet Frame:** Connect the side panels to the top and bottom panels using the provided dowels and cam locks/screws. Ensure all connections are secure.
- 3. Attach the Back Panel:** Slide or fasten the back panel into place. This panel provides structural integrity.
- 4. Install Hinges and Door:** Attach the hinges to the cabinet door and then to the cabinet frame. Adjust the hinges as needed to ensure the door opens and closes smoothly and aligns correctly.



Image: The cabinet with its door open, revealing the interior storage compartment and the installed hinges.



Image: A detailed view of one of the cabinet's metal hinges, showing its construction and attachment points.

Wall Mounting Instructions

This cabinet is designed to be wall-mounted. Proper installation is crucial for safety and stability.

- 1. Determine Mounting Location:** Choose a suitable wall location, ensuring it can support the weight of the cabinet and its contents. Avoid mounting over electrical wires or plumbing.
- 2. Mark Drilling Points:** Hold the assembled cabinet against the wall at the desired height. Use a level to ensure it is straight. Mark the positions for the wall mounting screws through the pre-attached brackets on the back of the cabinet.
- 3. Drill Pilot Holes:** Using an appropriate drill bit for your wall type and chosen wall plugs/screws, drill pilot holes at the marked positions.
- 4. Insert Wall Plugs:** Insert the appropriate wall plugs into the drilled holes.
- 5. Mount the Cabinet:** Align the cabinet's mounting brackets with the wall plugs and secure the cabinet to the wall using suitable screws. Tighten securely, but do not overtighten.
- 6. Verify Stability:** Gently pull on the cabinet to ensure it is firmly attached to the wall and does not wobble.



Image: The back of the cabinet, illustrating the design of the integrated mounting brackets used for wall installation.



Image: The assembled vidaXL TV Cabinet, wall-mounted in a living space, showcasing its minimalist design and functional placement.

OPERATING INSTRUCTIONS

This TV cabinet is designed for storage and display. To operate:

- **Door Operation:** Gently pull the door to open and push to close. Avoid forcing the door, as this may damage the hinges.
- **Storage:** Utilize the internal compartment for storing media accessories, remote controls, or other small items.
- **Display Surface:** The top surface can be used to display decorative items or small electronic devices. Ensure items placed on top do not exceed the cabinet's weight capacity.

CARE AND MAINTENANCE

To ensure the longevity and appearance of your vidaXL TV Cabinet, follow these care instructions:

- **Cleaning:** Wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the engineered wood finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage.

- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Periodic Checks:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary. Verify the wall mounting remains secure.

TROUBLESHOOTING

Issue: Cabinet feels unstable after wall mounting.

Solution: Ensure that the wall plugs and screws used are appropriate for your wall type and are securely fastened. Re-check all connections between cabinet panels. If instability persists, consult a professional for safe installation.

Issue: Door does not close properly or is misaligned.

Solution: Adjust the hinges. Most hinges allow for minor adjustments in three directions (up/down, left/right, in/out) using a screwdriver. Refer to the hinge manufacturer's instructions if available, or gently adjust screws until alignment is achieved.

Issue: Missing parts or damaged components upon arrival.

Solution: Do not proceed with assembly. Contact vidaXL customer support immediately for assistance and replacement parts.

SPECIFICATIONS

Product Dimensions and Details

Feature	Detail
Model Number	862576
Material	Engineered Wood
Overall Dimensions (L x W x H)	11.81 x 11.81 x 11.81 inches (30 x 30 x 30 cm)
Item Weight	12.21 pounds (5.55 kg)
Assembly Required	Yes
Mounting Type	Wall Mounted




Image: A technical drawing illustrating the precise dimensions of the cabinet, including width, depth, and height in both centimeters and inches.

WARRANTY

vidaXL products are manufactured to high-quality standards. For specific warranty information regarding your TV Cabinet Model 862576, please refer to the warranty card included in your package or visit the official vidaXL website. The warranty typically covers manufacturing defects under normal use.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact vidaXL customer support. You can typically find contact information on the vidaXL website or on your purchase documentation.

For online support, visit: www.vidaxl.com