Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bright Starts 17228-000

Bright Starts Just for Sun Flashlight Toy User Manual

Model: 17228-000

Introduction

The Bright Starts Just for Sun Flashlight Toy is designed to engage infants aged 6 months and up with interactive features. This toy includes a glowing dome, animal sounds, rattling beads, and a mirror to support sensory development and cause-and-effect learning. It is compact for both home use and travel.



Image: A baby interacts with the glowing Just for Sun Flashlight Toy.

Setup

Battery Installation

1. Locate the battery compartment at the base of the flashlight toy.
2. Using a Phillips head screwdriver, loosen the screw on the battery compartment cover.
3. Remove the cover.
4. Insert two (2) new AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
5. Replace the battery compartment cover and tighten the screw securely.

Note: Demo batteries are included but should be replaced with new batteries for optimal performance.

Operating Instructions

Activating Sounds and Lights

- To activate the lights and animal sounds, rotate the cheerful sunshine dome located at the top of the toy. Each rotation will cycle through various animal sounds (cat, bear, frog, monkey, bird, lion) and melodies, accompanied by glowing lights.



Image: Turning the dome activates over 30 melodies and sounds.

Using the Rainstick Rattle

- Shake the toy gently to hear the colorful beads inside rattle and fall, mimicking the sound of raindrops. This feature provides auditory stimulation and encourages motor skill development.



Image: Shaking the toy produces rattling sounds from the beads.

Mirror Feature

- A mirror is integrated into the bottom of the toy. This mirror encourages self-recognition and visual engagement during play.



Image: The mirror on the toy's base encourages self-recognition.

Portability

- The compact size of the toy allows for easy transport, fitting into most diaper bags for on-the-go entertainment.



Image: The toy is designed for easy transport.

Official Product Video

Your browser does not support the video tag.

Video: An official demonstration of the Bright Starts Just for Sun Toy's features and functionality.

Maintenance

Cleaning

- Wipe the toy clean with a damp cloth and mild soap.
- Do not immerse the toy in water.
- Air dry thoroughly before storage or next use.

Storage

- Store the toy in a cool, dry place away from direct sunlight.
- Remove batteries if the toy will not be used for an extended period to prevent leakage.

Troubleshooting

No Sound or Lights

- **Check Batteries:** Ensure that fresh AAA batteries are correctly installed in the compartment. Replace old or depleted batteries.
- **Battery Compartment:** Verify that the battery compartment cover is securely fastened.
- **Activation:** Confirm that the sunshine dome is being rotated sufficiently to trigger the sounds and lights.

Rattle Beads Not Moving

- **Shake Motion:** Ensure the toy is being shaken with enough motion for the beads to move freely.
- **Obstruction:** Inspect the clear rainstick section for any foreign objects that might be obstructing the beads.

Specifications

Brand	Bright Starts
Model Number	17228-000
Recommended Age	6 to 36 Months
Dimensions (L x W x H)	7"L x 3.8"W (approximately 6.97 x 3.82 x 3.82 inches)
Item Weight	0.37 Pounds
Material Type	Plastic
Power Source	Battery (Disposable)
Batteries Required	2 AAA batteries
Assembly Required	No
Educational Objective	Develop self-awareness and understanding of cause-and-effect through interactive play



Image: Product dimensions for the Just for Sun Flashlight Toy.

Warranty

This product is covered by a limited warranty against manufacturing defects. For specific warranty details and duration, please refer to the packaging or contact the manufacturer directly. Keep your proof of purchase for warranty claims.

Support

For further assistance, questions, or to report any issues with your Bright Starts Just for Sun Flashlight Toy, please visit the official Bright Starts website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.
Online resources and FAQs may also be available to help with common inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZJ2ZPTF

More documents and user manuals: **https://manuals.plus/**