Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coleman 1453187

Coleman Beach Shade Canopy Tent Instruction Manual

Model: 1453187 | Brand: Coleman

1. Product Overview

The Coleman Beach Shade Canopy Tent provides portable sun protection and privacy for various outdoor activities. Designed for quick setup, it features UVGuard material for UPF 50+ sun protection, an extended floor that zips up for privacy, and a rear window for ventilation. It is suitable for use at the beach, park, yard, or picnics.



Image 1.1: The Coleman Beach Shade Canopy Tent providing shade on a sunny beach.

2. Included Components

Verify that all components are present before assembly:

- Carry Bag
- Coleman Road Trip Beach Shade (Tent Fabric)
- Extra-Long Stakes
- Floor Mat (integrated with tent)
- Handy Dry Line
- Sandbags
- User Manual (this document)

3. Safety Information

Please read and follow these safety guidelines to ensure safe use of your Coleman Beach Shade Canopy Tent:

- Always stake down and secure guy lines when using the tent to prevent it from blowing away in windy conditions.
- Do not use near open flames or heat sources, as the fabric may be flammable.
- Keep away from direct sunlight for extended periods to prevent excessive heat buildup inside the tent.
- Always supervise children when they are using or playing near the tent.

4. Setup Instructions

The Coleman Beach Shade Canopy Tent is designed for quick and easy setup, typically within 5 minutes. Follow these steps:

1. **Unpack the Tent:** Remove the tent and all components from the carry bag. Lay the tent fabric flat on the ground.
2. **Assemble Poles:** The tent uses lightweight, shock-corded fiberglass poles. Connect the pole sections until they are fully assembled.
3. **Insert Poles:** Carefully slide the assembled poles through the fabric sleeves on the tent. Ensure the poles are fully seated in the corner grommets.
4. **Raise the Tent:** Lift the tent structure and secure the poles into their designated attachment points.
5. **Secure with Stakes and Guy Lines:** Use the included extra-long stakes to anchor the tent to the ground. Attach and tension the pre-attached guy lines for additional stability, especially in windy conditions.
6. **Fill Sandbags (Optional):** For stake-free stability on sand, fill the provided sandbags and place them at the base of the tent.



Image 4.1: Illustration of the pinch-free setup mechanism for easy pole extension.

Video 4.2: A demonstration of setting up the Coleman beach shade canopy tent. This video shows the process of unfolding the tent and inserting the poles to erect the structure, highlighting its ease of assembly.

5. Operating Instructions

Maximize your comfort and privacy with the tent's features:

- **Privacy Wall:** The extended front floor can be zipped up to create a private changing room or additional wind block.



Image 5.1: The extended front floor zipped up for privacy.

- **Ventilation:** Unzip the back window for improved airflow and to reduce heat buildup inside the tent.



Image 5.2: Interior view highlighting the rear mesh window for ventilation.

- **Dry Line:** Utilize the included dry line to hang wet bathing suits or towels.



Image 5.3: The internal dry line for hanging items.

- **Storage Pockets:** Mesh pockets are located inside for storing small gear, water bottles, or personal items.

Video 5.4: This video showcases the versatility of the Coleman Beach Shade Canopy Tent, demonstrating its use for various occasions and highlighting features like the privacy wall and ventilation options.

6. Maintenance

Proper care will extend the life of your beach shade:

- **Cleaning:** Clean the tent fabric with a mild soap solution and a soft cloth. Do not use harsh detergents or abrasive cleaners. Rinse thoroughly with water.
- **Drying:** Always ensure the tent is completely dry before packing it away to prevent mildew and odor. Air dry in a shaded area.
- **Storage:** Store the tent in its carry bag in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Pole Care:** Inspect poles for damage before and after each use. Clean any dirt or sand from pole sections.

7. Troubleshooting

If you encounter issues with your beach shade, consider the following:

- **Tent Instability:** Ensure all stakes are firmly in the ground and guy lines are properly tensioned. If on sand, ensure sandbags are filled and positioned correctly.
- **Difficulty with Pole Assembly/Disassembly:** Check that pole sections are aligned correctly and not bent. Avoid forcing connections.
- **Excessive Heat Inside:** Ensure the rear window is unzipped for maximum ventilation. Consider repositioning the tent to optimize shade.

8. Specifications

Feature	Detail
Brand	Coleman
Model Number	1453187
Material	Fiberglass (Frame), Heavy-duty Polyester (Canopy)
Color	Green
Item Weight	6.17 Pounds
Dimensions (L x W x H)	7 ft. 6 in. x 4 ft. 5 in. x 4 ft. 9 in. (2.3m x 1.3m x 1.4m)
Floor Area	33.75 Square Feet
UV Protection	UPF 50+ (UVGuard material)
Water Resistance Level	Not Water Resistant (provides shelter from light rain)
Required Assembly	Yes

9. Warranty and Support

This Coleman Beach Shade Canopy Tent comes with a **1-year limited warranty**. Products sold by Designed For Outdoors are guaranteed to be free of defects in workmanship and materials for up to one year after the purchase date. Please note that prolonged exposure to weather conditions including snow, rain, and humidity are not covered under this warranty.
For warranty claims or product support, please contact Coleman customer service directly. Refer to the contact information provided on the product packaging or the official Coleman website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZL3JXJ5

More documents and user manuals: **https://manuals.plus/**