Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WOPET B0DZM8KXH3

WOPET Automatic Cat Feeder User Manual

Model: B0DZM8KXH3 | Brand: WOPET

Introduction

Thank you for choosing the WOPET Automatic Cat Feeder. This device is designed to simplify pet feeding, offering programmable meal times and portion control for up to two cats or small dogs. With its dual power supply and user-friendly features, you can ensure your pets are fed consistently, even when you're away.



Image: The WOPET Automatic Cat Feeder, a black unit with a clear food level indicator and two stainless steel bowls at the base, filled with kibble.

Key Features

- **Dual Pet Feeding:** Effortlessly feed two cats or dogs simultaneously with two stainless steel bowls.
- **Programmable Meals:** Schedule up to 6 meals daily with adjustable portion sizes (1-20 portions, 12g per portion).
- **Food Freshness:** 4L/17 cups capacity, suitable for dry food (2-12mm kibble). Features a built-in desiccant bag and triple-seal system.
- **Personalized Meal Call:** Record a 10-second voice message to call your pets to eat.
- **Easy to Clean:** Removable tank lid, tank, tank base, and food bowls for thorough cleaning.

- **Dual Power Supply:** Operates on DC power supply with backup support from 3 alkaline D batteries (not included).
- **User-Friendly Interface:** Simple setup via LCD screen and manual feeding button.
- **Secure Lid Lock:** Prevents curious pets from accessing food.

Package Contents

Please check the package to ensure all items are present:

- WOPET Automatic Pet Feeder Unit
- Stainless Steel Food Bowls (x2)
- Food Bowl Connector
- Meal Splitter
- DC Power Adapter
- Desiccant Bag (pre-installed or separate)
- User Manual (this document)

Setup Guide

1. **Unpack and Assemble:**
   Carefully remove all components from the packaging. Rotate the tank lid right to remove it from the main body. Take out any inside accessories.



Image: A six-step visual guide showing how to assemble the feeder, including rotating the tank, installing the desiccant, attaching bowls, and connecting power.

2. **Install Desiccant Bag:**
   If not pre-installed, twist the lid to open the desiccant compartment and insert the desiccant bag. This helps maintain food freshness.
3. **Attach Bowls:**
   Assemble the two trays in place and connect them using the bowl connector. Then, install the stainless steel bowls into the assembled base.
4. **Fill with Food:**
   Pour dry kibble (recommended size 2-12mm) into the food tank. Do not overfill. The transparent window allows for easy monitoring of food levels.
5. **Connect Power:**

Plug the DC power adapter into the feeder and a wall outlet. For backup power, insert 3 alkaline D batteries (not included) into the battery compartment at the bottom of the unit. This ensures continuous feeding during power outages.



Image: The WOPET feeder connected to a wall outlet, with icons illustrating the 5V DC adapter and 3x D batteries (not included) as power sources.

Operating Instructions

LCD Screen Setup

The LCD screen allows for quick and easy setup of feeding schedules and other settings.



Image: A close-up of the WOPET feeder's LCD screen, showing time (20:05) and meal indicators (1-6), along with control buttons for setting and recording.

Setting Feeding Schedule

You can program up to 6 meals per day. Each meal can have a portion size from 1 to 20 portions (approximately 12g per portion).

- Use the control buttons on the LCD panel to navigate and set meal times and portion sizes.
- Refer to the recommended daily feeding portions table for guidance.



Image: The WOPET feeder in a living room setting, with an overlay showing a detailed feeding schedule example (e.g., 5:30 AM - 4 portions, 8:30 AM - 4 portions, etc.).

Personalized Meal Call

Record a 10-second voice message that will play at each scheduled meal time. This helps to call your pets to their food.

- Press and hold the record button on the LCD panel to begin recording your message.
- You can set the recording to play 0-2 times per meal.




Image: A WOPET feeder next to a small dog, with a speech bubble indicating a personalized voice message: "Hey, Baby it's time to eat!".

Manual Feeding

Press the manual feeding button on the LCD panel for instant food dispensing outside of the scheduled times. This is useful for extra snacks or testing.

App Control (If applicable)

For advanced control and monitoring, download the WOPET Life app. The feeder supports both 5GHz and 2.4GHz Wi-Fi networks for seamless connectivity.

- Follow the in-app instructions to connect your feeder to your home Wi-Fi network.
- Manage feeding plans, view feed records, and receive smart push notifications directly on your smartphone.

Maintenance & Cleaning

Regular cleaning ensures hygiene and extends the life of your feeder. The detachable design makes cleaning easy.




Image: Exploded view of the WOPET feeder components, including the tank lid, tank, food bowls, and base, with water splashes indicating ease of cleaning.

1. **Disassembly:**
   Unplug the feeder. Remove the food bowls and the food tank by rotating the lid and tank body. The meal splitter and bowl connector can also be detached.
2. **Cleaning:**
   Wash the stainless steel bowls, food tank, and other removable parts with mild soap and water. Rinse thoroughly and dry completely before reassembly.
   Do not immerse the main feeder unit (with electronic components) in water. Wipe it clean with a damp cloth.
3. **Desiccant Bag:**
   Replace the desiccant bag every 1-2 months, or as needed, to maintain food freshness.
4. **Reassembly:**
   Ensure all parts are dry. Reassemble the feeder by following the setup steps in reverse order.

Troubleshooting

Problem	Possible Cause	Solution
Feeder not dispensing food.	Food tank empty; kibble size too large; food jammed; dispenser clogged.	Refill food tank; ensure kibble is 2-12mm; clear any jams; clean dispenser mechanism.
Wi-Fi connection issues.	Incorrect Wi-Fi password; feeder too far from router; 5GHz/2.4GHz conflict.	Re-enter password; move feeder closer to router; ensure router supports 2.4GHz or use appropriate band.

Problem	Possible Cause	Solution
Pets knocking over bowls/feeder.	Feeder is too light; bowls not securely attached.	Ensure bowls are properly seated; consider placing feeder against a wall or on a non-slip mat for stability.
Voice recording not playing.	Recording not saved; volume too low.	Re-record and ensure it saves; check volume settings on the feeder.

Specifications

- **Brand:** WOPET
- **Model:** B0DZM8KXH3
- **Capacity:** 4L / 17 cups
- **Material:** BPA free
- **Kibble Size:** 2-12mm dry food only
- **Portion Size:** 1-20 portions (approx. 12g per portion)
- **Meals per Day:** Up to 6
- **Voice Recording:** 10 seconds
- **Power Supply:** DC 5V Adapter (included), 3 x D alkaline batteries (not included)
- **Dimensions:** 7.87 x 7.48 x 13 inches
- **Item Weight:** 3.76 pounds (1.71 Kilograms)
- **Connectivity:** Supports 5GHz & 2.4GHz Wi-Fi (for app control models)

Safety Information

- For indoor use only.
- Keep out of reach of children and pets when not in use or during assembly/disassembly.
- Use only dry pet food. Do not use wet, canned, or moist food.
- Ensure the power adapter cable is not chewed by pets.
- Do not immerse the main unit in water.
- Dispose of batteries properly according to local regulations.

Warranty and Support

WOPET provides a standard warranty for this product. For detailed warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official WOPET website.
For online support, you may also visit the WOPET Store on Amazon.

© 2025 WOPET. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZM8KXH3

More documents and user manuals: **https://manuals.plus/**