

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Fluted Tall Dresser 5 Drawer Instruction Manual (Model FD0WW5D)

VINGLI FD0WW5D

VINGLI Fluted Tall Dresser 5 Drawer User Manual

Model: FD0WW5D

1. INTRODUCTION

Thank you for choosing the VINGLI Fluted Tall Dresser 5 Drawer. This manual provides essential information for the safe assembly, operation, and maintenance of your new dresser. Please read these instructions carefully before beginning assembly and retain them for future reference.

This dresser features a walnut finish, fluted drawer fronts, and five full-extension drawers with soft-close slides. Its dimensions are approximately 15.59"D x 23.66"W x 44.88"H.

2. SAFETY INFORMATION

WARNING: Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Always use the tip-over restraint provided with the product.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

Ensure all hardware is securely tightened before use. Periodically check and re-tighten hardware as needed. Keep small parts away from children during assembly.



This image illustrates the metal anti-tipping bracket, anti-slip foot pads, and mending wedges included for enhanced stability and safety.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Dresser Panels (Top, Bottom, Sides, Back)
- Drawer Panels (Fronts, Sides, Backs, Bottoms)
- Hardware Bag (screws, dowels, cam locks, drawer slides, handles, anti-tipping kit)
- Instruction Manual

Specification



An overview of the dresser's dimensions and weight capacities for the top surface (130 lbs) and each drawer (30 lbs).

4. SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended to have two people for assembly. Follow the detailed instructions provided in the included assembly manual. Ensure you have a clear, spacious area for assembly.

1. **Prepare Components:** Unpack all parts and lay them out on a soft, clean surface to prevent scratches. Identify each part using the labels in the assembly manual.

2. **Assemble Frame:** Attach the side panels to the bottom and top panels using the provided hardware. Ensure all connections are secure.
3. **Install Drawer Slides:** Secure the drawer slides to the inner sides of the dresser frame and to the drawer boxes according to the manual.
4. **Assemble Drawers:** Construct each drawer box, then attach the fluted drawer fronts and handles.
5. **Insert Drawers:** Carefully slide the assembled drawers into the dresser frame.
6. **Attach Anti-Tipping Kit:** Securely fasten the anti-tipping bracket to the back of the dresser and to a wall stud using the provided hardware. This step is crucial for safety.

Refer to the schematic instructions in the separate assembly manual for visual guidance on each step.



This image highlights the 13.2-inch depth full-extension drawer and the metal silent drawer slides, ensuring smooth operation.

1.57" Thickened Support Base

Four 1.42" thick wooden legs

Four 1.57" support wood bars

One 1.57" adjustable support leg




A diagram illustrating the 1.57-inch thickened support base, including four 1.42-inch wooden legs, four 1.57-inch support bars, and an extra 1.57-inch middle leg for stability.

5. OPERATING INSTRUCTIONS

The VINGLI Fluted Tall Dresser is designed for storing clothing and other personal items. Each of the five drawers features full-extension, soft-close slides for smooth and quiet operation.

- **Opening Drawers:** Gently pull the glossy metal handle to open a drawer. The full-extension slides allow the drawer to extend completely for easy access to contents.
- **Closing Drawers:** Push the drawer gently until it engages with the soft-close mechanism. The drawer will then close slowly and silently.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 30 lbs per drawer and 220 lbs for the top surface. Overloading can damage the dresser and compromise stability.

Graceful & Timeless Look




Waveform Fluted Front

Enhanced Visual
Experience

Reflective Metal Gold Handle

Stylish Look &
Durable Use



This image showcases the waveform fluted front design and the reflective metal gold handle, contributing to the dresser's aesthetic.

6. MAINTENANCE

Proper care will ensure the longevity and appearance of your dresser.

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as this can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent water damage, especially on the waterproof surface.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Placement:** Avoid placing the dresser in direct sunlight or near heat sources, which can cause fading or warping.

7. TROUBLESHOOTING

If you encounter issues with your dresser, refer to the following common solutions:

- **Wobbly Dresser:** Ensure the dresser is placed on a level surface. Check that all assembly screws are tightened. If wobbling persists, verify the thickened support base is correctly installed and consider using the included mending wedges for additional stability.
- **Drawers Not Closing Smoothly:** Check if the drawer slides are properly aligned and free of obstructions. Ensure no items inside the drawer are preventing it from closing. Verify that the drawer slides are securely attached to both the drawer box and the dresser frame.
- **Drawer Sticking:** Inspect the drawer slides for any debris or damage. A small amount of silicone lubricant can be applied to the slides if friction is present, but avoid oil-based lubricants.
- **Tip-Over Concern:** Re-verify that the anti-tipping kit is correctly installed and securely anchored to a wall stud. Never place heavy items on top of the dresser that could cause it to become top-heavy.


8. SPECIFICATIONS

Brand	VINGLI
Model Number	FD0WW5D
Material	Engineered Wood
Finish Type	Veneer
Product Dimensions (D x W x H)	15.59" x 23.66" x 44.88"
Number of Drawers	5
Drawer Type	Metal Silent Full-Extension Drawer Slide
Item Weight	79.7 Pounds
Top Surface Weight Capacity	Up to 220 lbs
Drawer Weight Capacity	Up to 30 lbs per drawer
Required Assembly	Yes

Smooth Curved Edge

Ours

Polished Rounded Edge



Injury prevention from bumps/falls

Softer & eye-catching design



Others

Sharp Corner Design



Potential risk of bumping injury

Common & rigid appearance

This image compares the smooth, rounded edges of the VINGLI dresser, designed for injury prevention and a softer aesthetic, against typical sharp corner designs.

9. WARRANTY AND SUPPORT

This VINGLI dresser comes with a **1-Year Quality Warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use.

For warranty claims, missing parts, assembly assistance, or any other product-related inquiries, please contact VINGLI customer support. Have your model number (FD0WW5D) and purchase information ready when contacting support.

You can typically find contact information on the VINGLI brand store page or through your original retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DZNJQ42P>

More documents and user manuals: <https://manuals.plus/>