

DREAME R20 Pure

DREAME Cordless Stick Vacuum R20 Pure User Manual

Model: R20 Pure

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your DREAME Cordless Stick Vacuum R20 Pure. Please read this manual thoroughly before first use and retain it for future reference.

The DREAME R20 Pure is designed for versatile home cleaning, featuring powerful suction, advanced filtration, and intelligent illumination to ensure a comprehensive cleaning experience on various surfaces.

SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Do not use the vacuum cleaner outdoors or on wet surfaces.
- Do not allow the vacuum cleaner to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.

- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.).
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.
- Store your vacuum cleaner indoors in a cool, dry area.

WHAT'S IN THE BOX

Verify that all components are present before assembly.



What's in the Box

Image: All components included in the DREAME R20 Pure package. This includes the main vacuum body, extension rod, illumination multi-surface brush, motorized mini-brush, combination tool, wide combination tool, flexible adapter, battery pack, and wall mount.

- Main Body
- Extension Rod
- Illumination Multi-Surface Brush
- Motorized Mini-Brush
- Combination Tool
- Wide Combination Tool
- Flexible Adapter
- Battery Pack
- Wall Mount

ASSEMBLY AND SETUP

1. **Attach the Extension Rod:** Insert the extension rod into the main body until it clicks securely into place.
2. **Attach the Cleaning Head:** Connect the illumination multi-surface brush to the other end of the extension rod, ensuring it clicks firmly.
3. **Install the Battery:** Slide the battery pack into the slot on the main body until it locks. Ensure the battery is fully charged before first use.
4. **Charging:** Connect the charger to the battery or the wall mount. The LED screen will indicate charging status. A full charge provides up to 90 minutes of runtime.
5. **Wall Mount Installation (Optional):** Choose a suitable location near a power outlet. Secure the wall mount to the wall using the provided screws and anchors. This allows for convenient storage and charging.



Image: The DREAME R20 Pure vacuum cleaner fully assembled with its main components and various attachments displayed separately, ready for use.

OPERATING INSTRUCTIONS

Powering On/Off and Mode Selection

- **Power On:** Press the power button on the handle to start the vacuum.
- **Mode Selection:** Use the mode button on the LED screen to cycle through Eco, Med, and Turbo modes. The LED screen displays the current mode and battery level.
- **Power Off:** Press the power button again to turn off the vacuum.



LED Screen Displays Instant Cleaning Status

Image: A hand interacting with the LED screen of the DREAME R20 Pure, which clearly shows battery percentage and cleaning mode, allowing for easy monitoring and adjustment during operation.

Powerful Suction Performance

The DREAME R20 Pure is equipped with a high-speed motor delivering 150 AW of powerful suction, capable of effectively lifting dirt, dust, and debris from various surfaces.

425_w

Rated Power

150_{AW}

Suction Power



Powerful Cleaning with 150AW Suction Power

Image: An illustration detailing the powerful motor of the DREAME R20 Pure, indicating its 425W rated power and 150AW suction power, which contribute to its efficient cleaning capabilities.

Cleaning Surfaces

- **Hard Floors and Carpets:** The illumination multi-surface brush is suitable for both hard floors and carpets. The Celeste LED lights on the brush head illuminate dust and debris, making it easier to clean dark areas and under furniture.
- **Targeted Cleaning:** For specific areas, detach the extension rod and attach the appropriate accessory directly to the main body.

16x Dust Revealing



Multi-Surface Cleaning with Innovative CelesTect

Image: The illumination multi-surface brush of the DREAME R20 Pure in action, with its Celeste LED lights revealing hidden dust and particles on a dark floor, demonstrating its effectiveness in low-light conditions.

Using Attachments

- **Motorized Mini-Brush:** Ideal for cleaning pet hair from upholstery, mattresses, and stairs.
- **Combination Tool:** Features a brush and a wide nozzle, suitable for cleaning crevices, corners, and delicate surfaces.
- **Wide Combination Tool:** Wider version of the combination tool, useful for larger flat surfaces like tabletops or keyboards.
- **Flexible Adapter:** Allows the vacuum to reach under low furniture and into tight spaces without bending.



Motorized Mini-Brush



Wide Combination Tool



Combination Tool

Switchable Nozzles for Multipurpose Cleaning

Image: A collage showing the versatility of the DREAME R20 Pure with its various attachments: the motorized mini-brush for pet hair, the wide combination tool for surfaces like laptops, and the standard combination tool for narrow spaces.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your DREAME R20 Pure vacuum cleaner.

Emptying the Dust Cup

Empty the dust cup after each use or when the MAX fill line is reached.

1. Hold the main body over a trash bin.
2. Press the dust cup release button to open the bottom flap and empty contents.
3. Close the dust cup flap securely.

Cleaning Filters

The DREAME R20 Pure features a multi-layered filtration system, including a metal mesh filter, multi-cone filter, sponge filter, and fine particle filter. These components are washable.



Image: An exploded diagram illustrating the various components of the DREAME R20 Pure's 99.9% high-efficiency filtration system, including the fine particle filter, sponge filter, multi-cone filter, metal mesh filter, and cyclone separation unit.

1. **Disassembly:** Twist and pull to remove the dust cup from the main body. Separate the metal mesh filter, multi-cone filter, sponge filter, and fine particle filter.
2. **Washing:** Rinse all filter components under running water until clean. Do not use harsh detergents.
3. **Drying:** Allow all parts to air dry completely for at least 24 hours before reassembling. Ensure they are completely dry to prevent mold or damage.
4. **Reassembly:** Reassemble the filters in reverse order of disassembly and reattach the dust cup to the main body.

Cleaning the Brush Roll

Periodically check the brush roll for tangled hair or debris.

1. Turn off the vacuum and detach the illumination multi-surface brush.
2. Use a coin or flat tool to unlock the brush roll cover.

3. Remove the brush roll and cut away any tangled hair or fibers using scissors.
4. Clean any debris from the brush roll housing.
5. Reinsert the brush roll and secure the cover.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum not turning on.	Battery not charged or not properly installed.	Ensure battery is fully charged and securely inserted.
Loss of suction.	Dust cup full, filters clogged, or brush roll obstructed.	Empty dust cup. Clean all filters. Remove any obstructions from brush roll or air pathways.
Brush roll not spinning.	Obstruction in brush roll, or brush roll not properly installed.	Check for and remove any tangled hair or debris. Ensure brush roll is correctly reinserted.
Short runtime.	Battery not fully charged, or operating in Turbo mode constantly.	Fully charge the battery. Use Eco or Med mode for longer cleaning sessions.
LED lights on brush head not working.	Brush head connection loose or damaged.	Ensure the brush head is securely attached to the extension rod or main body. If issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	R20 Pure
Brand	DREAME
Suction Power	150 AW
Rated Power	425 W
Runtime	Up to 90 minutes (Eco Mode)
Dust Cup Capacity	0.6 Liters
Filtration System	99.9% High Efficiency Multi-layered Filtration (HEPA Filter)
Special Features	Celeste LED Illumination, Anti-Tangle Brush, LED Screen, Lightweight

Feature	Detail
Product Dimensions	28.6"L x 5.7"W x 12.9"H
Item Weight	9.5 pounds
Battery Type	1 x 9V battery (included)
UPC	810142560993

WARRANTY AND SUPPORT

Your DREAME Cordless Stick Vacuum R20 Pure comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including warranty duration and coverage details.

For technical support, service, or to inquire about replacement parts, please contact DREAME customer service. Contact information can typically be found on the official DREAME website or on the product packaging. Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 DREAME. All rights reserved.

This manual is for informational purposes only. Product specifications and design are subject to change without notice.