

YM06

Puccy Waterproof Pouch Instruction Manual for YOTON YM06 MP3 Player

Model: YM06 Compatible Waterproof Pouch

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Puccy Waterproof Pouch, designed for the YOTON YM06 MP3 Player. This pouch is engineered to protect your device from water, sand, snow, dust, and dirt, making it ideal for various outdoor and aquatic activities. Please read this manual thoroughly before initial use.

PACKAGE CONTENTS

- 1 x Puccy Waterproof Pouch
- 1 x Lanyard
- 1 x Armband

SETUP AND INITIAL SAFETY TEST

Before using the waterproof pouch with your YOTON YM06 MP3 Player, it is crucial to perform a safety test to ensure its integrity.

1. Perform a Safety Test:

- Place a piece of dry cloth or paper inside the empty pouch.
- Securely close the dual swivel locks, ensuring a tight seal.
- Submerge the sealed pouch in water for at least 30 minutes.
- Remove the pouch from the water, dry its exterior, and then open it to check if the cloth or paper inside is wet.
- **DO NOT use the product if the cloth or paper is wet.** Contact customer support for assistance.

2. Insert Your Device:

- After a successful safety test, open the dual swivel locks.
- Carefully insert your YOTON YM06 MP3 Player into the pouch.

- Ensure the device is centered and does not obstruct the sealing mechanism.
- Close the dual swivel locks firmly to create a watertight seal.

3. Attach Lanyard or Armband:

- Attach the provided lanyard to the designated loop on the pouch for neck or shoulder wear.
- Alternatively, use the armband for securing the pouch to your arm during activities like running or swimming. The armband features an elastic band and strong Velcro for adjustable length and tightness.

OPERATING INSTRUCTIONS

The Puccy Waterproof Pouch is IPX8 certified, providing protection against water damage up to 100 feet (30 meters) deep.

- **Touch Sensitivity:** The premium PVC material allows for good screen touch sensitivity. However, hydraulic pressure may affect screen touch sensitivity when deep underwater. For photography or video recording underwater, use the volume buttons on your YOTON YM06 MP3 Player as a shutter control.
- **Clear Visibility:** The transparent covers ensure that you can take high-definition photos and videos without removing your device from the pouch.

Crystal clear, soft and comfortable to the touch. With dedicated photography window that can perfectly restores the photography effect of your device.



***Please refer to the title for corresponding model**

Image: The transparent design of the pouch allows for clear underwater photography, capturing images of marine life and activities without obstruction.

MAINTENANCE

- **Cleaning:** After each use, especially in saltwater, rinse the pouch with fresh water and wipe it dry with a soft cloth.
- **Storage:** Store the pouch in a cool, dry place away from direct sunlight and sharp objects. Avoid folding or creasing the pouch excessively, as this may compromise its waterproof seal over time.
- **Regular Inspection:** Periodically inspect the pouch for any signs of wear, tears, or damage to the seals before each use.

TROUBLESHOOTING

- **Pouch Fails Safety Test:** If the safety test indicates water leakage, do not use the pouch. This may be due to a manufacturing defect or damage. Contact customer support for a replacement.
- **Reduced Touch Sensitivity Underwater:** This is a normal occurrence due to water pressure. Utilize the physical volume buttons on your YOTON YM06 MP3 Player for camera functions when

submerged.

- **Difficulty Sealing:** Ensure no debris, sand, or foreign objects are present on the sealing edges. Clean the edges thoroughly before attempting to close the dual swivel locks.

SPECIFICATIONS

Model Compatibility	YOTON YM06 MP3 Player
Waterproof Rating	IPX8 Certified (up to 100 ft / 30 meters)
Material	Premium Polyvinyl Chloride (PVC)
Color	Black
Form Factor	Armband / Pouch
Special Features	Travel-friendly, Clear Photography Window, Dual Swivel Locks

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the seller directly through your purchase platform. Keep your proof of purchase for any warranty claims.