Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYOUNG DJ12G-D545

Joyoung Multi-Functional Blender Soymilk Maker

Model: DJ12G-D545-US01 | Brand: JOYOUNG

Introduction

Thank you for choosing the Joyoung Multi-Functional Blender Soymilk Maker. This appliance is designed to provide a versatile and efficient way to prepare a variety of nutritious beverages, including fresh soy milk, smoothies, and more. With its advanced fine-grinding technology and multiple functions, it simplifies your daily routine and helps you maintain a healthy lifestyle. Please read this manual thoroughly before operation to ensure safe and optimal performance.



Image: Front view of the Joyoung Multi-Functional Blender Soymilk Maker, showcasing its sleek white design and integrated handle.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions when using your appliance:

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Keep hands and utensils out of the container while blending to prevent severe injury and/or damage to the blender.
- Always unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Close supervision is necessary when any appliance is used by or near children.
- Avoid contact with moving parts.
- Do not use attachments not recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

Product Overview and Components

Familiarize yourself with the various parts of your Joyoung Multi-Functional Blender Soymilk Maker.



Image: The Joyoung blender with its main body and the detachable blade assembly, illustrating the separate components for cleaning and assembly.

- **Main Body/Pitcher:** The primary container for ingredients, featuring a 1.2 Liter capacity.
- **Lid:** Securely covers the pitcher during operation.
- **Blade Assembly:** The fine-grinding mechanism, detachable for cleaning.
- **Control Panel:** Touch-sensitive interface for selecting functions.
- **Power Cord Inlet:** Located at the back of the base for power connection.



Image: Top-down view into the interior of the Joyoung blender pitcher, showing the stainless steel lining and measurement markings for accurate filling.

Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash the pitcher, lid, and blade assembly with warm, soapy water. Rinse thoroughly and dry completely.
3. **Placement:** Place the blender on a stable, flat, and dry surface, away from heat sources and direct sunlight.
4. **Assemble:** Ensure the blade assembly is securely attached to the pitcher. Place the lid firmly on the pitcher.
5. **Power Connection:** Connect the power cord to the inlet at the back of the blender base, then plug it into a 110-120V AC power outlet.



Image: Rear view of the Joyoung blender, highlighting the power cord inlet at the base, with a warning label in Chinese.

Operating Instructions

The Joyoung Multi-Functional Blender offers eight cold and hot functions for versatile beverage preparation.

General Operation:

1. Add ingredients to the pitcher, ensuring not to exceed the maximum fill line (1.2 Liters).
2. Securely place the lid on the pitcher.
3. Plug in the appliance. The control panel will illuminate.
4. Select your desired function using the touch controls. Refer to the specific function details below.
5. Press the Start/Stop button to begin the program.
6. The appliance will automatically stop when the program is complete.
7. Unplug the appliance after use.

Key Features:

- **1.2 Liter Capacity:** Ideal for preparing 3-4 servings, suitable for family use.
- **Professional Fine-Grinding Technology:** The 11,000 RPM high-speed motor ensures ingredients are finely ground for smooth and nutritious drinks. This technology extracts more nutrients from ingredients.
- **Eight Cold and Hot Functions:** Explore a wide range of recipes, from hot soy milk and porridges to cold smoothies and juices. Specific function names may vary based on model, but typically include options for:
  - Dry Bean Soymilk

- Soaked Bean Soymilk
- Rice Paste
- Porridge
- Juice
- Smoothie
- Warm/Keep Warm
- Clean

Maintenance and Cleaning

Regular cleaning and maintenance will extend the life of your Joyoung blender.

1. **Unplug:** Always unplug the appliance before cleaning.
2. **Self-Clean Function:** For quick cleaning, add water and a drop of dish soap to the pitcher, select the "Clean" function (if available), and run the cycle. Rinse thoroughly afterward.
3. **Manual Cleaning:**
   - *Pitcher and Blade Assembly:* Detach the blade assembly. Wash the pitcher, lid, and blade assembly with warm, soapy water using a non-abrasive sponge or brush. Be careful around the sharp blades.
   - *Motor Base:* Wipe the exterior of the motor base with a damp cloth. Do not immerse the motor base in water.
4. **Drying:** Ensure all parts are completely dry before reassembling or storing.
5. **Storage:** Store the blender in a dry, cool place.

Troubleshooting

If you encounter any issues with your Joyoung Multi-Functional Blender, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; lid not properly secured.	Ensure power cord is firmly plugged into a working outlet. Check if the lid is correctly placed and locked.
Blending is not smooth.	Insufficient liquid; too many ingredients; ingredients too large.	Add more liquid. Reduce the amount of ingredients. Cut ingredients into smaller pieces.
Burning smell during operation.	Overloading; prolonged operation.	Unplug immediately. Reduce ingredients. Allow the motor to cool down before next use. If smell persists, contact customer support.
Leakage from the pitcher.	Lid not properly sealed; pitcher overfilled.	Ensure the lid is securely closed. Do not exceed the maximum fill line.

If the problem persists after trying these solutions, please contact Joyoung customer support.

Specifications

Brand	JOYOUNG
Model Number	DJ12G-D545
Capacity	1.2 Liters (42 fl ounces)
Power Source	120 V
Voltage	110 V
Special Feature	Professional Fine-Grinding (11,000 RPM)
Controls Type	Touch
Product Dimensions	8.5"D x 8.5"W x 12"H
Item Weight	6.09 pounds
Color	White
Manufacture Year	2024

Warranty and Support

Your Joyoung Multi-Functional Blender Soymilk Maker comes with a**1 Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover:

- Damage caused by accident, misuse, abuse, or neglect.
- Damage caused by unauthorized modification or repair.
- Normal wear and tear.

For warranty claims, technical support, or any questions regarding your product, please contact Joyoung Customer Service:

Service Line: 1-888-968-8898

Please have your model number (DJ12G-D545) and proof of purchase ready when contacting support.



Image: Back of the Joyoung product box, displaying key features, specifications, and customer service contact information, including the service line number.

© 2024 JOYOUNG. All rights reserved.
This manual is for informational purposes only and may be subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZQJ5F2H

More documents and user manuals: **https://manuals.plus/**