

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Messenya](#) /

› Messenya Mid Century Modern 9-Drawer Dresser (Model D-202-160) Instruction Manual

## Messenya D-202-160

# Messenya Mid Century Modern 9-Drawer Dresser

MODEL: D-202-160

## 1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Messenya Mid Century Modern 9-Drawer Dresser, Model D-202-160. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

## 2. Safety Information

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- **Anti-Tip Device:** It is highly recommended to install the included anti-tip device to prevent accidental tipping, especially in households with children. Follow the specific instructions provided with the anti-tip kit.
- Do not allow children to climb on or play with the dresser.
- Distribute weight evenly across drawers and the top surface to maintain stability.

## 3. Package Contents

Before assembly, verify that all components and hardware are present. Refer to the separate parts list and hardware diagram included in your packaging. If any parts are missing or damaged, please contact customer service.

## 4. Assembly Instructions

Assembly is required for this dresser. Please follow the step-by-step instructions provided in the separate assembly guide included in your package. Each component is clearly labeled for ease of identification.

- **Tools Required:** A Phillips head screwdriver and a hammer (not included) are typically needed for assembly.

A power drill with appropriate bits can expedite the process.


- **Pre-embedded Fittings:** This dresser features pre-embedded fittings at every screw hole, which simplifies assembly and enhances connection strength. This design also allows for multiple assemblies and disassemblies without compromising structural integrity.
- **Drawer Glides:** The dresser utilizes three-section silent sliding rails for smooth drawer operation. Ensure these are installed correctly according to the assembly guide.



Figure 4.1: Overall dimensions of the Messenya 9-Drawer Dresser (15.7"D x 63"W x 30.7"H).



The frame is crafted from premium oak, ensuring robustness and stability; the beveled solid wood bar design is simple yet elegant



Each screw point is equipped with an embedded part, making the structure more stable, installation more convenient, and allowing for multiple disassemblies without damage

Figure 4.2: Illustration of the dresser's frame crafted from oak, highlighting the pre-embedded screw points for enhanced stability and ease of assembly.

## 5. Operation

The Messenya 9-Drawer Dresser is designed for organized storage in various rooms.

- **Drawer Use:** Gently pull and push the drawers using the electroplated handles. The three-section silent sliding rails ensure smooth and quiet operation. Avoid forcing drawers open or closed.
- **Weight Capacity:** Do not overload drawers. Distribute items evenly to prevent strain on the drawer glides and maintain the dresser's structural integrity. The spacious tabletop can hold decorative items, lamps, or a television, but ensure the weight does not exceed the dresser's stability limits.



Six storage zones to rummage through without getting cluttered

Elegant electroplated handles: stylish, durable, textured, and fade-resistant.

Premium thickened slide rails, each weighing 0.55 lbs

Figure 5.1: The dresser with multiple drawers open, illustrating the ample storage capacity and the premium thickened slide rails for smooth operation.



## WIDER AND DEEPER DRAWERS FOR MORE STORAGE.

Six storage spaces, zoned storage, storage categories are not limited to meet different storage needs

Six storage spaces, zoned storage, storage categories are not limited to meet different storage needs

 <b>12+</b> pull-out tissue	 <b>50+</b> Adult Socks
 <b>10+</b> plush puppet	 <b>7+</b> toy building blocks
 <b>40+</b> Adult underwear	 <b>40+</b> Baby diapers

Figure 5.2: Visual representation of the wider and deeper drawers, designed for increased storage capacity and organization of various items.

## 6. Maintenance and Care

Proper care will help maintain the appearance and longevity of your dresser.

- **Cleaning:** For general cleaning, wipe the surfaces with a soft, dry cloth. For more stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth to remove any moisture.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong detergents, or polishes containing silicone, as these can damage the finish.
- **Spills:** Wipe up spills immediately to prevent staining or damage to the wood finish.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood.
- **Handles:** The electroplated handles are designed to resist fading and rust. Clean them with a soft, dry cloth.

## WIDE PANELS WITH NATURAL TEXTURE

Durable, clear wood grains, easy to place small and large items



Figure 6.1: The dresser's wide panels feature a natural texture that is scratch-resistant, abrasion-resistant, not easy to penetrate, and easy to clean.

## 7. Troubleshooting

Problem	Possible Cause	Solution
Dresser is wobbly or unstable.	Hardware not fully tightened; uneven floor.	Ensure all screws and bolts are securely tightened. Use furniture levelers or shims under the legs if the floor is uneven.
Drawers do not slide smoothly.	Drawer glides are misaligned or obstructed; drawer is overloaded.	Check that the drawer glides are correctly installed and free of debris. Reduce the weight in the drawer.
Missing parts or damaged components upon arrival.	Shipping damage or packaging error.	Do not proceed with assembly. Contact customer service immediately for replacement parts.
Difficulty during assembly.	Instructions misinterpreted; incorrect parts used.	Review the assembly guide carefully. Ensure you are using the correct hardware for each step. Contact customer service if you require further assistance.

## 8. Specifications

- **Brand:** Messenya
- **Model Name:** D-202-160
- **Product Dimensions:** 15.7"D x 63"W x 30.7"H
- **Number of Drawers:** 9

- **Color:** Brown (Walnut Finish)
- **Materials:** E1-grade MDF, Natural Rubber Wood, Oak Frame
- **Item Weight:** 154 pounds
- **Assembly Required:** Yes
- **Product Care Instructions:** Wipe with Damp Cloth, Wipe with Dry Cloth



Figure 8.1: Emphasizing the quality materials and craftsmanship, including stable and solid construction, fine wood grain, and safe, odorless components.

## 9. Warranty and Customer Support

Your Messenya dresser is protected during shipping with foam padding and a 5-layer thickened cardboard box. If you encounter any issues, have questions regarding assembly, or require replacement parts, please contact Messenya customer service. We are committed to providing excellent after-sales support to ensure a satisfactory experience.

Please refer to your purchase documentation for specific warranty details and contact information.