

Akitas H2

Akitas H2 Handheld Vacuum Cleaner User Manual

Model: H2

1. INTRODUCTION

Thank you for choosing the Akitas H2 Handheld Vacuum Cleaner. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and keep it for future reference.

Safety Instructions

- Ensure the vacuum cleaner is fully charged before initial use.
- Do not use the vacuum cleaner to pick up liquids, burning objects, or hazardous materials.
- Keep the device away from water and high temperatures.
- Do not operate the vacuum cleaner if any part is damaged. Contact customer support.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. PACKAGE CONTENTS

Carefully unpack your Akitas H2 Handheld Vacuum Cleaner and check for the following items:

- Akitas H2 Handheld Vacuum Cleaner Unit
- Charging Base
- Power Adapter
- Crevice Tool
- Brush Nozzle
- Washable HEPA Filter (pre-installed)
- Washable Stainless Steel Mesh Filter (pre-installed)



Image: The Akitas H2 handheld vacuum cleaner shown with its charging base, power adapter, crevice tool, brush nozzle, and a washable filter.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Akitas H2 handheld vacuum cleaner:

- **Main Unit:** Contains the motor, battery, and dustbin.
- **Power Button:** Located on the handle for turning the unit on/off and switching modes.
- **Dustbin Release Button:** For detaching the dustbin.
- **Dustbin:** Collects debris.
- **Filter Assembly:** Includes HEPA and stainless steel filters inside the dustbin.
- **Charging Port:** Located on the main unit for direct charging.
- **Charging Base:** For convenient storage and charging.
- **Crevice Tool:** Ideal for narrow gaps and corners.

- **Brush Nozzle:** Suitable for upholstery, keyboards, and delicate surfaces.

Slechts 500g Slank, compact en licht




Image: The Akitas H2 vacuum cleaner, highlighting its compact size (44cm length, 13cm width) and lightweight design (500g), balanced against a water bottle.

4. SETUP

Initial Charging

1. Before first use, fully charge the vacuum cleaner.
2. Connect the power adapter to a wall outlet.
3. You can charge the unit in two ways:
 - **Using the Charging Base:** Place the vacuum cleaner onto the charging base. Ensure the charging contacts align.
 - **Direct Charging:** Plug the adapter directly into the charging port on the main unit.
4. The charging indicator light will show the charging status. A full charge typically takes approximately 3.5 hours.

Dubbele oplaadpoorten – afgestemd op uw levensstijl



Image: The Akitas H2 vacuum cleaner demonstrating its dual charging capabilities, both via a charging dock and direct plug-in.

Attaching Accessories

To attach an accessory (crevice tool or brush nozzle), simply align it with the suction opening of the main unit and push firmly until it clicks into place.

5. OPERATING INSTRUCTIONS

Powering On/Off and Suction Modes

1. Press the power button once to turn on the vacuum cleaner in **Normal Mode**.
2. Press the power button a second time to switch to **Max Mode** for stronger suction.
3. Press the power button a third time to turn off the vacuum cleaner.



Image: The Akitas H2 vacuum cleaner in action, showing its 90W brushless DC motor and strong suction power (up to 12000Pa).

Using Attachments

- **Crevice Tool:** Use this tool for reaching tight spaces, corners, car seats, and between cushions.
- **Brush Nozzle:** Attach the brush nozzle for cleaning delicate surfaces, upholstery, keyboards, and vents.

Spleetmondstuk & borstel

bereikt elke hoek



Image: The Akitas H2 vacuum cleaner being used with its crevice tool and brush attachment to clean various parts of a car interior, including seats and floor mats.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Akitas H2 vacuum cleaner.

Emptying the Dustbin

1. Ensure the vacuum cleaner is turned off.
2. Hold the vacuum cleaner over a trash bin.
3. Press the dustbin release button to open the dustbin flap and empty the collected debris.
4. Close the dustbin flap securely after emptying.



Image: A hand holding the Akitas H2 vacuum cleaner over a trash can, demonstrating the one-touch dustbin emptying mechanism.

Cleaning the Filters

The Akitas H2 features a washable HEPA filter and a stainless steel mesh filter. Clean them regularly to maintain suction power.

1. Turn off the vacuum cleaner and detach the dustbin.
2. Remove the filter assembly from the dustbin.
3. Separate the HEPA filter from the stainless steel mesh filter.
4. Rinse both filters under running water until clean. Do not use detergents.
5. Allow both filters to air dry completely for at least 24 hours before reassembling and placing them back into the dustbin. Ensure they are completely dry to prevent damage to the motor.

Wasbaar dubbel filter

vangt 99,97% van schadelijke deeltjes

Wasbaar H13 HEPA-filter

Wasbaar roestvrijstalen gaasfilter

90ml stofreservoir



Image: A detailed view of the Akitas H2's washable dual filter system, showing the H13 HEPA filter and the stainless steel mesh filter, along with the 90ml dust reservoir.

7. TROUBLESHOOTING

If you encounter any issues with your Akitas H2, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is depleted Power button not pressed correctly	Charge the vacuum cleaner Press the power button firmly
Low suction power	Dustbin is full Filters are clogged Nozzle/attachment is blocked	Empty the dustbin Clean and dry the filters Check and clear any blockages in the nozzle or main unit

Problem	Possible Cause	Solution
Short operating time	Battery not fully charged Operating in Max Mode continuously	Ensure battery is fully charged (3.5 hours) Use Normal Mode for longer runtime
Charging indicator not working	Power adapter not connected Charging contacts are dirty	Ensure adapter is securely plugged in Clean charging contacts on unit and base

8. SPECIFICATIONS

Technical details for the Akitas H2 Handheld Vacuum Cleaner:

Feature	Detail
Brand	Akitas
Model Number	H2
Color	Red
Product Dimensions (L x W x H)	43 x 16 x 9.5 cm
Item Weight	0.5 kg (unit only), 1.24 kg (packaged)
Number of Speeds	2 (Normal, Max)
Motor Power	90W BLDC Brushless Motor
Suction Power	7000-9000Pa (Normal Mode), 12000Pa (Max Mode)
Battery Type	3x 2600mAh 3.7V Li-ion batteries
Runtime	Up to 26 minutes (Normal Mode), Up to 20 minutes (Max Mode)
Charging Time	Approx. 3.5 hours
Filter Type	Washable HEPA (H13) and Stainless Steel Mesh
Dustbin Capacity	90ml
Power Source	Battery Powered
Cordless	Yes
Form Factor	Handheld
Country of Origin	China

3 * 2600mAh 3.7V Li-ion batterijen



Betrouwbaar en
duurzaam tot

26 Mins



20 Mins

in Max-modus voor
diepe reiniging



Image: An illustration showing the internal 3x 2600mAh 3.7V Li-ion batteries and their reliable performance, providing up to 26 minutes of use.

9. WARRANTY AND SUPPORT

Akitas products are designed for reliability and performance. For warranty information, technical support, or replacement parts, please refer to the contact details provided with your purchase or visit the official Akitas website.

Please retain your proof of purchase for warranty claims.

© 2025 Akitas. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question