

[Manuals.plus](#) /

› [G6is98kb](#) /

› G6is98kb SC-QL-001 15s Fast Heating Steam Cleaner User Manual

G6is98kb SC-QL-001

G6is98kb SC-QL-001 15s Fast Heating Steam Cleaner User Manual

Model: SC-QL-001

INTRODUCTION

Thank you for choosing the G6is98kb 15s Fast Heating Steam Cleaner. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new steam cleaner. Please read all instructions carefully before first use and retain this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always read all instructions before using the appliance.
- Use only distilled or demineralized water in the water tank to prevent mineral buildup and damage to the unit.
- Do not overfill the water tank.
- Keep the appliance out of reach of children and pets.
- Never direct steam at people, animals, or electrical appliances. Steam is extremely hot and can cause severe burns.
- Wear the provided protective gloves when operating the steam cleaner to protect your hands from hot surfaces and steam.
- Allow the appliance to cool completely before cleaning, performing maintenance, or storing.
- Ensure the power cord is not damaged and is properly plugged into a grounded outlet.
- Do not immerse the appliance in water or other liquids.

PACKAGE CONTENTS

Your G6is98kb Steam Cleaner package includes the following items:

- 1 x G6is98kb Steam Cleaner Unit
- 1 x Steam Gun/Handle with Flexible Hose
- 1 x Power Cord

- 1 x Funnel
- 1 x Pair of Protective Gloves
- 1 x Copper Nozzle
- 2 x Steel Brushes (small, round)
- 2 x Plastic Brushes (small, round)
- 1 x Large Plastic Brush
- 1 x Extension Wand
- 1 x Window/Glass Cleaning Tool
- 1 x Microfiber Cloth for Window Tool
- 1 x Small Wrench
- 1 x Set of O-rings/Washers
- 2 x AAA Batteries (for handle controls)



Figure 1: Overview of the G6is98kb Steam Cleaner unit and its 14 included accessories.

PRODUCT OVERVIEW

The G6is98kb Steam Cleaner features a compact design with intuitive controls and a transparent water tank for easy monitoring. The ergonomic handle integrates power and steam adjustment for single-handed operation.

SAY GOODBYE TO ANNOYING PROBLEMS

15s

Ready in
15 Seconds

2500
W

2500W
High Power

230
°F

Chemical-free
Steam up to 230°F



Figure 3: Ergonomic handle with integrated controls for steam adjustment.

SETUP

1. **Fill the Water Tank:** Open the water inlet cap on the main unit. Use the provided funnel to carefully pour distilled water into the tank. Do not exceed the maximum fill line. Securely close the cap.



Figure 4: Filling the water tank with the provided funnel.

2. **Connect Power:** Insert the power cord into the designated port on the steam cleaner unit, then plug the other end into a standard electrical outlet.



Figure 5: Connecting the power cord to the unit.

3. **Install Batteries in Handle:** Insert the two AAA batteries into the handle's battery compartment to enable the integrated controls.
4. **Attach Desired Accessory:** Select the appropriate cleaning accessory for your task. Securely attach it to the steam gun/handle. Ensure any washers/O-rings are correctly seated to prevent leaks, especially when using the extension wand or brass nozzle.

OPERATING INSTRUCTIONS

1. **Power On and Heat Up:** Press and hold the power button on the main unit for approximately 3 seconds to turn it on. The unit will begin heating the water. The LCD screen will display the current steam level. The steam cleaner is designed for fast heating, typically ready in 15-20 seconds.




Figure 6: Powering on the unit and selecting steam level.

2. **Adjust Steam Level:** Use the '+' and '-' buttons on the main unit or the integrated controls on the handle to select one of the 9 adjustable steam levels. Higher numbers indicate stronger steam output.
3. **Begin Cleaning:** Direct the steam nozzle towards the surface you wish to clean. Press the trigger on the handle to release steam. Move the nozzle slowly over the surface, allowing the steam to penetrate and loosen dirt. For stubborn areas, use the appropriate brush attachment and gently scrub while applying steam.
4. **Cleaning Applications:**
 - **Kitchen:** Use for countertops, stovetops, and range hoods. The steel brush can be effective for tough grease.
 - **Bathroom:** Ideal for tile grout, shower doors, and sinks. The copper nozzle or plastic brushes can reach tight spaces.
 - **Upholstery & Fabrics:** Use lower steam settings with a microfiber cloth for refreshing and sanitizing upholstery. Test on an inconspicuous area first.
 - **Floors:** For sealed hard floors, use the appropriate brush or cloth attachment.

- **Windows & Glass:** Attach the window cleaning tool with a microfiber cloth for streak-free results.
- **Car Interiors:** Clean and sanitize car upholstery, dashboards, and floor mats.

SAFE FOR KIDS & PETS

A woman with long dark hair is kneeling on a light-colored wooden floor, using a yellow steam cleaner. She is holding a black steam wand that is emitting a spray of white steam onto a white cloth on the floor. In the background, a young girl with blonde hair is sitting on a tan sofa, holding a small brown and white dog. The room is decorated with a green cabinet, a potted plant, and various toys. The overall atmosphere is bright and clean.

100%
NATURAL & SAFE
No Chemical Addition

Figure 7: Steam cleaning a kitchen stovetop.



Figure 8: Versatile cleaning applications for car upholstery, oven, and grout.

Video 1: Demonstration of the G6is98kb steam cleaner being used to clean shower grout, highlighting its effectiveness and long cord.

Video 2: Unboxing and initial setup of the G6is98kb steam cleaner, demonstrating its quick heating time and various attachments for window cleaning.

MAINTENANCE AND STORAGE

1. **Empty Water Tank:** After each use, unplug the unit and allow it to cool. Pull out the stopper and carefully empty any remaining water from the tank. This prevents stagnant water and mineral buildup.



Figure 9: Emptying the water tank after use.

2. **Clean Accessories:** Clean all attachments with water and mild soap. Ensure they are dry before storing.
3. **Descaling (Periodically):** If you notice reduced steam output or mineral residue, descale the unit by running a solution of equal parts white vinegar and distilled water through it. Follow with several cycles of pure distilled water.
4. **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or weak steam output	Water tank is empty; Unit not heated sufficiently; Steam level set too low; Nozzle/hose blocked; Mineral buildup.	Refill water tank; Allow 15-20 seconds for heating; Increase steam level using '+' button; Check for and clear blockages; Perform descaling.
Water leaking from connections	Accessory not securely attached; Worn or missing O-rings/washers.	Ensure all attachments are tightened properly; Replace O-rings/washers if damaged or missing.
Unit does not power on	Not plugged in; Power outlet malfunction; Unit malfunction.	Check power cord connection; Test outlet with another appliance; Contact customer support if issue persists.
Handle controls not working	Batteries are dead or incorrectly inserted.	Replace AAA batteries; Ensure correct polarity.

SPECIFICATIONS

Feature	Detail
Brand	G6is98kb
Model Number	SC-QL-001
Heat Time	15 Seconds
Maximum Temperature	221 Degrees Fahrenheit (105°C)

Feature	Detail
Power Source	Corded Electric (2500W)
Form Factor	Handheld
Capacity	40.57 Oz (approx. 1.2 Liters)
Runtime	30+ minutes (per tank)
Hose Length	6.5 ft (approx. 1.98m)
Power Cord Length	4.9 ft (approx. 1.49m)
Item Weight	3.8 lb (approx. 1.72 kg)
Surface Recommendation	Floor, Sink, Counter Top, Upholstery, Tile, Window, Grout

WARRANTY AND CUSTOMER SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

