

MEIRUBY M22

MEIRUBY M22 Butane Torch Lighter User Manual

Model: M22

1. IMPORTANT SAFETY INFORMATION

- **Butane Fuel Not Included:** Due to shipping regulations, butane fuel is not included. Please refill the torch before first use.
- **Do Not Overfill:** Avoid overfilling the gas tank. Refer to the visible fuel window.
- **Follow Instructions:** Use the torch strictly in accordance with this instruction manual.
- **High Temperature:** The torch reaches a maximum temperature of 1300 degrees Celsius (2372 degrees Fahrenheit). Handle with extreme care.
- **Safety Lock:** Always engage the safety lock when the torch is not in use to prevent accidental ignition.
- **Keep Out of Reach:** Store the torch out of reach of children.
- **Storage Conditions:** Do not expose the torch to direct sunlight or temperatures exceeding 50°C (122°F).
- **Cool Down:** Allow the torch to cool completely before storing it after use. The nozzle can remain hot for some time.

2. PACKAGE CONTENTS

Your MEIRUBY M22 Butane Torch Lighter package includes:

- 1 x MEIRUBY Butane Torch Lighter
- 3 x Butane Filling Nozzles (various sizes)
- 1 x Instruction Manual

3. PRODUCT OVERVIEW

The MEIRUBY M22 Butane Torch Lighter is designed for versatility and ease of use, featuring a robust construction and adjustable settings for various applications.



Image: Key components of the MEIRUBY M22 Butane Torch Lighter, including the flame outlet, ignition button, flame safe lock, visible fuel window, fuel refill hole, and fuel flow regulator.

- **Flame Outlet:** Where the butane flame exits.
- **Ignition Button:** Activates the flame.
- **Flame Safe Lock:** Prevents accidental ignition and can lock the flame on for continuous use.
- **Visible Fuel Window:** Allows monitoring of butane fuel levels.
- **Fuel Refill Hole:** Located at the base for refilling with butane gas.
- **Fuel Flow Regulator:** Adjusts the intensity and size of the flame.
- **Adjustable Jet Flame Head:** The torch head can be angled for precise application.

4. SETUP: BUTANE REFILLING INSTRUCTIONS

The MEIRUBY M22 Butane Torch Lighter is shipped without butane fuel. Please follow these steps to refill your torch:

1. **Choose Butane:** Select a high-quality butane gas canister with a long nozzle. Ensure the butane can is compatible

with refillable lighters.

2. **Invert Torch:** Turn the butane torch lighter upside down. This positions the refill valve correctly for optimal filling.
3. **Insert Nozzle:** Firmly insert the nozzle of the butane gas canister into the fuel refill hole at the base of the torch. Press down for approximately 10 seconds. Do not overfill.
4. **Monitor Level:** Use the visible fuel window to monitor the butane level during refilling. Stop when the window indicates a full tank or when butane starts to spray out.
5. **Stabilize Gas:** After refilling, wait a few minutes (typically 3-5 minutes) for the internal gas pressure to stabilize before attempting to ignite the torch.

HOW TO REFILL THE BUTANE TORCH

WARNING: Please choose high-quality butane filling



1. Choose a butane tank with a long nozzle



2. Turn the ignition upside down



**3. Insert The Pipe, Do not Overfill
Usually Take 10 Seconds To fill**



4. Please wait a few minutes for the gas to stabilize after filling before using

Image: Step-by-step guide on how to refill the butane torch, emphasizing the use of a long-nozzle butane tank, inverting the torch, inserting the pipe, and allowing gas to stabilize.



MEIRUBY VERSATILE GIFT

Choice for father's day
mother's day, Christmas
Thanksgiving, etc

Image: Close-up of the visible fuel window, illustrating how to monitor fuel levels and the MAX line to prevent overfilling.



MEIRUBY VERSATILE GIFT

Choice for father's day
mother's day, Christmas
Thanksgiving, etc

Image: Detail of the gas filling valve, highlighting its leak-proof design for safe and easy refilling.

5. OPERATING INSTRUCTIONS

5.1. Ignition and Flame Adjustment

1. **Unlock:** Slide the flame safe lock to the unlocked position.
2. **Ignite:** Press the ignition button to light the flame. For continuous flame, slide the safety lock forward to engage the lock.
3. **Adjust Flame:** Use the fuel flow regulator (located on the side) to increase or decrease the flame intensity. Slide towards '+' for a stronger flame and towards '-' for a gentler flame.
4. **Extinguish:** Release the ignition button or disengage the flame safe lock to turn off the torch.

MULTI-PURPOSE BUTANE SPRAY GUN

Barbecue Grills Camping|
Wood Burning|Charcoal|Cigars etc.



Image: Close-up of the fuel flame regulator, showing the '+' and '-' indicators for adjusting flame size and intensity.

5.2. Adjustable Flame Head

The torch features an adjustable jet flame head that can be angled to suit your specific task, providing precise flame direction and anti-scald protection.

Adjustable Flame with

MULTI-PURPOSE BUTANE TORCH



Image: The MEIRUBY Butane Torch demonstrating its adjustable head angle feature.

MULTI-PURPOSE BUTANE SPRAY GUN

Barbecue Grills Camping|
Wood Burning|Charcoal|Cigars etc.



Image: Illustration of the adjustable jet flame head angle, highlighting its anti-scald design for precise and sturdy flame

6. APPLICATIONS

The MEIRUBY M22 Butane Torch Lighter is a versatile tool suitable for a wide range of applications:

- **Culinary Uses:** Ideal for caramelizing sugar on crème brûlée, searing meats (e.g., tomahawk steaks), melting cheese, roasting vegetables, and browning meringues.
- **Outdoor Activities:** Excellent for igniting campfires, charcoal grills, and BBQ pits, even in windy conditions due to its windproof design.
- **DIY Projects:** Useful for soldering, heat shrinking, small welding tasks, and other craft or hobby applications.
- **Household Tasks:** Can be used for lighting candles, gas stoves, and fireplaces.



CONTINUOUS FLAME

Unique powerful fire provides a better cooking experience

- ✓ BUTANE REFILLABLE
- ✓ CONVENIENT AND FAST
- ✓ SAFETY SWITCH

Multi-Flame Intensity

Image: The MEIRUBY Butane Torch demonstrating its continuous flame for culinary tasks, highlighting its refillable butane, convenience, speed, and safety switch.

Multi-Purpose Butane Torch



Image: The MEIRUBY Butane Torch being used to ignite charcoal for a BBQ, illustrating its multi-purpose functionality for kitchen, ignition, and welding tasks.

7. TROUBLESHOOTING

• Torch Not Igniting:

- Check the butane fuel level through the visible window. If low, refill the torch.
- Ensure the safety lock is fully disengaged before pressing the ignition button.
- Verify that the fuel flow regulator is not set to the minimum ('-') position.

• Weak or Inconsistent Flame:

- The butane level might be low. Refill the torch.
- Ensure you are using high-quality butane fuel. Impurities can affect performance.
- Adjust the fuel flow regulator towards the maximum ('+') position.

• **Difficulty Refilling:**

- Ensure the torch is inverted during refilling.
- Use one of the provided butane filling nozzles that fits snugly into the refill hole.
- Do not overfill. A slight hiss or spray-back indicates the tank is full.
- Allow the torch to sit for a few minutes after refilling for the gas to settle.

8. SPECIFICATIONS

Feature	Detail
Brand	MEIRUBY
Model Number	M22
Item Weight	0.2 Kilograms
Color	Black
Max Temperature	1300°C (2372°F)

9. WARRANTY AND SUPPORT

MEIRUBY values customer satisfaction. If you have any questions or concerns regarding your MEIRUBY M22 Butane Torch Lighter, please do not hesitate to contact our customer service team. We are committed to providing a satisfactory response within 12 hours.

For support, please refer to the contact information provided with your purchase or visit the official MEIRUBY store on Amazon: [MEIRUBY Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question