OILSAO AOW11

OILSAO AOW11 Cordless Water Flosser Instruction Manual

Your guide to effective oral hygiene with the OILSAO AOW11 Water Flosser.

Important Safety Information

Please read all instructions carefully before using the OILSAO AOW11 Cordless Water Flosser. Keep this manual for future reference.

- **CAUTION:** Keep out of reach of children. Always supervise children when using the product.
- Do not use for purposes other than oral hygiene.
- Do not submerge the toothbrush in water while charging.
- Ensure the charging port cover is securely closed before exposing the device to water.
- Use only with water or dentist-recommended mouthwash.

Product Overview

The OILSAO AOW11 Cordless Water Flosser is designed for comprehensive oral cleaning, offering a unique U-shaped flossing head and multiple modes for personalized dental care. Its portable and waterproof design makes it ideal for home and travel use.



Image: The OILSAO AOW11 Cordless Water Flosser, showcasing its sleek design and the innovative U-shaped flossing tip.

Key Features:

- **U-Shaped Flossing Head:** Cleans both front and back sides of teeth simultaneously for a 360° deep clean.
- **350ML Ultra-Large Water Tank:** Provides 120 seconds of continuous flossing, reducing the need for frequent refills.
- **IPX7 Waterproof:** Safe for use in the shower or bath.
- **5 Flossing Modes & 10 Pressure Levels:** Customizable settings for various oral care needs, including Strong, Normal, Soft, Pulse, and Child modes.
- **9 Jet Tips Included:** A variety of tips for different cleaning requirements, such as standard,

orthodontic, periodontal, and tongue cleaner.

- **Portable & Rechargeable:** Long-lasting battery life (up to 30 days) and compact design for travel convenience.

Package Contents

Verify that all items are present in your package:

- 1 x OILSAO AOW11 Water Flosser Unit
- 2 x U-Shaped Flossing Heads
- 2 x Flossing Toothbrush Heads
- 2 x Standard Jet Tips
- 1 x Orthodontic Tip
- 1 x Periodontal Tip
- 1 x Tongue Cleaner
- 1 x USB-C Charging Cable
- 1 x User Manual



Image: The complete set of 9 interchangeable jet tips and the main water flosser unit.

Setup and First Use

1. Charging the Device

1. Open the silicone cover at the bottom of the device to reveal the USB-C charging port.
2. Connect the provided USB-C cable to the device and a suitable power source (e.g., USB adapter, computer, power bank).
3. The battery indicator lights will illuminate during charging and turn solid when fully charged. A full charge typically takes approximately 4 hours.
4. Ensure the silicone cover is firmly closed after charging to maintain waterproof integrity.

2. Filling the Water Tank

1. The 350ML water tank can be filled in two ways:
2. **Method A (Top Fill):** Open the small cap on the top of the water tank and pour warm water into the opening.
3. **Method B (Detachable Tank):** Twist the water tank counter-clockwise to detach it from the main unit. Fill the tank directly from the faucet. Reattach by aligning and twisting clockwise until secure.
4. Use warm water for a more comfortable experience. Do not use hot water.



Image: Demonstrates how to fill the 350ML water tank, either by opening the top cap or detaching the tank.

Operating Instructions

1. Attaching a Nozzle

1. Select the desired jet tip (e.g., U-shaped, standard, orthodontic).
2. Insert the tip into the hole at the top of the main unit until it clicks into place.
3. To remove, press the release button on the side of the unit and pull the tip out.



Image: A selection of specialized jet tips, including standard, orthodontic, periodontal, and tongue cleaner, designed for different oral care needs.

2. Selecting a Mode and Pressure

1. Press the 'MODE' button to cycle through the 5 available flossing modes:
    - **Strong:** For deep cleaning of teeth and braces.
    - **Normal:** For comprehensive and effective cleaning.
    - **Soft:** For daily cleaning and sensitive gums.
    - **Pulse:** For gum massage.
    - **Child:** For gentle dental care.
2. Each mode features 10 adjustable pressure settings. The device will remember your last used mode.



Image: Visual representation of the five customizable flossing modes: Strong, Normal, Soft, Pulse, and Child, each tailored for specific dental requirements.

3. Using the Water Flosser

1. Lean over a sink and place the jet tip into your mouth.
2. Press the 'ON/OFF' button to start the water flow.
3. Direct the water stream at a 90-degree angle to your gumline.
4. For the U-shaped tip, gently glide it over your teeth, allowing it to clean both front and back surfaces simultaneously.
5. For other tips, move the tip along your gumline, pausing briefly between teeth to allow water to clean thoroughly.
6. Keep your mouth slightly open to allow water to flow into the sink.
7. The device will automatically shut off after 2 minutes.

Your browser does not support the video tag.

Video: An official product video demonstrating the OILSAO water flosser in use, highlighting its U-shaped tip and cordless operation.

Maintenance and Care

1. Cleaning the Device

1. After each use, empty any remaining water from the tank.
2. Rinse the water tank and the main unit with clean water.
3. Wipe the exterior of the device with a soft, dry cloth.
4. Ensure the charging port is dry before closing its silicone cover.

2. Storage

1. Store the water flosser in a cool, dry place away from direct sunlight.
2. It is recommended to store the device with the water tank empty to prevent bacterial growth.

3. Replacing Nozzles

1. For optimal hygiene and performance, replace jet tips every 3-6 months, or sooner if they show signs of wear.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on	Low battery or no charge.	Charge the device fully.
Weak water pressure	Water tank is low or empty; nozzle is clogged; incorrect mode selected.	Refill water tank; clean the nozzle; select a stronger mode.
Water leaks from the device	Water tank not properly attached; charging port cover not sealed.	Ensure water tank is securely twisted on; firmly close the charging port cover.
Nozzle is difficult to remove	Release button not fully pressed.	Press the nozzle release button firmly before pulling the tip.

Specifications

Feature	Detail
Model Number	AOW11
Product Dimensions	3.5 x 3.5 x 9.4 inches
Item Weight	14.89 ounces
Water Tank Capacity	350ML / 12oz
Waterproof Rating	IPX7
Power Source	Battery Powered (1 AAA battery included)

Feature	Detail
Operation Modes	5 (Strong, Normal, Soft, Pulse, Child)
Pressure Settings	10 levels
Nozzle Rotation	360°

Warranty and Support

OILSAO is committed to providing high-quality products and customer satisfaction. Your OILSAO AOW11 Cordless Water Flosser comes with a standard manufacturer's warranty covering defects in materials and workmanship under normal use.

For any questions, concerns, or support needs, please contact our customer service team. We offer 24/7 customer support to assist you.

- **Customer Support Email:** dentalclean@oilsaosupport.com



Image: A graphic indicating customer support availability and contact information for OILSAO products.