

[Manuals.plus](#) /

> [aqinsfai](#) /

> aqinsfai Replacement Inner Bowl for Panasonic SR-DF101 Rice Cooker

aqinsfai SR-DF101 Compatible Inner Bowl

aqinsfai Replacement Inner Bowl for Panasonic SR-DF101 Rice Cooker

Instruction Manual

1. INTRODUCTION

This instruction manual provides essential information for the proper use and maintenance of your aqinsfai replacement inner bowl. This inner bowl is specifically designed to be compatible with Panasonic SR-DF101, SR-TMG10, and SR-TMH10 rice cooker models. Please read this manual thoroughly before first use to ensure optimal performance and longevity of the product.

2. PRODUCT OVERVIEW

The aqinsfai replacement inner bowl is a high-quality component intended to replace a damaged or worn original inner pot in compatible Panasonic rice cookers. It is constructed from durable materials to ensure even heat distribution and ease of cleaning.

Key Features:

- **Compatibility:** Designed for a snug fit within Panasonic SR-DF101, SR-TMG10, and SR-TMH10 rice cookers.
- **Durable Construction:** Made from thickened 304 stainless steel for enhanced durability and performance.
- **Even Heat Distribution:** The material and design promote uniform heat distribution for consistent cooking results.
- **Easy Maintenance:** Features a surface that simplifies cleaning.



Figure 2.1: Top-down view of the replacement inner bowl, showing the interior and measurement markings.

3. SETUP AND INSTALLATION

Installing the replacement inner bowl is a straightforward process. Ensure your rice cooker is unplugged and cooled before proceeding.

1. **Preparation:** Unplug the rice cooker from the power outlet. Allow the unit to cool completely if it has been recently used.
2. **Remove Old Bowl (if applicable):** Carefully lift out the existing inner bowl from the rice cooker housing.
3. **Inspect Rice Cooker:** Check the interior of the rice cooker housing for any debris or food particles. Clean if necessary.
4. **Place New Bowl:** Gently lower the aqinsfai replacement inner bowl into the rice cooker housing. Ensure it sits flat and securely within the heating element area. Do not force it.
5. **Verify Fit:** The bowl should fit snugly without wobbling. If it does not fit correctly, double-check the compatibility with your specific Panasonic rice cooker model (SR-DF101, SR-TMG10, or SR-TMH10).



Figure 3.1: Side view of the replacement inner bowl, illustrating its shape and exterior markings.

4. OPERATING INSTRUCTIONS

Once the inner bowl is correctly installed, you can use your rice cooker as usual. The replacement bowl functions identically to the original in terms of cooking performance.

1. **Add Ingredients:** Place your desired amount of rice and water into the inner bowl according to your recipe or the rice cooker's instructions. The bowl features internal markings for common rice and water ratios.
2. **Close Lid:** Securely close the rice cooker lid.
3. **Start Cooking:** Plug in the rice cooker and select the appropriate cooking setting.
4. **After Cooking:** Once cooking is complete, allow the rice to rest for a few minutes before serving. Use a non-abrasive utensil to scoop out the rice to avoid scratching the inner bowl's surface.



Figure 4.1: Interior view of the inner bowl, highlighting the embossed measurement lines for white rice, brown rice, and porridge.

5. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your replacement inner bowl and ensure hygienic cooking.

1. **Immediate Cleaning:** After each use, remove any remaining food particles.
2. **Washing:** Wash the inner bowl with warm water and a mild dish soap. Use a soft sponge or cloth. Avoid abrasive scrubbers, steel wool, or harsh detergents, as these can damage the surface.
3. **Rinsing:** Rinse thoroughly under running water to remove all soap residue.
4. **Drying:** Dry the inner bowl completely with a soft cloth before storing or placing it back into the rice cooker.
5. **Dishwasher Use:** While the 304 stainless steel is generally dishwasher safe, hand washing is recommended to preserve the surface finish over time.



Figure 5.1: Exterior side view of the inner bowl, showing the rim and base.

6. TROUBLESHOOTING

This section addresses common concerns related to the inner bowl.

Problem	Possible Cause	Solution
Inner bowl does not fit.	Incorrect model compatibility.	Verify your rice cooker model is Panasonic SR-DF101, SR-TMG10, or SR-TMH10.
Food sticks to the bottom.	Insufficient water, incorrect cooking settings, or residue buildup.	Ensure correct water-to-rice ratio. Refer to your rice cooker's manual for settings. Clean the bowl thoroughly after each use.
Scratches on the surface.	Use of abrasive utensils or cleaning tools.	Always use plastic or wooden utensils. Clean with a soft sponge or cloth.

7. SPECIFICATIONS

The following specifications apply to the aqinsfai replacement inner bowl:

- **Material:** Thickened 304 Stainless Steel
- **Compatibility:** Panasonic SR-DF101, SR-TMG10, SR-TMH10 Rice Cookers
- **Item Weight:** Approximately 50 Grams (1.76 ounces)
- **Dimensions:** Refer to your original rice cooker manual for exact dimensions, or measure the existing bowl.



Figure 7.1: Top-down view of the inner bowl with a measuring tape, indicating an approximate diameter of 20cm (8 inches).

8. WARRANTY AND SUPPORT

Specific warranty information for this aqinsfai replacement inner bowl is not provided in the product details. For any issues or support inquiries, please contact the seller directly through the platform where the purchase was made. Retain your proof of purchase for any potential claims.

