



Manuals.plus /

› wogree /

› WOGREE Golf Rangefinder H116T User Manual

wogree H116T

WOGREE Golf Rangefinder H116T User Manual

Model: H116T

INTRODUCTION

Thank you for choosing the WOGREE Golf Rangefinder H116T. This advanced laser rangefinder is designed to provide accurate distance measurements for golf and hunting, enhancing your precision and performance. Featuring slope compensation, flag pole locking with vibration, and a strong magnetic strap, the H116T is a versatile and durable tool for any enthusiast. This manual will guide you through the setup, operation, and maintenance of your new device.



Image: The WOGREE Golf Rangefinder H116T, a compact device with a white body and black accents, featuring the objective lens and laser emitter/receiver on the front, and the model number H-116 visible on the side.

PACKAGE CONTENTS

Please ensure all the following items are included in your package:

- 1 x WOGREE Golf Rangefinder H116T
- 1 x Storage Package (Carrying Case)
- 1 x Lithium Battery (CR2-3V)
- 1 x Hang String (Lanyard)
- 1 x Carabiner
- 1 x Lens Cloth
- 1 x Operation Manual (This Document)

KEY FEATURES

- **Slope Compensation:** Provides accurate distance readings adjusted for elevation changes, with a slope switch for tournament legal play.
- **Strong Magnetic Strap:** Built-in magnet allows secure attachment to golf carts or other magnetic surfaces.
- **Four Measurement Modes:**
 - **M1 Hunting Mode:** Measures straight-line distance, horizontal distance, angle, and continuous scan.

- **M2 Non-slope Mode:** Features Flag Locking and Vibration without slope compensation.
 - **M3 Slope Mode:** Includes Slope Compensation, Golf Flag Locking, and Vibration.
 - **M4 Vertical Distance Mode:** Measures straight-line distance and vertical distance.
- **High-precision Measurement:** Measures 5-1200 yards with 0.5-yard accuracy.
 - **Intelligent Flagpole Locking:** Delivers a short vibration to confirm locking onto the flagstick.
 - **Compact and Lightweight Design:** Ergonomic design for comfortable handling and easy portability.
 - **Durable Construction:** Rubber armor provides resistance against drops and shocks.

SETUP GUIDE

1. Battery Installation

1. Locate the battery compartment on the device.
2. Open the battery compartment cover.
3. Insert the provided CR2-3V Lithium Battery, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.

2. Focus Adjustment

To ensure a clear view through the eyepiece, rotate the eyepiece ring until the display and target appear sharp and in focus. This adjustment is crucial for accurate readings.

3. Attaching the Lanyard and Carabiner

Attach the hang string (lanyard) to the designated loop on the rangefinder for secure carrying. The carabiner can be used to clip the rangefinder to your golf bag or belt loop.

OPERATING INSTRUCTIONS

Powering On/Off

Press the power button (usually the main measurement button) to turn on the device. The device will automatically power off after a period of inactivity to conserve battery.

Changing Measurement Modes

The WOGREE H116T features four distinct measurement modes. Use the mode button (typically a separate button or a long press of the power button) to cycle through M1, M2, M3, and M4. The current mode will be displayed in the eyepiece.

M1: Hunting Mode

This mode provides straight-line distance, horizontal distance, and angle. It also supports continuous scan measurement, allowing you to scan multiple targets without repeatedly pressing the button.

M2: Non-slope Mode

Ideal for tournament play where slope compensation is not permitted. This mode offers flag locking and vibration feedback when the flagstick is acquired.

M3: Slope Mode

This mode calculates the adjusted distance based on elevation changes between you and the target, providing a "play as" distance. It also includes golf flag locking and vibration. Ensure the slope switch is enabled for this mode.

M4: Vertical Distance Mode

Measures the straight-line distance and the vertical height difference to the target.

Using the Magnetic Strap

The built-in strong magnet allows you to conveniently attach the rangefinder to the metal frame of a golf cart or other magnetic surfaces. This keeps your device easily accessible during your game.

CARE AND MAINTENANCE

- **Cleaning Lenses:** Use the provided lens cloth or a soft, clean, lint-free cloth to gently wipe the lenses. Do not use abrasive materials or chemical cleaners.
- **Cleaning Body:** Wipe the body of the rangefinder with a soft, damp cloth. Avoid harsh chemicals.
- **Storage:** When not in use, store the rangefinder in its protective storage package in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery:** If the device will not be used for an extended period, it is recommended to remove the battery to prevent leakage.
- **Water Resistance:** While durable, avoid submerging the device in water. It is designed to withstand light rain and splashes, but not full immersion.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Battery is dead or incorrectly installed.	Check battery polarity. Replace with a new CR2-3V battery.
Inaccurate readings.	Unclear focus, dirty lens, or target too far/close.	Adjust eyepiece focus. Clean lenses with the provided cloth. Ensure target is within 5-1200 yard range.
Display is dim or flickering.	Low battery.	Replace the battery.
Cannot lock onto flag.	Obstructions, unsteady hand, or incorrect mode.	Ensure a clear line of sight. Hold the device steady. Confirm you are in M2 or M3 mode.

TECHNICAL SPECIFICATIONS

Model Name	H116T
Measuring Range	5 - 1200 Yards
Accuracy	±0.5 Yards
Color	White
Material	Plastic
Item Weight	145 Grams
Battery Type	CR2-3V Lithium Battery
Dimensions (L x W x H)	Approx. 5.5 x 3.6 x 2.3 inches (Package)
Sport	Golf, Hunting

WARRANTY AND SUPPORT

Warranty Information

The WOGREE Golf Rangefinder H116T comes with a **2-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product performs as described under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty claims, please contact WOGREE customer support. Refer to the contact information provided on the product packaging or the official WOGREE website.