

[Manuals.plus](#) /

> [LLIVEKIT](#) /

> LLIVEKIT 10L Dual Compartment Air Fryer Instruction Manual

## LLIVEKIT 10L Dual Compartment Air Fryer

# LLIVEKIT 10L Dual Compartment Air Fryer Instruction Manual

Model: 10L Dual Compartment Air Fryer

Brand: LLIVEKIT

## 1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the LLIVEKIT 10L Dual Compartment Air Fryer. Retain this manual for future reference.

- Always place the appliance on a stable, heat-resistant surface, away from walls or other appliances to allow adequate air circulation.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Supervise children closely when the appliance is in use. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way. Contact customer support for assistance.
- Hot surfaces: The exterior and interior of the air fryer become very hot during operation. Use oven mitts when handling hot components.
- Do not block the air intake or outlet vents during operation.
- Unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool completely before handling or storing.
- Do not use accessories or attachments not recommended by the manufacturer.

## 2. PRODUCT OVERVIEW

### 2.1 Components

The LLIVEKIT 10L Dual Compartment Air Fryer is designed for efficient and versatile cooking. Familiarize yourself with its main components:

- **Main Unit:** Houses the heating elements, fan, and control panel.
- **Dual Cooking Baskets:** Two independent 5L baskets for simultaneous cooking of different foods.
- **Viewing Windows:** Transparent windows on each basket allow monitoring of food without opening.
- **Control Panel:** Touch-sensitive interface for selecting programs, adjusting settings, and managing cooking functions.
- **Crisper Plates/Grids:** Removable plates placed inside the baskets to promote air circulation and crisping.





Figure 2.1: Front view of the LLIVEKIT 10L Dual Compartment Air Fryer with food visible in both baskets.

## 2.2 Control Panel

The intuitive touch control panel allows for easy selection of cooking modes and adjustments.

# 7 Préréglages de Cuisson +

# 2 Fonctions de Synchronisation Intelligente

Panneau de commande clair pour faciliter la cuisson



Figure 2.2: Detailed view of the control panel, showing various preset icons and function buttons.

## 3. SETUP AND FIRST USE

### 3.1 Unpacking

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Check that all components are present and undamaged.

### 3.2 Initial Cleaning

1. Wipe the exterior of the main unit with a damp cloth.
2. Wash the cooking baskets and crisper plates with warm, soapy water. Rinse thoroughly and dry completely.
3. Do not use abrasive cleaners or scouring pads, as these can damage the non-stick coating.

### 3.3 Placement

1. Place the air fryer on a stable, level, and heat-resistant surface.

2. Ensure there is at least 15 cm (6 inches) of clear space around the back and sides of the appliance for proper ventilation.
3. Do not place the air fryer near flammable materials or heat sources.

## 4. OPERATING THE AIR FRYER

### 4.1 Power On/Off

- Plug the power cord into a grounded electrical outlet. The control panel will illuminate.
- Press the Power button to turn the appliance on or off.

### 4.2 Pre-programmed Settings

The air fryer features 7 pre-programmed settings for common dishes:

- Fries
- Pastry
- Dried Fruits (Dehydration)
- Bacon
- Roast
- Bake
- Reheat

To use a preset, select the desired basket (Zone 1 or Zone 2), then press the corresponding preset icon on the control panel. The default time and temperature will be displayed. You can adjust these settings manually if needed.

### 4.3 Manual Mode

For custom cooking, you can manually set the temperature and time:

- Select the desired basket (Zone 1 or Zone 2).
- Use the temperature adjustment buttons to set the temperature between 80°C and 200°C.
- Use the time adjustment buttons to set the cooking duration.
- Press the Start/Pause button to begin cooking.

### 4.4 Dual Zone Cooking Features

The LLIVEKIT air fryer offers advanced features for cooking in both baskets simultaneously.

#### 4.4.1 SMART FINISH

The SMART FINISH function allows you to cook two different foods with different settings, ensuring both finish cooking at the same time.

1. Place different foods in Zone 1 and Zone 2.
2. Select Zone 1 and set its desired cooking program (preset or manual time/temperature).
3. Select Zone 2 and set its desired cooking program.
4. Press the SMART FINISH button. The air fryer will automatically adjust the cooking times to ensure both zones complete simultaneously.
5. Press Start/Pause to begin.

# SMART FINISH

Le plaisir synchronisé  
de deux aliments différents



Figure 4.1: SMART FINISH function example, cooking steak in Zone 1 and vegetables in Zone 2, finishing together.

## 4.4.2 MATCH COOK

The MATCH COOK function synchronizes the settings for both baskets, ideal for cooking larger quantities of the same food.

1. Place the same food in both Zone 1 and Zone 2.
2. Set the desired cooking program (preset or manual time/temperature) for either Zone 1 or Zone 2.
3. Press the MATCH COOK button. The settings from the selected zone will be mirrored to the other zone.
4. Press Start/Pause to begin.

# MATCH COOK

Cuisson simultanée de deux portions des mêmes ingrédients.



Figure 4.2: MATCH COOK function example, cooking fries in both Zone 1 and Zone 2 with identical settings.

## 4.5 Cooking Process

- **Preheating:** The LLIVEKIT air fryer heats instantly, often eliminating the need for preheating, making it up to 70% faster than conventional ovens.
- **Loading Food:** Place food in the cooking baskets, ensuring not to overfill. For best results, arrange food in a single layer.
- **Shake/Flip Reminder:** The appliance features an automatic shake/flip reminder to ensure even cooking and crispiness. When prompted, carefully remove the basket and shake or flip the food, then reinsert the basket.

# Rappel de Retournement Intelligent

Il vous rappelle de secouer ou de retourner les aliments à mi-cuisson pour garantir une cuisson homogène et des résultats croustillants.




\*La lumière intégrée permet de vérifier facilement le processus de cuisson en temps réel.

Figure 4.3: The air fryer prompting a shake reminder during cooking for optimal results.

- **Monitoring:** Use the viewing windows to monitor the cooking progress without interrupting the cycle. The 360° hot air circulation ensures thorough and even cooking.

# Technologie de Friture à l'air Chaud à **360°** et à Double Couche

Croustillant à l'extérieur et tendre, juteux et délicieux à l'intérieur



**90%**  
d'huile en moins

**3 fois**  
plus rapide

**28 turbo**  
ventilateurs sur le  
dessus et le dessous

\* Par rapport à la friture, les frites coupées à la main

Figure 4.4: Illustration of the 360-degree hot air circulation technology for even cooking.

- **Completion:** The air fryer will beep when the cooking cycle is complete. Carefully remove the baskets and transfer the cooked food.

## 5. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer. The LLIVEKIT air fryer is designed for easy cleaning with its removable components.

### 5.1 Daily Cleaning

1. Unplug the air fryer and allow it to cool completely before cleaning.
2. Remove the cooking baskets and crisper plates.
3. Wash the baskets and crisper plates with warm, soapy water. The food-grade polypropylene baskets are dishwasher safe.
4. For stubborn residue, soak the components in warm water for a few minutes before cleaning.

5. Wipe the interior of the air fryer with a damp cloth. Do not use abrasive materials.
6. Wipe the exterior of the appliance with a damp cloth.
7. Ensure all parts are thoroughly dry before reassembling or storing.

## 5.2 Deep Cleaning

Periodically, a more thorough cleaning may be required:

- If the heating element appears dirty, gently wipe it with a damp cloth after the appliance has cooled. Do not use excessive water.
- For difficult-to-remove grease, a paste of baking soda and water can be applied to non-stick surfaces, left for a short period, then gently wiped away.

## 6. TROUBLESHOOTING

If you encounter any issues with your LLIVEKIT Air Fryer, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; Power button not pressed; Power outlet malfunction.	Ensure the power cord is securely plugged in. Press the Power button. Test the outlet with another appliance.
Food is not cooked evenly.	Baskets are overcrowded; Food not shaken/flipped; Incorrect temperature/time.	Do not overcrowd baskets; cook in smaller batches. Shake or flip food halfway through cooking. Adjust temperature and time as needed.
Food is not crispy.	Too much moisture; Not enough oil (for certain foods); Temperature too low.	Pat food dry before cooking. Lightly spray with oil for crispier results. Increase temperature slightly.
White smoke coming from the air fryer.	Grease residue from previous use; High-fat food cooking.	Clean the baskets and interior thoroughly. For high-fat foods, drain excess fat during cooking.
Appliance smells during first use.	Normal for new appliances due to manufacturing residues.	This is normal and will dissipate after a few uses. Ensure good ventilation.

## 7. TECHNICAL SPECIFICATIONS

Refer to the following specifications for your LLIVEKIT 10L Dual Compartment Air Fryer:

Feature	Specification
Brand	LLIVEKIT

Feature	Specification
Model	10L Dual Compartment Air Fryer
Capacity	10 Liters (2 x 5L independent baskets)
Power	2460 Watts
Dimensions (L x W x H)	39.6 x 25 x 45.5 cm
Weight	9.53 Kilograms
Material	Polypropylene (PP)
Control Method	Touch
Special Features	Automatic shut-off, Temperature control, Dual zone functionality, Timer, Programmable, Stain resistant
Recommended Uses	Dehydration, Grilling, Reheating, Roasting

# Design à Double Empilement

Économiser **30%** d'espace  
Profiter de capacité doublée



Figure 7.1: Dimensions of the LLIVEKIT 10L Dual Compartment Air Fryer.

## 8. WARRANTY AND SUPPORT

The LLIVEKIT 10L Dual Compartment Air Fryer comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage duration and claim procedures.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact LLIVEKIT customer service. You can typically find contact information on the LLIVEKIT official website or through your retailer's support channels.

When contacting support, please have your product model number (10L Dual Compartment Air Fryer) and purchase date available.

