

MHJKHG Handheld High Pressure Steam Cleaner

MHJKHG Handheld High Pressure Steam Cleaner User Manual

Model: Handheld High Pressure Steam Cleaner

Brand: MHJKHG

1. INTRODUCTION

Thank you for choosing the MHJKHG Handheld High Pressure Steam Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new steam cleaner. Please read this manual thoroughly before first use and retain it for future reference.

2. SAFETY INSTRUCTIONS

WARNING: Failure to follow these safety instructions may result in electric shock, fire, serious injury, or property damage.

- Always ensure the power supply matches the voltage specified on the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep children and pets away from the appliance during operation.
- Steam is extremely hot. Avoid direct contact with skin or eyes to prevent burns.
- Do not open the water tank cap while the unit is pressurized or hot. Allow it to cool down completely before refilling.
- Use only clean tap water. Do not add detergents, perfumes, or other chemicals to the water tank.
- Unplug the appliance from the power outlet before cleaning, maintenance, or when not in use.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance has been dropped or damaged in any way.
- Ensure adequate ventilation when using the steam cleaner in enclosed spaces.

3. PACKAGE CONTENTS

Carefully unpack your MHJKHG Handheld High Pressure Steam Cleaner and check that all items are present and in good condition:

- 1 x Cleaning Machine (Main Unit)
- 1 x Steam Nozzle/Gun
- 1 x High-Pressure Hose
- 1 x Power Cord
- Additional accessories (if included, refer to packaging)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your steam cleaner before operation.



Figure 4.1: The MHJKHG Handheld High Pressure Steam Cleaner with its main components, including the portable case, steam gun, hose, and power cord.

The main unit is housed in a durable case, featuring controls for steam, hot water, and cold water functions. The handheld steam gun connects via a high-pressure hose, allowing for flexible cleaning.



Figure 4.2: Overview of the steam cleaner's capabilities, highlighting steam, cold water, hot water functions, and 3000W power for commercial-grade cleaning.

HOT AND COLD ALL IN ONE

Steam, hot water and cold water switch back and forth



Figure 4.3: Visual representation of the 'Hot and Cold All in One' feature, illustrating the ability to switch between steam, hot water, and cold water output.

5. SETUP

1. **Placement:** Place the main unit on a stable, flat, and heat-resistant surface. Ensure there is adequate space around the unit for ventilation.
2. **Water Filling:** Ensure the unit is unplugged. Unscrew the water tank cap. Fill the water tank with clean tap water. Do not overfill. Securely close the water tank cap.
3. **Connect Hose and Nozzle:** Attach the high-pressure hose securely to the main unit's outlet. Connect the steam gun/nozzle to the other end of the hose. Ensure all connections are tight to prevent leaks.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

6. OPERATING INSTRUCTIONS

1. **Power On:** Turn on the main power switch on the unit. The indicator light will illuminate.
2. **Heating:** Allow the unit approximately 20 seconds to heat up and build steam pressure. The steam temperature can reach up to 270°F (132°C).

3. **Select Mode:** Use the control switches on the unit to select your desired output: Steam, Hot Water, or Cold Water.
4. **Begin Cleaning:** Point the nozzle at the surface to be cleaned. Press the trigger on the handheld steam gun to release steam or water.
5. **Cleaning Technique:** For optimal results, hold the nozzle close to the surface. For stubborn stains, allow the steam to penetrate for a few seconds before wiping.
6. **Applications:** This cleaner is suitable for various surfaces including kitchen range hoods, cooktops, air conditioners, refrigerators, sofas, microwave ovens, toilets, and car seats.



Figure 6.1: The MHJKHG Handheld High Pressure Steam Cleaner being used to clean a kitchen range hood, demonstrating its effectiveness in removing grease and grime with high-temperature steam.

7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your steam cleaner.

- **After Each Use:** Unplug the unit and allow it to cool completely. Drain any remaining water from the tank.
- **Cleaning the Exterior:** Wipe the exterior of the unit with a damp cloth. Do not use abrasive cleaners or solvents.

- **Nozzle Cleaning:** If the nozzle becomes clogged, use a small pin or needle to clear any mineral deposits.
- **Descaling (Periodically):** Depending on water hardness, descaling may be necessary. Consult a qualified technician or refer to specific descaling instructions if provided with your unit.
- **Storage:** Store the steam cleaner in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the hose and power cord are neatly coiled.

8. TROUBLESHOOTING

If you encounter issues with your steam cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or low pressure	Water tank empty; Unit not heated sufficiently; Nozzle clogged.	Refill water tank; Allow more heating time (20s+); Clean nozzle.
Water leaking from connections	Connections not tight; Damaged O-rings.	Tighten all connections; Inspect and replace O-rings if damaged.
Unit not turning on	No power supply; Power switch off.	Check power outlet and plug; Ensure power switch is in 'ON' position.
Excessive noise	Low water level; Unit vibrating on uneven surface.	Refill water tank; Place unit on a stable, flat surface.

If the problem persists after attempting these solutions, please contact customer support.

9. SPECIFICATIONS

- **Product Name:** High Pressure Steam Cleaner
- **Type:** Handheld
- **Power:** 1700W
- **Steam Pressure:** 3-5 bar
- **Steam Temperature:** 210-270°F (99-132°C)
- **Steam Duration:** >30 minutes (continuous)
- **Heating Time:** Approximately 20 seconds
- **Manufacturer:** MHJKHG
- **ASIN:** B0DZXKR4PC

10. WARRANTY AND SUPPORT

Your MHJKHG Handheld High Pressure Steam Cleaner comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, replacement parts, or any inquiries, please contact MHJKHG customer service through your retailer or the official MHJKHG website.

