Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Emerson /
- Emerson EVP-2002 Home Theater LCD Projector User Manual

Emerson EVP-2002

Emerson EVP-2002 Home Theater LCD Projector User Manual

Model: EVP-2002

INTRODUCTION

Thank you for choosing the Emerson EVP-2002 Home Theater LCD Projector. This manual provides essential information for setting up, operating, and maintaining your projector to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and retain it for future reference.

WHAT'S IN THE BOX

Upon unpacking, please ensure all the following items are present:

- Emerson EVP-2002 Projector
- · UL Approved Power Adaptor
- · Remote Control
- · Projector Lens Cover
- User Manual (this document)

PRODUCT OVERVIEW

The Emerson EVP-2002 is designed to deliver an immersive home theater experience with its advanced LCD technology and versatile connectivity options.



Image: Front view of the Emerson EVP-2002 projector, showcasing the lens and ventilation. This compact projector is designed for home entertainment.

Key Features:

- Immersive Entertainment: Transforms your space into a theater for sports, movies, and TV shows.
- Bluetooth Connectivity: Allows easy pairing with external audio devices.
- Effortless Media Streaming: Compatible with streaming devices like Amazon Fire Stick, Roku, or Google Chromecast (not included).
- Vivid Visuals: Advanced LCD projector delivers high-quality resolution with clarity and color vibrancy.
- Versatile Multi-Media Functionality: Supports HDMI and USB flash drives for various video, audio, and photo formats.
- Long-Lasting LED Bulb: Durable LED bulb with up to 30,000 hours of lifespan.
- Powerful Built-In Speakers: Delivers clear, full-bodied sound.



Image: Side view of the Emerson EVP-2002 projector, showing its compact cylindrical design and adjustable stand.

Product Dimensions and Weight:

• **Dimensions:** 6.75 x 4.12 x 4.98 inches

• Weight: 1.43 pounds

Versatile Media Playback

Stream and play media via HDMI or USB flash drives. Show family photos, play music, or enjoy movies with support for various video, audio, and photo formats for versatile entertainment.




Image: Diagram illustrating the dimensions (6.75 in. length, 4.12 in. width, 4.98 in. height) and weight (1.43 lbs) of the Emerson EVP-2002 projector.

SETUP GUIDE

1. Placement

Position the projector on a stable, flat surface. Ensure there is adequate ventilation around the unit. The distance from the screen or wall will determine the image size. Adjust the projector's angle using its stand for optimal projection.

2. Power Connection

- 1. Connect the UL Approved Power Adaptor to the DC IN port on the projector.
- 2. Plug the power adaptor into a standard electrical outlet.
- 3. The power indicator light should illuminate.

3. Connecting Input Sources

The EVP-2002 offers multiple input options:

- **HDMI:** Connect an HDMI cable from your source device (e.g., laptop, game console, streaming stick) to the HDMI port on the projector.
- USB: Insert a USB flash drive into the USB port to play media files directly.
- 3.5mm Audio: Connect external speakers or headphones using a 3.5mm audio cable to the AUX OUT port.



Image: Rear view of the Emerson EVP-2002 projector, showing the various input ports including HDMI, USB, and DC power input.

OPERATING INSTRUCTIONS

1. Power On/Off

- To power on, press the Power button on the projector or the remote control.
- To power off, press the Power button again. The projector will enter standby mode.

2. Adjusting Focus

Rotate the focus ring located near the lens until the projected image appears clear and sharp.

3. Source Selection

Use the "Source" button on the remote control or the projector's control panel to cycle through available input sources (HDMI, USB, etc.).

4. Bluetooth Connectivity

- 1. Ensure Bluetooth is enabled on your external audio device (e.g., speaker, headphones).
- 2. On the projector, navigate to the Bluetooth settings (refer to on-screen menu if available, or press the dedicated Bluetooth button if present).
- 3. Select your device from the list of available devices to pair.
- 4. Once paired, audio will be routed through the connected Bluetooth device.



Image: The Emerson EVP-2002 projector displaying a Bluetooth icon, indicating its wireless audio connectivity feature.

5. Media Playback (USB)

- 1. Insert a USB flash drive containing compatible media files into the USB port.
- 2. Select "USB" as the input source.
- 3. Navigate through the folders and files using the remote control or projector buttons.
- 4. Select a file to begin playback.




Image: The Emerson EVP-2002 projector connected to a USB drive, illustrating its capability to play various media formats directly.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your projector.

1. Cleaning the Lens

- · Always power off and unplug the projector before cleaning.
- Use a soft, lint-free cloth specifically designed for optical lenses.
- Gently wipe the lens in a circular motion. Avoid harsh chemicals or abrasive materials.
- Replace the lens cover when the projector is not in use to protect it from dust.

2. Cleaning the Projector Body

- Wipe the exterior with a soft, dry cloth.
- Do not use liquid cleaners or sprays directly on the projector.

3. Ventilation

- Ensure the ventilation vents are not blocked to prevent overheating.
- · Periodically check and gently clean any dust accumulation on the vents using a soft brush or compressed air.

Troubleshooting

If you encounter issues with your projector, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No image projected	Power not connected Incorrect input source selected Source device not powered on or connected	Check power cable and outlet. Select the correct input source (HDMI, USB). Ensure the source device is on and connected properly.
Image is blurry	Focus not adjusted Projector too close/far from screen	Rotate the focus ring until the image is sharp. Adjust projector distance for optimal image size and clarity.
No sound	Volume too low or muted Incorrect audio output selected Bluetooth device not paired	Increase volume on projector and source device. Check mute settings. Ensure audio output is set to internal speakers or correct external device. Re-pair Bluetooth audio device.
Projector overheats	Blocked ventilation vents Operating in a hot environment	Ensure vents are clear and unobstructed. Operate in a well-ventilated area.

SPECIFICATIONS

Feature	Detail
Model Number	EVP-2002
Brand	Emerson
Product Dimensions	6.75 x 4.12 x 4.98 inches
Item Weight	1.43 pounds
Display Resolution	1280 x 720
Connectivity Technology	Bluetooth
Special Feature	Built-In Speaker
Recommended Uses	Business, Education, Gaming, Home Cinema
Manufacturer	Naxa Electronics, Inc.

PRODUCT VIDEOS

Emerson EVP-2002 Product Video - 360 Spin

Your browser does not support the video tag.

Video: A 360-degree view of the Emerson EVP-2002 projector, showcasing its design and various angles. This video provides a comprehensive visual overview of the product's exterior.

WARRANTY AND SUPPORT

Warranty Information

For detailed warranty information, please refer to the warranty card included with your product or visit the official Emerson website. Keep your purchase receipt as proof of purchase for any warranty claims.

Customer Support

If you require further assistance, technical support, or have questions not covered in this manual, please contact Emerson customer support. Contact details can typically be found on the product packaging, the official Emerson website, or the warranty card.

© 2025 Emerson. All rights reserved. Specifications are subject to change without notice.

Related Documents - EVP-2002



Emerson 110" Home Theater 480P LCD Projector EVP-1001 User Manual

User manual for the Emerson 110" Home Theater 480P LCD Projector (EVP-1001). Provides setup, operation, safety instructions, and connection guides for the Emerson projector.



Emerson EVP-1000 150-Inch Home Theater LCD Projector User Manual

Comprehensive user manual for the Emerson EVP-1000 150-inch Home Theater LCD Projector, detailing setup, operation, safety instructions, and specifications. Visit emersonaudio.com for more.



Emerson EVP-2000 150-Inch Home Theater LCD Projector User Manual

Comprehensive user manual for the Emerson EVP-2000 150-inch Home Theater LCD Projector. Covers setup, operation, features, connectivity options (HDMI, VGA, AV, Bluetooth), and troubleshooting for an enhanced home cinema experience.



Emerson LC260EM2 26-inch LCD TV Owner's Manual

Comprehensive owner's manual for the Emerson LC260EM2 26-inch LCD TV, covering setup, operation, features, connections, troubleshooting, and safety information.

