



[Manuals.plus](#) /

> [PetSnowy](#) /

> PetSnowy 13.5L Automatic Vacuum Sealing Pet Food Storage Container User Manual

PetSnowy Vacuum Storage Container 13.5L

PetSnowy 13.5L Automatic Vacuum Sealing Pet Food Storage Container User Manual

Brand: PetSnowy | Model: Vacuum Storage Container 13.5L

INTRODUCTION

This manual provides essential information for the safe and efficient use of your PetSnowy 13.5L Automatic Vacuum Sealing Pet Food Storage Container. Please read these instructions carefully before first use and retain them for future reference.

This container is designed to preserve the freshness of pet food by creating a vacuum seal, protecting it from moisture, oxidation, and pests.

PRODUCT FEATURES

- **High-Efficiency Vacuum Technology:** Achieves a maximum negative pressure difference of -20kPa, effectively blocking air and moisture to maintain optimal food quality. This technology significantly extends the freshness of stored food.

高効率真空技術

負圧差は最大-20kpa
食品の新鮮さを保持




Image: High-efficiency vacuum technology in action, illustrating air being removed from the container to preserve food freshness.

- **Automatic Vacuum Sealing:** The container automatically creates a vacuum seal when the lid is closed, ensuring pet food remains dry and crisp for extended periods, preventing moisture and oxidation.

自動真空密封

毎回使用時に乾燥と
サクサク感を簡単に保つ



Image: A dog sits calmly beside the PetSnowy container, demonstrating its seamless integration into a pet-friendly home environment and its automatic sealing function.

- **Low Noise Operation:** The vacuum pump operates quietly, minimizing disturbance to daily life and ensuring a peaceful environment for both pets and owners.

低騒音操作

静かに作動し
日常生活の邪魔はしません




Image: A cat sleeps undisturbed next to the PetSnowy container, highlighting its quiet operation.

- **Detachable Charging Design:** The vacuum pump unit features a Type-C interface and is detachable, allowing for convenient individual charging without needing to move the entire storage tank.

取り外し可能な充電設計

Type-Cインターフェースで充電可能
ストレージタンクを移動する必要なし



Image: The detachable Type-C charging unit is shown, emphasizing its ease of removal and charging.

- **Large Capacity Design:** With a capacity of 13.5 liters, this container is suitable for storing various dry pet foods and freeze-dried foods, accommodating substantial quantities.

大容量設計

さまざまなドライフードや
フリーズドライ食品に適応



Image: The PetSnowy container prominently displays its 13.15L capacity, showcasing its ability to hold a large volume of pet food.

- **High-Quality Materials:** The storage tank is constructed from premium food-grade melamine material, ensuring safety, durability, and long-term reliability.

高品質な素材

高級食品グレードのメラミン素材を使用
安全で耐久性あり



Image: An exploded view of the container's components and a cat being fed, illustrating the high-quality, food-grade materials used in its construction.

- **Low Battery Notification:** A red indicator light flashes when the vacuum pump's battery is low, prompting you to recharge and prevent interruptions in use.

PARTS LIST

- Main Storage Unit (Container)
- Vacuum Pump Unit (integrated into lid)
- Type-C Charging Cable (not explicitly listed but implied by "rechargeable")

SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Inspect for any damage.
2. **Initial Cleaning:** Before first use, wash the main storage unit and lid (excluding the vacuum pump unit) with mild soap and water. Rinse thoroughly and dry completely. The vacuum pump unit is not dishwasher safe and should not be submerged in water.
3. **Initial Charge:** Ensure the detachable vacuum pump unit is fully charged using the provided Type-C charging cable.

The indicator light will change to show a full charge.

4. **Placement:** Place the container on a stable, flat surface away from direct sunlight and heat sources.

OPERATION

1. **Adding Food:** Open the lid and pour your pet's dry food or freeze-dried food into the container. Do not overfill beyond the maximum fill line.
2. **Sealing:** Close the lid firmly. The automatic vacuum pump will activate, removing air from the container to create a vacuum seal. This process typically takes 20-30 seconds.
3. **Opening:** To open the container, press the release button on the lid (if applicable, or follow specific instructions on the device to release the vacuum). Once the vacuum is released, lift the lid.
4. **Recharging:** When the low battery indicator light flashes red, detach the vacuum pump unit and connect it to a power source using the Type-C charging cable.

Your browser does not support the video tag.

Video: This video demonstrates the process of using the PetSnowy Vacuum Storage Container, including adding food and activating the vacuum seal.

MAINTENANCE

- **Cleaning the Container:** Regularly clean the main storage unit with mild soap and water. Ensure it is completely dry before adding new food.
- **Cleaning the Lid and Vacuum Pump:** Wipe the lid and the exterior of the vacuum pump unit with a damp cloth. Do not submerge the vacuum pump unit in water or place it in a dishwasher.
- **Seal Inspection:** Periodically check the silicone seal around the lid for any damage or debris that could compromise the vacuum seal. Clean or replace if necessary.
- **Storage:** When not in use, store the container in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Container does not vacuum seal.	Lid not closed properly; Seal is dirty or damaged; Vacuum pump battery is low.	Ensure lid is firmly closed; Clean or inspect the silicone seal; Recharge the vacuum pump unit.
Vacuum pump is not operating.	Battery is depleted; Unit is not properly attached.	Recharge the vacuum pump unit; Ensure the vacuum pump unit is securely attached to the lid.
Red light is flashing.	Low battery.	Recharge the vacuum pump unit using the Type-C cable.

SPECIFICATIONS

Feature	Detail
Brand	PetSnowy
Model	Vacuum Storage Container 13.5L
Color	White

Feature	Detail
Material	Acrylonitrile Butadiene Styrene (ABS)
Capacity	13.5 Liters
Product Dimensions (L x W x H)	32 cm x 39 cm x 39 cm
Special Features	Sealed, Automatic Vacuum, Rechargeable
Container Shape	Square
Dishwasher Safe	No
Microwave Safe	No
Country of Origin	China

SAFETY INFORMATION

- Do not immerse the vacuum pump unit in water or any other liquid.
- Keep out of reach of children and pets to prevent accidental operation or damage.
- Use only the provided or a compatible Type-C charging cable for recharging.
- Do not attempt to disassemble or repair the vacuum pump unit yourself. Contact customer support if issues arise.
- Ensure the container is placed on a stable surface to prevent tipping.
- This product is intended for dry pet food and freeze-dried food storage only. Do not store liquids or other perishable items that require refrigeration.

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the product packaging or contact PetSnowy customer service directly. Keep your purchase receipt as proof of purchase.