



[Manuals.plus](#) /

› [SUNJOM](#) /

› SUNJOM Freepods Over-Ear Headphones User Manual

SUNJOM Freepods

SUNJOM Freepods Over-Ear Headphones User Manual

Model: Freepods

Brand: SUNJOM

1. INTRODUCTION

Thank you for choosing SUNJOM Freepods Over-Ear Headphones. These headphones are designed to provide a high-quality audio experience with advanced features such as Active Noise Cancellation (ANC), Bluetooth 5.4 connectivity, and extended battery life. This manual will guide you through the setup, operation, and maintenance of your new headphones.



Image: SUNJOM Freepods Over-Ear Headphones in Silver.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- SUNJOM Freepods Over-Ear Headphones
- Charging Cable (Type-C)
- 3.5mm Audio Cable
- User Manual

3. PRODUCT OVERVIEW

The SUNJOM Freepods headphones feature an ergonomic design for comfortable wear and intuitive controls for easy operation. Familiarize yourself with the main components and controls:




Image: Detailed diagram of headphone controls for playback, volume, and ANC.

Your browser does not support the video tag.

Video: Official product overview of SUNJOM FreePods 120H Playtime Wireless Over-Ear Headphones, highlighting key features and design.

Key Features:

- **Active Noise Cancellation (ANC):** Reduces external environmental noise for an immersive listening experience.
- **Transparency Mode:** Allows you to hear your surroundings while enjoying audio.
- **Bluetooth 5.4:** Ensures stable and seamless wireless connection with a range of up to 33 feet (10 meters).
- **120-Hour Playtime:** Extended battery life for long listening sessions (ANC off, 50% volume).
- **Built-in Microphone:** Provides clear audio for hands-free calls and video conferences.
- **Multipoint Connection:** Connects to two devices simultaneously, allowing seamless switching between them.
- **40mm Dynamic Drivers:** Delivers hi-fi stereo audio with rich bass and clear sound.

4. SETUP

4.1 Charging the Headphones

Before first use, fully charge your headphones. A full charge takes approximately 4 hours and provides up to 120 hours of playtime (with ANC off at 50% volume).

1. Connect the provided Type-C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power source (e.g., computer, wall adapter).
3. The LED indicator will show the charging status and turn off when fully charged.

120-HOUR PLAYTIME

120
hours



1895 songs

60 movie

8 long haul flight

Image: Graphic illustrating the 120-hour battery life of SUNJOM Freepods headphones.

4.2 Bluetooth Pairing

Pair your headphones with your device using Bluetooth 5.4 technology for a stable connection.

1. Ensure the headphones are charged and powered off.
2. Press and hold the power button (refer to Product Overview for button location) until the LED indicator flashes, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "FreePods" from the list of devices.
5. Once connected, the LED indicator will change to a steady light or flash slowly.

ADVANCED BLUETOOTH 5.4 WIRELESS TECHNOLOGY

Make your connection more stable and faster



Image: The SUNJOM Freepods headphones connected wirelessly to a smartphone, demonstrating Bluetooth 5.4 technology.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Press and hold the power button for approximately 3 seconds until the LED indicator lights up.
- **Power Off:** Press and hold the power button for approximately 5 seconds until the LED indicator turns off.

5.2 Music Playback

- **Play/Pause:** Press the multi-function button once.
- **Next Track:** Double-press the multi-function button.
- **Previous Track:** Triple-press the multi-function button.
- **Volume Up/Down:** Use the volume dial (refer to Product Overview for location).

5.3 Active Noise Cancellation (ANC) and Transparency Mode

The headphones offer two distinct listening modes:

- **Activate ANC:** Press the ANC button once to enable Active Noise Cancellation. This mode reduces ambient noise.
- **Activate Transparency Mode:** Press the ANC button again to switch to Transparency Mode, allowing you to hear your surroundings.
- **Deactivate ANC/Transparency:** Press the ANC button a third time to turn off both modes.



Image: A person wearing SUNJOM Freepods headphones, illustrating the active noise cancellation feature.

5.4 Call Management

- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button for 2 seconds.

5.5 Multipoint Connection

The headphones can connect to two Bluetooth devices simultaneously, allowing you to seamlessly switch between them.

1. Pair the headphones with the first device (e.g., smartphone) as described in Section 4.2.
2. Disconnect Bluetooth on the first device.
3. Pair the headphones with the second device (e.g., laptop).
4. Reconnect Bluetooth on the first device. The headphones will now be connected to both devices.

5. Audio will automatically switch to the device that is actively playing sound or receiving a call.

MULTIPOINT CONNECTION

Seamlessly pair and switch between two devices with no hassle.



Image: SUNJOM FreePods headphones connected to a smartphone and a laptop, demonstrating multipoint connection.

5.6 Wired Mode

If the battery runs out or for wired connection, use the included 3.5mm audio cable.

- Connect one end of the 3.5mm audio cable to the headphone's audio jack.
- Connect the other end to your audio source's 3.5mm port.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Water:** Do not expose the headphones to water or excessive moisture.

7. TROUBLESHOOTING

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source and try again.
Cannot pair with a device.	Ensure Bluetooth is enabled on your device. Make sure the headphones are in pairing mode (LED flashing). Move the headphones closer to your device. Forget "Freepods" from your device's Bluetooth list and try pairing again.
No sound or low volume.	Adjust the volume on both the headphones and your connected device. Ensure the headphones are properly connected via Bluetooth or the 3.5mm cable. Check if the audio source is playing.
ANC is not working effectively.	Ensure the ANC mode is activated. Check that the earcups form a good seal around your ears.

8. SPECIFICATIONS

Feature	Detail
Model Name	Freepods
Noise Control	Active Noise Cancellation, Transparency Mode
Connectivity Technology	Wired, Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.4
Bluetooth Range	10 Meters (33 feet)
Audio Driver Type	Dynamic Driver
Audio Driver Size	40 Millimeters
Frequency Response	2.48 GHz
Sensitivity	120 dB
Impedance	32 Ohms
Battery Life	Up to 120 Hours (ANC off, 50% volume)
Charging Time	4 Hours
Headphones Jack	3.5 mm Jack
Control Type	Button Control
Material	Leather, Metal, Plastic
Item Weight	8.5 ounces (0.53 Pounds)
Product Dimensions	8.27 x 7.48 x 1.97 inches

9. WARRANTY AND SUPPORT

SUNJOM products are designed and manufactured to the highest quality standards. For detailed warranty information and customer support, please refer to the warranty card included in your package or visit the official SUNJOM website.

If you encounter any issues or have questions regarding your Freepods headphones, please contact SUNJOM customer service for assistance.