



Manuals.plus /

› Xgody /

› Xgody S200 Big Button Flip Phone User Manual

## Xgody S200

# Xgody S200 Big Button Flip Phone

User Manual

## 1. PRODUCT OVERVIEW

---

The Xgody S200 is a user-friendly flip phone specifically designed for seniors and individuals who prefer simplicity and ease of use. It features a large keypad, a clear 2.4-inch color display, and a loud speaker for enhanced accessibility.



Figure 1.1: Xgody S200 Big Button Flip Phone, open, displaying its screen and large keypad.

### Key Features:

- **Large Buttons & Clear Display:** Easy-to-read UI with enlarged fonts and icons.
- **Loud Speaker:** High-volume speaker for clear conversations.
- **Long-lasting Battery:** 1300mAh battery providing up to 200 hours standby and 6 hours talk time.
- **Type-C Charging:** Convenient and modern charging interface.
- **Dual SIM Support:** Flexible management of communication needs.
- **SD Card Expansion:** For additional storage.
- **Multi-functional Tools:** Built-in flashlight, FM radio, and Bluetooth.

- **SOS Emergency Calls:** Supports up to 5 emergency contacts for quick access.
- **Durable Flip Design:** Protects the screen and enhances portability.

## 2. SAFETY INFORMATION

---

Please read this safety information carefully before using your Xgody S200 phone to ensure safe and proper operation. Keep this manual for future reference.

- **Battery Safety:** Use only the original or approved charger and battery. Do not short-circuit, puncture, or expose the battery to extreme temperatures. Dispose of batteries properly.
- **Charging:** Ensure the charger is connected to a compatible power source. Do not charge in damp conditions.
- **Hearing Protection:** Avoid prolonged exposure to high volume levels to prevent hearing damage.
- **Driving Safety:** Do not use your phone while driving. Always prioritize road safety.
- **Medical Devices:** Maintain a safe distance between the phone and medical devices like pacemakers. Consult your physician and medical device manufacturer for specific guidelines.
- **Water Resistance:** This phone is not waterproof. Avoid exposure to liquids.

## 3. GETTING STARTED

---

### 3.1 Package Contents

Verify that all items are present in your product package:

- Xgody S200 Flip Phone
- Phone Case
- Screen Protector
- USB Cable (Type-C)
- Lanyard

### 3.2 Battery Installation and Charging

The Xgody S200 comes with a 1300mAh Lithium Ion battery. For optimal performance, fully charge the battery before first use.

1. Open the back cover of the phone.
2. Insert the battery, ensuring the gold contacts align with the phone's terminals.
3. Replace the back cover.
4. Connect the provided Type-C USB cable to the phone's charging port and the other end to a compatible USB power adapter.
5. The phone will indicate charging status on the screen. A full charge typically takes a few hours.

# SOS Emergency Calls

Support 5 Family Numbers  
--Guarantee The Safety of The Elderly




Figure 3.1: Charging the Xgody S200 via Type-C port.

## 3.3 SIM Card and SD Card Installation

The S200 supports dual SIM cards (2G GSM networks) and a microSD card for expandable storage.

1. Power off the phone and remove the back cover and battery.
2. Locate the SIM card slots. Insert your SIM cards into the designated slots, ensuring the gold contacts face downwards.
3. If using an SD card, insert it into the microSD card slot until it clicks into place.
4. Replace the battery and back cover.

# XGODY S200



2 SIM Card



Speed Dial



Foldable Phone



2.4"HD Phone

Figure 3.2: The Xgody S200 supports dual SIM cards.

## 4. OPERATING YOUR PHONE

### 4.1 Power On/Off

- **To Power On:** Press and hold the Power/End Call button (red button) until the screen lights up.
- **To Power Off:** Press and hold the Power/End Call button until the power-off options appear, then select 'Power off'.

### 4.2 Making and Receiving Calls

The large buttons and clear audio make calling simple.

- **To Make a Call:** Dial the number using the keypad and press the Call button (green button).
- **To Receive a Call:** When the phone rings, press the Call button to answer.
- **To End a Call:** Press the Power/End Call button.

## 2G Basic Mobile Phone

Please make sure your card support 2G network



Figure 4.1: Using the Xgody S200 for calls, demonstrating ease of use with large buttons.

# Phone volume is loud and clear

It is more convenient for the elderly to hear the conversation clearly when calling!




Figure 4.2: The Xgody S200 provides loud and clear phone volume.

## 4.3 SOS Emergency Calls

The SOS function allows you to quickly contact pre-set emergency numbers.

- **Setting Up SOS Contacts:** Navigate to the SOS settings in the phone's menu to add up to 5 emergency contact numbers.
- **Activating SOS:** In standby mode, press and hold the dedicated SOS button (usually located on the back or side of the phone) for 3 seconds. The phone will automatically dial the pre-set emergency contacts in sequence until one answers.



Figure 4.3: SOS Emergency Call feature for quick assistance.

#### 4.4 Flashlight

The built-in flashlight provides convenient illumination.

- **To Turn On/Off:** Press and hold the dedicated flashlight button (often a side button or a key on the keypad) for 3 seconds.

# Flip Phone

The unique design makes the phone more convenient to carry. Folding angle 180° and exquisite appearance are irresistible



Figure 4.4: Activating the flashlight on the Xgody S200.

## 4.5 FM Radio

The phone includes a built-in FM radio for entertainment.

- **Accessing FM Radio:** Navigate to the 'FM Radio' option in the phone's main menu.
- **Using Headphones:** For best reception, connect headphones (not included) to the 3.5mm audio jack, as they often act as an antenna.

## 4.6 Bluetooth

Connect your phone to other Bluetooth-enabled devices.

- **Enabling Bluetooth:** Go to 'Settings' and then 'Bluetooth' to turn it on.
- **Pairing Devices:** Search for available devices and select the one you wish to pair with. Follow on-screen prompts to complete the pairing process.

## 5. CARE AND MAINTENANCE

---

Proper care will extend the life of your Xgody S200 phone.

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** While durable, avoid dropping the phone. The flip design offers screen protection when closed.
- **Battery Care:** Do not leave the phone connected to the charger for excessively long periods after it is fully charged.

# 1300mAh Large Capacity Battery

Super long standby time, no need for frequent charging



# 1300mAh




Figure 5.1: The durable flip design protects the screen.

## 6. TROUBLESHOOTING

---

If you encounter issues with your Xgody S200, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Phone does not power on	Battery is drained or not properly installed.	Charge the battery for at least 30 minutes. Ensure the battery is correctly inserted.
Cannot hear calls clearly / Low speaker volume	Volume setting is too low; speaker obstructed; network issue.	Increase the call volume using the side buttons. Ensure the speaker is not covered. Check network signal strength.
Cannot make or receive calls	No SIM card; SIM card not activated; out of network coverage.	Ensure SIM card is inserted correctly. Contact your network provider to activate SIM. Move to an area with better network coverage.
Battery drains quickly	Frequent usage; background features active; aging battery.	Reduce screen brightness. Turn off Bluetooth when not in use. Limit continuous talk time.

## 7. PRODUCT SPECIFICATIONS

---

Feature	Specification
Model Name	XGODY S200
Brand	Xgody
Operating System	Nucleus OS
Screen Size	2.4 Inches
Battery Capacity	1300mAh Lithium Ion (included)
Charging Port	Type-C
Wireless Carrier	Unlocked for All Carriers
Cellular Technology	2G GSM
SIM Card Slot Count	Dual SIM
Memory Storage Capacity	0.03 GB (internal)
Package Dimensions	21.1 x 9.2 x 5.2 cm
Item Weight	260 g
Manufacturer	XGODY

## 8. WARRANTY AND SUPPORT

---

For warranty information and technical support, please refer to the documentation provided with your purchase or contact your retailer. Keep your proof of purchase for warranty claims.

If you require further assistance or have questions not covered in this manual, please reach out to Xgody customer

service or the authorized dealer from whom you purchased the product.