

[Manuals.plus](#) /

> [Clforczh](#) /

> Clforczh Head Shaver 8780 User Manual

Clforczh 8780

Clforczh Head Shaver 8780 User Manual

MODEL: 8780

Product Overview

The Clforczh Head Shaver 8780 is an advanced electric rotary shaver designed for bald men, offering a fast, close, and comfortable shaving experience. It features a revolutionary 7D magnetic blade system for easy cleaning, IPX6 waterproofing for wet and dry use, an intuitive LED display for battery status, and convenient USB-C fast charging. This kit provides a complete grooming solution for head, face, and beard.



Image: The Clforczh Head Shaver 8780, showcasing its sleek design and packaging.

1. Setup

1.1 Unboxing and Initial Charge

Upon opening the premium gift box, you will find the head shaver unit, the 7D magnetic blade head, a USB-C charging cable, and a cleaning brush. Before the first use, it is essential to fully charge the shaver. Connect the USB-C cable to the shaver's charging port and plug the other end into a compatible USB power source (e.g., laptop, car charger, power bank). The LED display will illuminate to show the charging status and current battery percentage. A complete charge typically takes approximately 1.5 hours, providing up to 120 minutes of runtime.

Your browser does not support the video tag.

Video: An overview of the Clforczh Head Shaver, demonstrating its features and accessories.

1.2 Attaching the Shaving Head

The Clforczh Head Shaver features a revolutionary 7D magnetic blade system that allows for effortless attachment and detachment of the shaving head. To attach, simply align the shaving head with the main unit; the magnets will securely snap it into place. Ensure it is firmly seated before use.



Image: The magnetic detachment feature of the shaving head, highlighting its ease of use.

2. Operating Instructions

2.1 Powering On/Off and Travel Lock

- **To Power On:** Press the power button located on the top of the shaver. The LED display will show the current battery percentage.
- **To Power Off:** Press the power button again.
- **To Activate Travel Lock:** Press and hold the power button for 3 seconds until a lock icon appears on the LED display. This feature prevents accidental activation during travel or storage.
- **To Unlock:** Press and hold the power button for 3 seconds until the lock icon disappears from the LED display.



Image: The shaver's LED display indicating battery level and travel lock status.

2.2 Shaving Techniques (Wet & Dry)

The Clforzh Head Shaver 8780 is versatile, supporting both wet and dry shaving methods. Its 7D flexible blades with 360° full coverage are designed to glide effortlessly over the contours of your head, face, and neck.

- **Dry Shaving:** Ensure your skin is clean and completely dry. Gently press the shaver against your skin and move it in small, circular motions.
- **Wet Shaving:** For a smoother and more comfortable shave, apply shaving foam or gel to your skin. The IPX6 waterproof design allows for safe and convenient use in the shower. Rinse the shaver head under running water periodically during your shave to prevent hair buildup and maintain optimal performance.



Image: The shaver's IPX6 waterproof design, suitable for wet shaving.

Wet/Dry Shaving

IPX6



Image: Demonstrating the shaver's ability to be used safely and effectively in the shower.



Image: A user demonstrating the shaver's ergonomic design for head shaving.

3. Maintenance

3.1 Cleaning the Shaver Head

Regular cleaning is crucial for maintaining the shaver's performance and hygiene. The 7D magnetic blade system makes cleaning exceptionally easy.

1. **Detach the Head:** Simply pull the shaving head away from the main unit. The magnetic connection will release easily.
2. **Rinse Thoroughly:** Rinse the detached shaving head under running water for approximately 3 seconds. This action effectively removes 99% of hair residue and bacteria.
3. **Brush Cleaning (for dry hair):** For dry hair removal, use the provided cleaning brush to dislodge any trapped hairs from the blades and the contact points on the main unit.
4. **Drying:** Ensure the shaving head is completely dry before reattaching it to the main unit or storing the shaver.

Cordless & Type-C Charging

Includes USB Cable and Charger, 90-minute battery life per charge.

150 mins
Charging Time

120 mins
Runing Time

 Travel
Lock



Image: The included cleaning brush, ideal for removing dry hair from the shaver blades.

3.2 Battery Care

To maximize the lifespan of your shaver's 800mAh battery:

- Avoid completely draining the battery before recharging.
- Store the shaver in a cool, dry place when not in use.
- The shaver provides up to 120 minutes of runtime on a 1.5-hour fast charge.

4. Troubleshooting

4.1 Shaver Not Turning On

- **Check Battery:** Ensure the shaver has sufficient charge. The LED display will indicate the battery level. Recharge if the battery is low.
- **Travel Lock:** Verify that the travel lock feature is not activated. Press and hold the power button for 3 seconds to unlock the shaver.

4.2 Poor Shaving Performance

- **Clean Blades:** Accumulated hair and debris can significantly impact shaving efficiency. Detach and thoroughly clean the shaving head as described in the Maintenance section.

- **Blade Wear:** Over extended use, the blades may become dull. If cleaning does not improve performance, consider replacing the shaving head.
- **Proper Technique:** Ensure you are using the recommended small, circular motions and applying gentle, consistent pressure for optimal results.

4.3 Water Leakage

While the shaver boasts an IPX6 waterproof rating, it is crucial to ensure the shaving head is properly attached and sealed to the main unit before any wet use or rinsing. If water inadvertently enters the main unit, immediately power off the device and allow it to dry completely in a well-ventilated area before attempting to use it again.

5. Specifications

Feature	Detail
Brand	Ciforczh
Model Name	8780
Product Dimensions	3.15 x 3.15 x 3.94 inches; 1.32 Pounds
Power Source	Battery Powered
Battery Capacity	800mAh
Charging Time	1.5 hours (Fast Charge)
Runtime	120 minutes
Waterproof Rating	IPX6
Special Features	Portable, Waterproof, Detachable Head, Floating Head, Battery Indicator
Recommended Uses	Beard, Scalp, Face

6. Warranty and Support

The Ciforczh Head Shaver 8780 comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of the warranty. For technical support, troubleshooting assistance, or to make a warranty claim, please contact Ciforczh customer service. Contact information can typically be found in your product documentation or on the official Ciforczh website.

6.1 Safety Information

For your safety and to ensure the longevity of your device, please adhere to the following safety guidelines:

- Always unplug the shaver before using it near water, especially when charging.
- After each use, rinse the shaver under running water and clean it thoroughly to prevent bacterial growth and maintain hygiene.
- Always follow the cleaning and maintenance instructions provided in this manual and with the shaver's packaging.