

## Novalife B0F13LLTTJ

# Novalife Rotating Belgian Waffle Maker Instruction Manual

Model: B0F13LLTTJ

## INTRODUCTION

Thank you for choosing the Novalife Rotating Belgian Waffle Maker. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read all instructions carefully before first use and retain this manual for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.

11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
12. To disconnect, turn any control to "off," then remove plug from wall outlet.
13. Do not use appliance for other than intended use.

## PRODUCT COMPONENTS

Familiarize yourself with the parts of your Novalife Waffle Maker:

- **Waffle Plates:** Non-stick cooking surfaces for Belgian waffles.
- **Browning Control Knob:** Adjusts waffle crispness from light to dark.
- **Power Indicator Light (Red):** Illuminates when the unit is powered on.
- **Ready Indicator Light (Green):** Illuminates when the unit is preheated and ready to cook.
- **Cool-Touch Handle:** For safe handling and flipping.
- **Locking Buckle:** Secures the handle for compact storage.
- **Removable Drip Tray:** Collects excess batter for easy cleanup.
- **Non-Slip Feet:** Provides stability during use.
- **180° Rotating Design:** Allows for even batter distribution and cooking.



Overview of the Novalife Rotating Belgian Waffle Maker, highlighting its 1100W power, LED indicator lights, non-stick

plates, and locking buckle.

## SETUP

1. Unpack the waffle maker and remove all packaging materials.
2. Wipe the non-stick cooking plates with a damp cloth and dry thoroughly.
3. Place the waffle maker on a stable, heat-resistant surface.
4. Ensure the removable drip tray is correctly positioned beneath the waffle plates.
5. Plug the power cord into a standard 120V AC electrical outlet. The red Power indicator light will illuminate.

## OPERATING INSTRUCTIONS

### Preheating


1. Close the waffle maker and set the browning control knob to your desired setting (from Min to Max).
2. Allow the unit to preheat. The green Ready indicator light will illuminate when the waffle maker has reached the optimal cooking temperature.

### Cooking Waffles

1. Once the green Ready light is on, open the waffle maker.
2. Pour approximately 1 cup of waffle batter onto the center of the bottom waffle plate. Distribute evenly.
3. Close the waffle maker.
4. Immediately rotate the waffle maker 180 degrees using the cool-touch handle. This ensures even batter distribution and consistent cooking on both sides.
5. Cook for approximately 3-6 minutes, or until the green Ready light illuminates again, indicating the waffle is done according to your selected browning level.
6. Open the waffle maker and carefully remove the cooked waffle using a non-metallic utensil.
7. Close the waffle maker to maintain heat for subsequent waffles.



Visual guide demonstrating the process of pouring batter, closing, rotating, and enjoying waffles.



## CUSTOMIZE TO YOUR TASTE

Get waffles of different colors and textures by adjusting the control knob

The browning control knob allows customization of waffle crispness, from light to dark.

## CLEANING AND MAINTENANCE

Proper cleaning and maintenance ensure the longevity and performance of your waffle maker.

1. Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. Remove the drip tray and wash it with warm, soapy water. It is dishwasher safe.
3. Wipe the non-stick cooking plates with a damp cloth or sponge. For stubborn residue, use a small amount of cooking oil to soften it, then wipe clean. Do not use abrasive cleaners or metal scouring pads, as these can damage the non-stick coating.
4. Wipe the exterior of the waffle maker with a damp cloth. Do not immerse the appliance in water or any other liquid.
5. Ensure all parts are thoroughly dry before storing.



## NON-STICK COATING


Wipe off residual grease thoroughly with a wet cloth

Cleaning the non-stick plates with a damp cloth for easy maintenance.

## STORAGE

The Novalife Waffle Maker features a compact design for convenient storage.

- Ensure the appliance is clean and completely cool before storing.
- Fold the cool-touch handle into its upright position and secure it with the locking buckle.
- Store the waffle maker vertically in a cabinet or on a shelf to save space.



The waffle maker's foldable handle allows for compact, vertical storage in a cabinet.

## TROUBLESHOOTING

If you encounter issues with your waffle maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Waffle maker does not turn on.	Not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working outlet.
Waffles are not cooking evenly.	Insufficient batter; improper rotation; uneven preheating.	Ensure sufficient batter is used and the unit is rotated 180 degrees after closing. Allow full preheating until the green light illuminates.
Waffles stick to plates.	Plates not properly seasoned; too little oil/butter in batter; plates not clean.	Ensure plates are clean. Lightly brush plates with cooking oil before each use, especially for the first few waffles.

Problem	Possible Cause	Solution
Excess batter overflows.	Too much batter used.	Reduce the amount of batter. Approximately 1 cup is recommended. The drip tray will catch minor overflows.

If the problem persists, please contact Novalife customer support.

## SPECIFICATIONS

Feature	Detail
Brand	Novalife
Model Number	B0F13LLTTJ
Power	1100 Watts
Voltage	120 Volts
Material	Stainless Steel
Special Features	Double Side Heating, 180° Rotating Design, Adjustable Browning Control, Non-Stick Coating, Removable Drip Tray, Foldable Cool Touch Handle
Number of Settings	5 (Browning Control)
UPC	717967491825

## WARRANTY AND SUPPORT

This Novalife Waffle Maker comes with a limited warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or contact Novalife customer support.

For technical assistance, troubleshooting, or any product-related inquiries, please contact Novalife customer support through the retailer where the product was purchased or visit the official Novalife website.