

HOOBRO WW25BZ01

HOOBRO Folding TV Tables (Set of 2) Instruction Manual

Model: WW25BZ01

INTRODUCTION

Thank you for choosing the HOOBRO Folding TV Tables. This set of two versatile tables is designed to provide convenient surface space for various activities, such as dining, working on a laptop, or holding beverages. Their foldable design allows for easy storage and portability. Please read this manual carefully before assembly and use to ensure safe and proper operation.

SAFETY INFORMATION

- Children should not stand or climb on the product.
- Do not exceed the maximum recommended weight capacity of 10 kg (22 lbs) per table.
- Ensure the table is fully unfolded and stable before placing items on it.
- Avoid placing hot items directly on the table surface without protection.
- Keep away from open flames and direct heat sources.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Folding Table Top (x2)
- Folding Leg Frame (x2)
- Assembly Hardware (screws, Allen key, etc.)

SETUP AND ASSEMBLY

The HOOBRO Folding TV Tables are designed for simple and quick assembly. All necessary tools are included.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Table Top to Frame:** Align the pre-drilled holes on the table top with the corresponding holes on the folding leg frame. Secure the table top to the frame using the provided screws and Allen key. Ensure all screws are tightened firmly but do not overtighten.
3. **Repeat for Second Table:** Follow the same steps to assemble the second folding table.




Image: Dimensions of the HOOBRO folding table, illustrating its height, width, and depth for reference.



Image: Detailed view of the folding mechanism, highlighting the points where the legs lock into place when unfolded.

OPERATING INSTRUCTIONS

Unfolding the Table:

1. Place the folded table on a flat surface.
2. Gently pull the leg frames outwards until they fully extend and lock into position. You may need to apply a slight force to ensure the locking mechanism engages securely.
3. Verify that all four legs are stable and the table top is level before use.

Folding the Table for Storage:

1. Remove all items from the table surface.
2. Locate the locking mechanisms on the leg frames. Gently disengage the locks (refer to the assembly image for visual guidance).
3. Fold the leg frames inwards until they are flat against the table top.
4. The folded table can then be stored in a compact space, such as under a sofa or against a wall.



Image: The folding table stored compactly under a sofa, highlighting its easy storage feature.



Image: One table in use next to a sofa, while another is folded and stored vertically, showcasing versatility.

MAINTENANCE

- **Cleaning:** Wipe the table surface with a soft, damp cloth. For stubborn stains, use a mild detergent and dry immediately. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Storage:** When not in use, store the tables in a dry place away from direct sunlight and extreme temperatures to prolong their lifespan.

TROUBLESHOOTING

Problem: Table feels unstable or wobbly.

Solution: Ensure that the leg frames are fully extended and the locking mechanisms are securely engaged. Check all assembly screws and tighten them if loose.

Problem: Difficulty folding or unfolding the table.

Solution: The locking mechanisms may require a firm but gentle force to engage or disengage. Ensure no obstructions are preventing the legs from moving freely. If the mechanism is stiff, a small amount of

silicone lubricant can be applied to the pivot points.

SPECIFICATIONS

Feature	Detail
Model Number	WW25BZ01
Dimensions (Unfolded)	48 cm (L) x 36 cm (W) x 66.5 cm (H) / 18.9" (L) x 14.2" (W) x 26.2" (H)
Weight per Table	5.2 kg (11.46 lbs)
Maximum Weight Recommendation	10 kg (22 lbs)
Frame Material	Metal
Top Material	Engineered Wood
Color	White
Shape	Rectangular
Style	Minimalist

WARRANTY AND SUPPORT

HOOBRO products are designed for quality and durability. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any questions, concerns, or assistance with your product, please contact HOOBRO customer support through the retailer where you purchased the item or visit the official HOOBRO website for contact information.