



[Manuals.plus](#) /

> [MOSKESON](#) /

> MOSKESON 2-Pack Spill Proof Scoop Plate with Non-Skid Suction Base Instruction Manual

MOSKESON Sp tableware-002

MOSKESON 2-Pack Spill Proof Scoop Plate Instruction Manual

Model: Sp tableware-002

1. PRODUCT OVERVIEW

The MOSKESON Spill Proof Scoop Plate is an adaptive dinnerware solution designed to facilitate independent eating for individuals with limited mobility, tremors, or other conditions that make self-feeding challenging. This product features a unique design to minimize spills and a non-skid base for stability during use.

SPILL-PROOF AND NON-SLIP

This spoon bowl/plate features a removable non-slip pad design, ensuring it stays securely in place during use



Image: User demonstrating the MOSKESON Spill Proof Scoop Plate.

2. KEY FEATURES

- **Spill-Proof Design:** Features high edges, deep grooves, and a contoured lip to effectively prevent food from spilling, aiding one-handed eating.
- **Removable Non-Skid Suction Base:** Ensures the plate remains stable and secure on surfaces, reducing the risk of accidental movement or spills. The pad is detachable for easy cleaning.
- **Durable and Safe Material:** Constructed from high-quality, odorless polypropylene, which is heat-resistant and free from Latex and BPA.
- **Dishwasher and Microwave Safe:** Designed for convenience, allowing for easy cleaning and reheating of food.
Note: It is recommended to avoid heating the plastic suction pads in the microwave.
- **User-Friendly:** Suitable for a wide range of users including the elderly, individuals with Parkinson's, those with arm injuries, and children.
- **White Color:** Provides a clear visual contrast, which can assist individuals with low vision in distinguishing food.

PRODUCT FEATURES



Odorless



Removable Suction Pad



Spill-Proof



Non-Slip



Image: Detailed view of product features including the removable suction pad and spill-proof design.



**REGULAR
BOWLS & PLATES**



**HIGH RIMMED
BOWLS & PLATES**



Image: Visual comparison of spill prevention with high-rimmed plates.

DISABILITY-FRIENDLY WHITE COLOR

Clear visual effect, helps seniors
enhance appetite

White Color

Highlights the color of the food,
which helps to enhance the appetite
of the elderly



Image: The white color of the plate enhancing food recognition.

3. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the plates from their packaging.
2. **Initial Cleaning:** Before first use, wash the plates and suction pads thoroughly with warm, soapy water or place them in a dishwasher. Rinse completely and dry.
3. **Attach Suction Pad:** Ensure the bottom of the plate and the suction pad are clean and dry. Align the suction pad with the base of the plate and press firmly to secure it.

4. OPERATING INSTRUCTIONS

1. **Placement:** Place the plate on a clean, dry, and smooth flat surface (e.g., a table or tray).
2. **Secure the Plate:** Press down firmly on the center of the plate to engage the suction base. This will create a vacuum, securing the plate to the surface and preventing accidental movement.
3. **Serving Food:** Place food onto the plate. The high edges and contoured lip are designed to assist in scooping food onto utensils, making it easier to eat independently.

4. **One-Handed Use:** The design supports one-handed eating by providing a stable surface and a barrier against spills.

REDUCE SPILLS AND MESS

A reliable helper for the elderly and Parkinson's patients, effectively reducing food spills and helping you say goodbye to messy dining environments




Image: Demonstrating the plate's effectiveness in reducing spills.

5. MAINTENANCE AND CARE

- **Cleaning:** The plates are dishwasher safe. For hand washing, use warm water and mild dish soap.
- **Microwave Use:** The plates are microwave safe for reheating food. However, to prolong the life of the suction pad, it is recommended to remove it before microwaving.
- **Drying:** Ensure all components are thoroughly dry before storage to prevent bacterial growth.
- **Storage:** Store in a clean, dry place away from direct sunlight.

EAT WITH PEACE OF MIND

Made from high-quality polypropylene, odorless, heat-resistant, and safe for dishwasher and microwave use.



Latex & BPA Free



Easy to Clean



Microwave Safe



Dishwasher Safe



Tip: It is recommended to avoid heating the plastic pads in the microwave

Image: Product dimensions and care instructions.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Plate does not stick to surface.	Surface or suction pad is dirty, wet, or uneven.	Ensure the table surface and the bottom of the suction pad are clean, dry, and smooth. Press down firmly on the plate to create a strong seal.
Food still spills from the plate.	Improper scooping technique or excessive food quantity.	Utilize the high edges and contoured lip for easier scooping. Avoid overfilling the plate.

7. SPECIFICATIONS

Model Number: Sp tableware-002

Product Dimensions: 9.25 x 3.15 x 9.25 inches (L x W x H)

Item Weight: 14.89 ounces (for 2 plates)

Material: High-quality Polypropylene

Color: White

Care Instructions: Dishwasher Safe, Microwave Safe (remove suction pad for microwave)

Included Components: 2 Plates with removable suction bases

8. WARRANTY INFORMATION

This product is covered by the standard manufacturer's warranty. For specific details regarding warranty coverage, duration, and claims process, please refer to the documentation included with your purchase or contact MOSKESON customer support directly.

9. SUPPORT AND CONTACT

For any questions, concerns, or assistance with your MOSKESON Spill Proof Scoop Plate, please contact our customer support team.

Manufacturer: MOSKESON

You can also visit the official MOSKESON store for more information and products: [MOSKESON Store on Amazon](#)