

[Manuals.plus](#) /

› [Inateck](#) /

› Inateck Ultra-Slim Bluetooth Keyboard User Manual

Inateck KB01003

Inateck Ultra-Slim Bluetooth Keyboard User Manual

MODEL: KB01003

INTRODUCTION

Thank you for choosing the Inateck Ultra-Slim Bluetooth Keyboard. This manual provides detailed instructions on how to set up, operate, and maintain your keyboard to ensure optimal performance and a comfortable typing experience across multiple devices.

WHAT'S IN THE BOX

- 1 x Inateck Ultra-Slim Bluetooth Keyboard
- 2 x AAA batteries (included)
- 1 x User Manual

SPECIFICATIONS

Feature	Detail
Product Dimensions	11.22 x 4.72 x 0.63 inches (285mm x 120mm x 17mm)
Item Weight	13 ounces (217g)
Connectivity Technology	Bluetooth
Compatible Devices	Windows, iPadOS, Android, iOS
Battery Life	Up to 18 months (based on 2 hours daily use)
Number of Keys	78
Key Travel	1.5mm
Color	Gray

Feature	Detail
Material	Plastic

SETUP

Battery Installation

Your keyboard comes with two AAA batteries included. To install them:

1. Locate the battery compartment on the back of the keyboard.
2. Open the battery compartment cover.
3. Insert the two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

Bluetooth Pairing

The Inateck keyboard supports connection with up to three devices simultaneously. Follow these steps to pair your keyboard:

1. Turn on the keyboard using the ON/OFF switch.
2. Press and hold the **Fn** key and one of the device keys (**F1**, **F2**, or **F3**) for 3-5 seconds until the corresponding indicator light (blue/orange/green) flashes rapidly. This indicates the keyboard is in pairing mode for that channel.
3. On your device (e.g., iPad, laptop, smartphone), go to Bluetooth settings and search for available devices.
4. Select "Inateck Keyboard" from the list of found devices.
5. If prompted, enter the pairing code displayed on your device using the Inateck keyboard and press **Enter**.
6. Once paired, the indicator light will stop flashing and turn off, indicating a successful connection.

Alternatively, you can press the dedicated **CONNECT** button on the keyboard to initiate pairing for the currently selected channel.

Bluetooth connection



1 Long press:
Pair in this channel

2 Short press:
Switch to this channel



3 Connect button:
Pair in the current channel

Image: Detailed steps for Bluetooth pairing and switching channels (F1, F2, F3) on the Inateck keyboard.

Smart Indicator Lights

The keyboard features colorful indicator lights to provide clear status updates:

- **White Light:** Caps Lock status.
- **Red Light:** Low Battery warning.
- **Flashing (Blue/Orange/Green):** Indicates the keyboard is connecting or in pairing mode.

- **Off:** Indicates a stable connection.

Smart Light Indicator:

○ Caps Lock indicator

● Low battery

●●● Fast flash: connecting
●●● Slow flash: reconnecting
Off: connected



Image: Explanation of the keyboard's smart indicator lights for Caps Lock, low battery, and connection status.

OPERATING INSTRUCTIONS

Multi-Device Switching

To switch between your three connected devices, simply press **Fn + F1**, **Fn + F2**, or **Fn + F3**. The keyboard will seamlessly switch to the corresponding device.

Connect 3 Devices Simultaneously

F1/F2/F3
switch between devices



Image: The keyboard's ability to connect to and switch between three devices simultaneously, such as a laptop, desktop, and tablet.

Compatibility

The Inateck Ultra-Slim Bluetooth Keyboard is designed for broad compatibility, supporting the following operating systems:

- Windows
- iPadOS

- Android
- iOS
- Mac OS
- Fire OS

Compatible with

Windows iPad OS Android
Mac OS Fire OS




Image: Visual representation of the keyboard's compatibility with various operating systems and devices.

The keyboard features a 1.5mm key travel and an ergonomic tilt angle for comfortable typing during extended sessions. Its ultra-slim and lightweight design (217g) makes it highly portable, fitting easily into your bag for on-the-go use.

Tilted design for comfortable typing




Image: Illustration demonstrating the ergonomic tilted design of the keyboard for improved typing posture and comfort.



Only 217g (0.5 lb)



Image: The ultra-slim and compact design of the keyboard, highlighting its portability and small footprint next to a laptop.

Lightweight and Portable

Ready to use anytime



Image: The keyboard being used in various portable scenarios, emphasizing its lightweight and ready-to-use nature.

Battery Life

The keyboard is powered by two AAA batteries, offering an impressive battery life of up to 18 months based on 2 hours of continuous daily use. This design minimizes the need for frequent battery replacements.

Ultra long battery life

Powered by 2*AAA batteries



Image: Visual representation of the keyboard's ultra-long battery life, powered by two AAA batteries.

Official Product Video

Video: An official product video demonstrating the Inateck Bluetooth Keyboard, highlighting its features such as multi-device switching, ergonomic design, and portability. This video is provided by the seller, TNTonline.

MAINTENANCE

To ensure the longevity and optimal performance of your Inateck Ultra-Slim Bluetooth Keyboard, please follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to wipe the keyboard surface. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- **Dust Removal:** Use compressed air to remove dust and debris from between the keys.
- **Storage:** When not in use for extended periods, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries promptly when the low battery indicator (red light) appears to avoid interruption of use. Ensure to use new AAA batteries.
- **Avoid Liquids:** Do not expose the keyboard to liquids. In case of accidental spills, immediately turn off the keyboard, remove batteries, and allow it to dry completely before re-use.

TROUBLESHOOTING

If you encounter any issues with your Inateck Ultra-Slim Bluetooth Keyboard, please refer to the following common solutions:

Problem	Possible Solution
Keyboard does not turn on.	Ensure the ON/OFF switch is in the 'ON' position. Check if the batteries are correctly installed and have sufficient charge. Replace batteries if necessary.
Unable to pair the keyboard.	Make sure the keyboard is in pairing mode (indicator light flashing). Ensure Bluetooth is enabled on your device. Move the keyboard closer to your device. Try forgetting the device on your host device's Bluetooth settings and re-pairing.
Keys are not responding.	Check if the keyboard is connected to the correct device channel (F1/F2/F3). Ensure the keyboard is fully charged or has fresh batteries. Restart both the keyboard and your device.
Connection is unstable or frequently disconnects.	Ensure there are no strong interferences (e.g., Wi-Fi routers, other Bluetooth devices) nearby. Move the keyboard closer to your device. Update Bluetooth drivers on your computer if applicable.
Indicator lights are not working as expected.	Refer to the 'Smart Indicator Lights' section for correct behavior. If the red light is on, replace batteries. If other lights behave erratically, try resetting the keyboard by turning it off and on.

If the issue persists after trying these solutions, please contact Inateck customer support for further assistance.

WARRANTY AND SUPPORT

Inateck products come with a standard manufacturer's warranty. For detailed warranty information, product support, or to register your product, please visit the official Inateck website or contact their customer service team. Keep your purchase receipt as proof of purchase for warranty claims.

You can find more information and support at:www.inateck.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question