

[Manuals.plus](#) /

› [Dawnwake](#) /

› Dawnwake Cordless Rechargeable Table Lamp User Manual

Dawnwake TD3003

Dawnwake Cordless Rechargeable Table Lamp

Model: TD3003

User Manual

1. INTRODUCTION

Thank you for choosing the Dawnwake Cordless Rechargeable Table Lamp. This lamp is designed for versatility and convenience, featuring a portable, rechargeable design with touch-sensitive dimming. Its fabric shade provides a soft, comfortable light, making it ideal for various settings such as bedrooms, living rooms, and offices. This manual provides essential information for the safe and efficient use of your lamp.



Image: The Dawnwake Cordless Rechargeable Table Lamp with its fabric shade and wood-look base, illuminated on a surface.

2. PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present and undamaged. If any items are missing or damaged, please contact customer support.

- 1 x Dawnwake Cordless Table Lamp
 - 1 x USB-C Charging Cable (DC5V/1A)
 - 1 x User Manual
-

PACKING LIST

- 1 x Dawnwake Cordless Table Lamp
- 1 x UsB-C Cable (DC5V/1A)
- 1 x User Manual



Image: A visual representation of the lamp, USB-C cable, and user manual, indicating the items included in the package.

3. SETUP AND FIRST USE

3.1 Initial Charging

Before first use, fully charge the lamp. The lamp is equipped with a 4000mAh rechargeable lithium electronic battery.

1. Connect the provided USB-C charging cable to the charging port located on the lamp's base.
2. Connect the other end of the USB-C cable to a compatible 5V/1A USB power adapter (not included).
3. A blue indicator light will appear at the touch head position on the lamp's base, indicating that charging is in progress.
4. Charging typically takes 4-7 hours for a full charge. The blue indicator light will automatically turn off once the battery is fully charged.

The lamp can be used while charging.

Rechargeable, No Hassle!

 4000MAH BATTERY
OPERATED



Can be Used While Charging



Charging: 4-7 Hours



Brightest: Almost 18 Hours



USB-C: Charge Table Lamp



Image: An illustration detailing the lamp's charging process, highlighting the USB-C port, 4000mAh battery, and charging duration.

4. OPERATING INSTRUCTIONS

The Dawnwake Table Lamp features a sensitive touch-sensitive switch for easy operation and brightness adjustment.

4.1 Power On/Off and Brightness Adjustment

- To Turn On:** Lightly touch the metal area on the lamp's base. The lamp will illuminate at its lowest brightness setting.
- To Adjust Brightness:** Continue to lightly touch the metal area to cycle through the three available brightness levels:
 - **Low Light (20%):** Ideal for bedside use, night light, or creating a subtle ambiance.
 - **Medium Light (50%):** Suitable for general illumination, reading, or daily tasks.
 - **High Light (100%):** Provides maximum brightness for outdoor use, kitchen lighting, or desk work.

3. **To Turn Off:** After cycling through the high light setting, another touch will turn the lamp off.



Image: A visual guide demonstrating the touch-sensitive switch and the three distinct brightness levels (low, medium, high) of the lamp.

5. MAINTENANCE

5.1 Cleaning

To maintain the appearance and functionality of your lamp:

- Ensure the lamp is turned off and disconnected from any charging source before cleaning.
- Wipe the lamp's base and shade with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or fabric.

5.2 Bulb Replacement

The lamp uses a replaceable E26 4W LED bulb. If the bulb needs replacement:

1. Ensure the lamp is turned off and disconnected from any charging source.
2. Carefully remove the fabric shade.
3. Unscrew the old E26 bulb counter-clockwise.
4. Screw in a new E26 4W LED bulb clockwise until secure.
5. Replace the fabric shade.



Image: A close-up view of the lamp's interior, highlighting the replaceable E26 4W Low Voltage LED bulb.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted.	Charge the lamp fully (4-7 hours).
	Bulb is loose or faulty.	Check if the E26 bulb is securely screwed in. Replace if faulty.

Problem	Possible Cause	Solution
Lamp turns off unexpectedly.	Low battery.	Recharge the lamp.
Touch control is unresponsive.	Foreign object or moisture on touch area.	Ensure the touch area is clean and dry.
Blue charging indicator does not light up.	Charging cable or adapter issue.	Try a different USB-C cable or power adapter. Ensure connections are secure.

7. SPECIFICATIONS

Model Number	TD3003
Brand	Dawnwake
Dimensions (L x W x H)	17.8 x 17.8 x 27.9 cm (7 x 7 x 11 inches)
Weight	0.73 kg (1.6 lbs)
Battery Capacity	4000mAh Rechargeable Lithium Electronic Battery
Charging Time	4-7 hours
Operating Time (Fully Charged)	Up to 10-18 hours (depending on brightness setting)
Charging Input	USB-C, DC 5V/1A
Bulb Type	E26 4W LED (Low Voltage, Replaceable)
Shade Material	Linen/Fabric
Base Material	Wood-look (Plastic)
Switch Type	Touch-sensitive
Brightness Levels	3 (Low, Medium, High)

8. SAFETY INFORMATION

- Do not expose the lamp to extreme temperatures, direct sunlight, or high humidity.
- Keep the lamp away from water and liquids to prevent electric shock or damage.
- Do not attempt to disassemble or modify the lamp. This will void the warranty and may cause damage or injury.
- Use only the provided USB-C cable and a compatible 5V/1A USB power adapter for charging.
- Keep out of reach of children and pets.
- If the lamp is damaged or malfunctions, discontinue use immediately and contact customer support.

9. WARRANTY AND SUPPORT

Dawnwake products are designed for quality and reliability. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Dawnwake website.

Please retain your proof of purchase for any warranty claims.

