#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Breezary /
- > User Manual for Breezary 19" Retro Style Rattan Caged Ceiling Fan

## **Breezary 33077-GD-AMZ**

# **User Manual**

19" Retro Style Rattan Caged Ceiling Fan with Lights and Remote Control

Model: 33077-GD-AMZ | Brand: Breezary

#### IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before beginning installation and use. Failure to follow these instructions could result in electric shock, fire, or serious personal injury.

- Always disconnect power at the main circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar
  with wiring, consult a qualified electrician.
- Ensure the installation site can support the weight of the fan.
- Do not operate the fan with damaged wiring or if it has been dropped or damaged in any way.
- Keep hands, hair, and clothing away from the fan blades when the fan is operating.
- This fan is designed for indoor use only.

## WHAT'S IN THE BOX

Verify that all components are present before beginning assembly.

- 1 x 19 Inch 7-Blade Enclosed Ceiling Fan Light
- 1 x Remote Controller Kit
- 1 x Instruction Manual (this document)



Image: The Breezary 19-inch Retro Style Rattan Caged Ceiling Fan, showcasing its design and indicating the included remote control and instruction manual.

## **PRODUCT FEATURES**

- Retro Style Bladeless Design: Metal and rattan caged ceiling fan light with 7 blades and 4 x T45 light bases (bulbs not included), suitable for industrial, rustic, and modern decor.
- Quiet Reversible DC Motor: Pure copper DC motor provides strong and steady wind power with low noise (35dB). The reversible function allows for warm air circulation in winter and cooling in summer.
- Remote Control: Convenient remote offers 6 adjustable speeds, reversible rotation, and a timer function (1/2/4/8 hours).
- Flush Mount Design: 19-inch black caged design enhances aesthetics and provides reliable air circulation and lighting, ideal for various rooms.



Image: Illustration demonstrating the fan's reversible motor, showing downward airflow for cooling in summer and upward airflow for balanced warm air circulation in winter.



Image: A visual guide to the 6 adjustable fan speeds, categorizing them into low (1-2), medium (3-4), and high (5-6) for different comfort levels.



Image: An infographic illustrating the fan's ultra-quiet operation at 30dB, comparing it to sounds like a library (20dB), chat (50dB), and meeting (70dB).



# E26 Base Bulb - 4 Required (Not Included)

Recommended Bulb Types:



T45

Image: Three views of the fan demonstrating the light off, light on, and night-time illumination, with a note that four T45 E26 base bulbs are required (not included).

#### **SETUP & INSTALLATION**

This ceiling fan is designed for flush mount installation. Due to the electrical nature of this product, professional installation by a qualified electrician is recommended.

#### **Pre-Installation Checklist:**

- 1. Unpack all components and verify against the "What's in the Box" section.
- 2. Ensure power is disconnected at the circuit breaker.
- 3. Prepare the electrical box and mounting location according to local codes.

#### General Installation Steps (Refer to included manual for detailed diagrams):

- 1. Secure the mounting bracket to the ceiling electrical box.
- 2. Make electrical connections (Live, Neutral, Ground) as per the wiring diagram in the detailed instruction manual.
- 3. Attach the fan body to the mounting bracket.
- 4. Install the light bulbs (4 x T45 E26 base bulbs, not included).

- 5. Secure the light cover/cage.
- 6. Restore power and test the fan and light functions.




Image: A dimensional drawing of the fan, indicating its 19-inch diameter and 8-inch height, along with a recommendation for room sizes less than 5' x 10' for optimal performance in smaller spaces like hallways or laundry rooms.

## **OPERATING INSTRUCTIONS**

The Breezary 19" Retro Style Rattan Caged Ceiling Fan is operated using the included remote control.



Image: The remote control for the ceiling fan, highlighting buttons for power (ALL OFF, LIGHT ON/OFF), fan speed (1-6), natural wind mode, forward rotation (F), reverse rotation (R), and timer settings (1H/4H).

#### **Remote Control Functions:**

- ALL OFF: Turns off both the fan and the light.
- LIGHT ON/OFF: Toggles the light on or off.
- Fan Speed (1-6): Adjusts the fan speed from 1 (lowest) to 6 (highest).
- Natural Wind: Activates a mode that simulates natural breeze by varying fan speed.
- Forward Rotating (F): Sets the fan to rotate clockwise, pushing air downwards for a cooling effect (typically for summer).
- **Reverse Rotating (R):** Sets the fan to rotate counter-clockwise, drawing air upwards to circulate warm air (typically for winter).
- Timer (1H/4H): Sets the fan to automatically turn off after 1 hour or 4 hours.

#### MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Bulb Replacement:** Ensure power is off before replacing bulbs. This fan requires 4 x T45 E26 base bulbs (not included). Allow bulbs to cool before handling.
- Tightness Check: Periodically check all screws and connections for tightness.

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not operate.	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker; Verify all wiring connections are secure; Replace remote battery or re-pair remote (refer to detailed manual).
Light does not turn on.	Bulbs not installed or faulty; Loose wire connection; Light switch on remote is off.	Install or replace bulbs; Check light wiring; Press LIGHT ON/OFF button on remote.
Fan is noisy.	Loose screws on mounting bracket or fan body; Fan not properly secured.	Ensure all mounting screws are tight; Verify fan is securely attached to the ceiling.
Remote control not working.	Low or dead battery; Remote not paired with fan.	Replace battery; Follow pairing instructions in the full manual.

If problems persist after attempting these solutions, please contact customer support.

# **S**PECIFICATIONS

Attribute	Detail
Brand	Breezary
Model Name	19" Small Caged Ceiling Fan
Item Model Number	33077-GD-AMZ
Product Dimensions	19"L x 19"W x 8"H
Item Weight	4.5 Pounds
Material	ABS Plastic, Metal
Style	Retro/Farmhouse/Modern
Number of Blades	7
Motor Type	DC Motor
Reversible Motor	Yes
Control Method	Remote Control
Fan Speeds	6-Speed
Light Source Type	Incandescent (Bulbs Not Included)
Bulb Base	E26 (T45 recommended)

Attribute	Detail
Number of Light Sources	4
Voltage	120 Volts (DC)
Wattage	25 watts (fan motor)
Installation Type	Flush Mount
Indoor/Outdoor Usage	Indoor
Special Features	Bulbs Not Included, Flush Mount Design, Remote Controlled, Reversible DC Motor, Timer
Certification	ETL Listed

## WARRANTY & SUPPORT

This product comes with a **Limited Warranty**. Please refer to the original purchase documentation or contact Breezary customer service for specific warranty terms and conditions.

#### **Customer Support:**

For any questions regarding installation, operation, maintenance, or troubleshooting that are not covered in this manual, please contact Breezary customer service. Contact information can typically be found on the product packaging or the official Breezary website.


When contacting support, please have your product model number (33077-GD-AMZ) and purchase date available.

© 2025 Breezary. All rights reserved.

#### Related Documents - 33077-GD-AMZ



Breezary 35071 Ceiling Fan with Light: Installation & User Manual | 20-inch Satin Nickel Caged Fan Official installation and user manual for the Breezary 35071 Ceiling Fan with Light. Features include 20-inch Satin Nickel Caged design, 7 ABS Blades, and 6-speed operation. This guide provides safety guidelines, parts list, assembly instructions, wiring diagrams, remote functions, and troubleshooting tips for optimal performance.



#### 52 Inch Ceiling Fan with Light - Installation and User Manual - Model 29050

This manual provides comprehensive installation, operation, and troubleshooting instructions for the 52-inch ceiling fan with light, model number 29050. It includes safety precautions, parts identification, assembly steps, remote control functions, and solutions for common issues.