Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TYCOLE T2143

TYCOLE Wood Cabin Building Blocks Set with LED Lights (Model T2143) Instruction Manual

Model: T2143

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your TYCOLE Wood Cabin Building Blocks Set with LED Lights. This set allows you to construct a detailed two-story log cabin model, complete with interior furnishings and exterior forest elements. The integrated LED lighting system enhances the visual appeal of the completed model.



Image: The TYCOLE Wood Cabin Building Blocks Set, showcasing the completed model with its detailed log cabin design and surrounding forest elements.

Safety Information

WARNING: Not for children under 3 years.This product contains small parts which may pose a choking hazard. Adult supervision is recommended during assembly, especially for younger builders.

Package Contents

Before beginning assembly, please verify that all components are present in your package. The TYCOLE Wood Cabin Building Blocks Set includes:

- Approximately 1969 building block pieces.
- Multiple numbered bags containing sorted pieces.

- 5 LED light blocks for illumination.
- 1 Brick separator tool.
- Detailed instruction manual.
- Batteries (LR44, nonstandard battery) for LED lights are included.



Image: An overview of the product's size and included components, highlighting the 4 brick bags, 5 LED lights, brick separator tool, and clear instructions.

Assembly Guide

Follow the step-by-step instructions provided in the included manual to construct your wood cabin model. The assembly process is designed to be engaging and educational.

Step 1: Preparation

1. Unpack all contents and lay them out on a clean, flat surface.

2. Familiarize yourself with the instruction manual and the different types of pieces.
3. Locate the numbered bags, which correspond to specific sections of the build.

Step 2: Following the Manual

1. Begin with the first numbered bag and follow the instructions for that section.
2. Carefully observe the images in the manual, paying attention to piece orientation and placement.
3. Use the brick separator tool if you need to disassemble any incorrectly placed pieces.

Step 3: Building the Structure

1. The model features a two-story design with a removable roof and an open back for interior access.
2. Construct the base, then proceed to the first-floor living area, including furniture like sofas, a TV, clock, fireplace, and kitchen elements.
3. Build the second-floor bedroom, accessible via a ladder, furnishing it with a bed and wardrobe.
4. Integrate the exterior details such as trees, botanical elements, steps, openable doors, a toolbox, and a campfire as instructed.



Image: The TYCOLE Forest Wooden House Building Set, illustrating the complete model with its detailed exterior and natural surroundings.



Image: A father and son engaged in the assembly of the TYCOLE Wood Cabin, demonstrating the collaborative and enjoyable building process.

Operating the LED Lights

The TYCOLE Wood Cabin features integrated LED lighting to illuminate both the interior and exterior of the model. The lights are powered by LR44 nonstandard batteries, which are included.

- **Activation:** The LED light blocks are typically activated by a small switch or by inserting a specific piece that completes the circuit. Refer to the instruction manual for the exact activation method for each light block.
- **Battery Replacement:** If the lights dim or stop working, replace the LR44 batteries. Ensure correct polarity when inserting new batteries.



Image: A comparison showing the TYCOLE Wood Cabin model with its LED lights turned off and then illuminated, highlighting the enhanced visual effect.



Image: Close-up views of the cabin's interior, including the bedroom, wardrobe, living area, and kitchen, all illuminated by the integrated LED lights.

Care and Maintenance

To ensure the longevity and appearance of your TYCOLE Wood Cabin Building Blocks Set, follow these care guidelines:

- **Cleaning:** Dust the model regularly with a soft, dry cloth. For deeper cleaning, gently wipe pieces with a damp cloth and mild soap, then dry thoroughly. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the assembled model or individual pieces in a cool, dry place away from direct sunlight to prevent discoloration or warping.
- **Handling:** Handle the model with care to prevent pieces from detaching or breaking.

Troubleshooting

Missing Pieces

While quality control is maintained, occasionally a piece may be missing. If you encounter missing pieces, please contact customer support with details of the missing part (e.g., shape, color, step number in the manual).

LED Lights Not Working

- **Check Batteries:** Ensure the LR44 batteries are correctly installed and not depleted. Replace them if necessary.
- **Check Connections:** Verify that the LED light blocks are securely connected as per the instructions.
- **Internal Contacts:** If a light block is not functioning, it may be due to bent internal contacts. Carefully unscrew the bottom of the LED block and gently adjust the contacts to ensure they spring back and make proper connection when activated.

Product Specifications

Brand	TYCOLE
Model Number	T2143
Number of Pieces	1969
Material	Plastic
Color	Brown
Product Dimensions (L x W x H)	24.31 x 18.9 x 23.5 cm (9.57 x 7.44 x 9.25 inches)
Item Weight	1.36 kg (3 lbs)
Recommended Age	6 years and up
Batteries Required	Yes (LR44, nonstandard battery)
Batteries Included	Yes

Warranty and Customer Support

TYCOLE is committed to providing high-quality products. For any questions, concerns, or assistance with your building set, please contact our customer support team.

Email: TycoleCare@outlook.com

Please provide your model number (T2143) and a detailed description of your inquiry when contacting support.

© 2025 TYCOLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F18VN8RV

More documents and user manuals: **https://manuals.plus/**