

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [VIVO](#) /

> VIVO T4x Smartphone User Manual

## VIVO T4x

# VIVO T4x Smartphone User Manual

Model: T4x

## 1. INTRODUCTION

---

Welcome to the VIVO T4x user manual. This guide provides comprehensive instructions to help you set up, operate, maintain, and troubleshoot your new VIVO T4x smartphone. The VIVO T4x is designed to offer a balanced experience with its powerful Qualcomm Snapdragon 6 Gen 1 processor, a versatile camera system, and a long-lasting 6500mAh battery, all running on Android 14 with Funtouch OS 14.

Please read this manual carefully to ensure optimal performance and longevity of your device. Keep this manual for future reference.

## 2. DEVICE OVERVIEW

---

Familiarize yourself with the physical components of your VIVO T4x smartphone.



Image: The VIVO T4x smartphone in Pronto Purple. The front display highlights key features like the 6500mAh battery, Dimensity 7300 processor, and military-grade durability. The rear shows a triple camera setup with a flash module and the VIVO logo.

- **Front Display:** High-resolution screen for vibrant visuals. Features a punch-hole camera at the top center.
- **Rear Camera Module:** Located on the upper left of the back panel, featuring multiple lenses and a flash.
- **Power Button:** Typically on the right side, used to power on/off or wake/sleep the device.
- **Volume Buttons:** Usually above the power button, for adjusting audio levels.
- **USB Port:** Located at the bottom, for charging and data transfer.

- **SIM/SD Card Tray:** Typically on the left side, for inserting SIM cards and expandable memory.

## 3. WHAT'S IN THE BOX

---

Upon unboxing your VIVO T4x, please ensure all the following items are present:

- VIVO T4x Smartphone
- USB Type-C Cable
- Power Adapter (Charger)
- SIM Ejector Tool
- Quick Start Guide
- Warranty Card

*Note: Contents may vary slightly by region.*

## 4. SETUP

---

### 4.1. Inserting SIM and SD Card

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card into the designated slots on the tray, ensuring correct orientation.
4. Carefully push the tray back into the phone until it clicks into place.

### 4.2. Powering On and Initial Setup

1. Press and hold the Power button until the VIVO logo appears.
2. Follow the on-screen instructions to complete the initial setup:
  - Select your language and region.
  - Connect to a Wi-Fi network.
  - Accept the End User License Agreement.
  - Sign in with your Google account or create a new one.
  - Set up screen lock (PIN, pattern, password, fingerprint, face unlock).
  - Restore data from a previous device (optional).

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Basic Navigation

- **Touch:** Tap an icon to open an app or select an item.
- **Swipe:** Move your finger across the screen to scroll through pages or content.
- **Pinch:** Use two fingers to zoom in or out on photos and web pages.
- **Home Screen:** Swipe up from the bottom (if using gestures) or tap the Home button to return to the home screen.
- **Recent Apps:** Swipe up and hold from the bottom (gestures) or tap the Recent Apps button to view

and switch between open applications.

## 5.2. Calls and Messages

- **Making a Call:** Open the Phone app, enter the number, and tap the call icon.
- **Sending a Message:** Open the Messages app, tap 'Start chat', enter the recipient and your message.

## 5.3. Camera Usage

The VIVO T4x features a versatile camera system. Open the Camera app to access various modes:

- **Photo:** Standard mode for still images.
- **Video:** Record high-quality videos.
- **Portrait:** Create photos with a blurred background effect.
- **Night:** Enhance photos taken in low-light conditions.
- Explore other modes and settings within the camera app for creative photography.

## 5.4. Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi to connect to available networks.
- **Bluetooth:** Go to Settings > Connected devices > Bluetooth to pair with other Bluetooth devices.
- **USB:** Connect your phone to a computer using the USB cable for file transfer or charging.

## 5.5. Battery Management

Your VIVO T4x is equipped with a 6500mAh battery and supports fast charging. To optimize battery life:

- Reduce screen brightness.
- Turn off Wi-Fi, Bluetooth, and GPS when not in use.
- Close background apps.
- Enable Battery Saver mode in Settings > Battery.

## 6. MAINTENANCE AND CARE

---

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid harsh chemicals.
- **Software Updates:** Regularly check for system updates in Settings > System > System update to ensure your device has the latest features and security patches.
- **Battery Care:** Avoid extreme temperatures. Do not let the battery drain completely often. Use the original charger for optimal charging.
- **Storage Management:** Periodically clear unnecessary files and uninstall unused apps to free up storage space.
- **Environmental Conditions:** Protect your phone from water, dust, and direct sunlight.

## 7. TROUBLESHOOTING

---

If you encounter issues with your VIVO T4x, refer to the following common solutions:

- **Device Not Turning On:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Apps Freezing/Crashing:** Close the app from recent apps and reopen it. Clear the app's cache

(Settings > Apps > [App Name] > Storage & cache > Clear cache).

- **Network Issues (No Signal/Wi-Fi):** Restart your phone. Check if Airplane mode is off. Reset network settings (Settings > System > Reset options > Reset Wi-Fi, mobile & Bluetooth).
- **Slow Performance:** Close background apps. Clear cache. Check for system updates. Consider a factory reset as a last resort (back up your data first).

For persistent issues, please contact VIVO customer support.

## 8. SPECIFICATIONS

Key technical specifications for the VIVO T4x smartphone:

Feature	Specification
Operating System	Android 14 (with Funtouch OS 14)
RAM	6 GB
Internal Storage	128 GB
Processor	Qualcomm Snapdragon 6 Gen 1 (Octa-core, up to 2.5 GHz)
Battery Capacity	6500 Milliamp Hours (mAh)
Display Resolution	1080 x 2408
Connectivity	Bluetooth, USB, Wi-Fi, 5G
Special Features	Dual SIM, Expandable Memory, Fast Charging Support
Color	Pronto Purple
Item Weight	470 g
Country of Origin	India

## 9. WARRANTY AND SUPPORT

Your VIVO T4x smartphone comes with a limited manufacturer's warranty. Please refer to the warranty card included in your product packaging for detailed terms and conditions, including warranty period and coverage.

For technical support, service, or further inquiries, please visit the official VIVO India website or contact their customer service helpline. You can find contact information on the VIVO support page or in your quick start guide.

**Online Support:** [Visit VIVO India Support](#)

